Floor-Mounted Installation（MeetingBoard Pro）

For the operation video, please refer to Floor-Mounted - Teams/Floor-Mounted - Zoom.

## Package Contents

Floor Stand

Floor stand beam

A Screw X 4
（M6 × 12 mm）
* For mounting floor stand beam

B Screw X 6
（M6 × 20 mm）
For locking floor stand and endpoint

4mm Hex key

Rubber cap X 2

PC Patch X 2

Quick Start Guide
(Floor-Mounted)

Tray

Hook

Plug X 2
(with M6×15 mm screw)

C Screw X 4
（M5×10 mm）
* For locking hook

Hex key

Endpoint Installation

1. Lock the scroll wheels

2. Put down the floor stand and install the floor stand beam on the floor stand

A

⬡ X 4

(M6 × 12mm)

ⓘ If the beam is reversed, the screws will not fit in.

Put down one leg and install the beam with screw A

Raise the stand and install the other leg

2

3. Raise the endpoint, mount the endpoint into the floor stand, and tighten the screws on both sides of the legs of the floor stand

* We recommend 2 people working together to mount a 65-inch device or 75-inch device, and 4 people working together to mount an 86-inch device. (86-inch device can be carried by the handles on both sides)

B

X 6 (M6×20mm)

Rubber cap X 2

PC Patch X 2

* Match the colors of the stickers on the back of the endpoint and the floor stand respectively.

Tighten the screws B to prevent the floor stand from detaching from the endpoint, and affix the PC patch

1

2

Unlock the scroll wheels to move after installing.

Hardware Component Instructions

5

Microphone mute status indicator light

Camera
Lens

Microphone   Microphone

You can use HDMI Input source by connecting the HDMI cable. Meanwhile, you can use the endpoint control PC by connecting both HDMI cable and USB cable.

Connect Yealink accessories, etc（VCH51, VCM35)

VCH 2

VCH 1

USB (A - B) Cable
* Not included

Touch

PC

HDMI In

PC *** Not included**

HDMI Cable
* Not included

HDMI out

Display   Projector

HDMI Cable
* not included

Internet

3M CAT5e (RJ45- RJ45) Cable

LAN 1

Reset

Sensor   Speaker   Stylus pen   Speaker   Power
(Including power indicator light)

LAN port 1 can provide network access to both Android and Windows OPS simultaneously, but LAN port 2 can only provide network access to Android.

Wireless Presentation Pod
Purchased separately

USB flash drive
*** not Included**

Third-party Audio Input/Output Port

RCA in

RCA out

3M Power Cable (220V)

Not included accessories requirements:
- Display: Resolution of 1080p or higher and with an HDMI port.
- PC: Equipped with HDMI or USB-A Port.
- USB flash drive: With USB-A port.
- HDMI: Standard HDMI cable.
- USB-B cable: USB 2.0 (A - B) cable.

Power On

1. Insert the end of the power cable into the power port of the endpoint.
2. Insert the power cord plug into the outlet.
3. Turn the rocker switch button on the right rear of the endpoint to "I" to turn on the endpoint.

Upon first power-on of the endpoint, follow the on-screen setup wizard to configure language, time, network, etc., to initialize the configuration. The initialization operations vary with software versions.

ⓘ After the endpoint is started for the first time or restored to factory settings, go to settings on the touchscreen to configure the admin password (default password:0000).

Power Outage

Turn the rocker switch button on the right rear of the endpoint to "O" to turn off the endpoint.

After installing the deployment, you can refer to Quick Setup - Teams/Quick Setup - Zoom to set up the MeetingBoard. After setup, please refer to Quick Usage - Teams/Quick Usage - Zoom to learn about general functions.