# ZYXEL

## FWA710v2

5G NR Outdoor Router

## Quick Start Guide

ENGLISH | DEUTSCH


## Contents


Package Contents
Location Examples
SIM Card Installation
Cable Connections
Nebula Registration with the App
Nebula Registration via the Web
Management Methods – A or B
Option A - WiFi Connection
Option B - Ethernet Connection
Pole / Wall Mounting: Connect M Bracket and Main Frame
Wall Mounting
Pole Mounting
Pole / Wall Mounting Angle Adjustment
Grounding
Support Information


## Package Contents


Outdoor Router
Mounting Kit
Quick Start Guide
Safety Warning
Power Adapter
Ethernet Cable
Grounding Wire
Wall Anchor
Screw
Pole Mounting Strap
Screw
Screw
Screw

## Grounding




EN ① Remove the M4 ground screw from the Zyxel Device's rear panel as shown. Secure a green/yellow ground cable (18 AWG or smaller) to the Zyxel Device's rear panel using the M4 ground screw.

② Attach the other end of the cable to the ground, either to the same ground electrode as the pole you installed the device on or to the main grounding electrode of the building. Follow your country's regulations and safety instructions to electrically ground the device properly. Qualified service personnel must confirm that the building's protective earthing terminal is valid.

DE ① Entfernen Sie die M4 Erdungsschraube von der Rückwand des Zyxel-Gerät wie abgebildet. Befestigen Sie ein grün/gelbes Erdungskabel (18 AWG oder kleiner) mit der M4 Erdungsschraube an der Rückwand des Zyxel-Gerät.

② Befestigen Sie das andere Ende des Kabels an der Erdungseinrichtung, entweder an derselben Erdungselektrode wie die Stange, an der Sie das Gerät installiert haben oder der Haupterdungselektrode des Gebäudes. Befolgen Sie die nationalen Vorschriften und Sicherheitshinweise, um das Gerät richtig elektrisch zu erden. Qualifiziertes Servicepersonal muss bestätigen, dass die Schutzerdungsklemme des Gebäudes funktionsfähig ist.

## Support Information

**EU**
https://support.zyxel.eu

**USA**
+ 1 800 255 4101
support@zyxel.com

**Taiwan**
+ 886 2 2739 9889
retail@zyxel.com.tw

**Zyxel Community**
https://community.zyxel.com

**See the User's Guide at www.zyxel.com for more information, including customer support and safety warnings.**

**EU Importer**
Zyxel Networks A/S
Gladsaxevej 378, 2. th. 2860 Søborg, Denmark
https://www.zyxel.com/dk/da/

**UK Importer**
Zyxel Networks UK
2 Old Row Court, Rose Street, Wokingham, RG40 1XZ, United Kingdom (UK)
https://www.zyxel.com/uk/en/

**US Importer**
Zyxel Communications, Inc
1130 North Miller Street Anaheim, CA 92806-2001
https://www.zyxel.com/us/en/

Copyright © 2026 Zyxel and/or its affiliates. All Rights Reserved.

### Safety Warnings/ EU DECLARATION OF CONFORMITY

- There is a remote risk of electric shock from lightning: do not install, use, or service this device during a thunderstorm.
- Connect only suitable accessories to the device; make sure to connect the cables to the correct ports.
- Do not open the device, opening or removing covers can expose you to dangerous high voltage points or other risks. Please contact your vendor for further information.
- Place connecting cables carefully so that no one will step on them or stumble over them and disconnect all cables from this device before servicing or disassembling.
- Please use the provided or designated connection cables/power cables/ adaptors. connect it to the right supply voltage (for example, 120V AC in North America or 230V AC in Europe), If the power adaptor or cord is damaged, it might cause electrocution. remove it
- from the device and the power source, repairing the power adapter or cord is prohibited, contact your local vendor to order a new one.
- Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instruction.
- The socket-outlet shall be installed near the device, and shall be easily accessible because it serves as the main disconnecting device.

  This equipment should be installed and operated with a minimum distance of 40 cm between the radio equipment and your body.

**EU DECLARATION OF CONFORMITY**

Hereby, Zyxel declares that the FWA710v2 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.zyxel.com/global/en/support/download

**Disposal and Recycling Information**

The symbol below means that according to local regulations your product and/or its battery shall be disposed of separately from domestic waste. If this product is end of life, take it to a recycling station designated by local authorities. At the time of disposal, the separate collection of your product and/or its battery will help save natural resources and ensure that the environment is sustainable development.



### Sicherheitshinweise/ EU-Konformitätserklärung

- Bei einem Blitzeinschlag besteht die geringe Wahrscheinlichkeit eines Stromschlags: Dieser darf nicht während eines Gewitters installiert, benutzt und repariert werden.
- Nutzen Sie mit diesem Gerät nur geeignetes Zubehör; schließen Sie die Kabelstecker nur an die richtigen Anschlüsse an.
- Öffnen Sie nicht das Gerät. Beim Öffnen und Entfernen des Gehäuses legen Sie Hochspannung führende und andere unfallgefährliche Teile frei. Weitere Informationen dazu erhalten Sie bei Ihrem Händler.
- Verlegen Sie die Anschlusskabel so, das niemand darauf treten oder darüber stolpern kann. Trennen Sie vor dem Reparieren oder auseinander nehmen des Geräts zuerst alle Kabel ab.
- Verwenden Sie die mitgelieferten oder als geeignet deklarierte Verbindungskabel/Netzkabel/Adapter. Schließen Sie das Gerät an eine Netzsteckdose mit geeigneter Spannung an (z. B. 120 V AC in Nordamerika oder 230 V AC in Europa). Wenn der Netzadapter oder das Stromkabel beschädigt ist, besteht lebensgefährliche Stromschlaggefahr. Trennen Sie das beschädigte Kabel oder den Adapter vom Gerät und von der Stromquelle ab. Reparieren Sie in keinem Fall den Adapter oder das Kabel. Bestellen Sie einen neuen Adapter oder ein neues Kabel bei Ihrem Händler.
- Wenn der Akku durch einen Akku des falschen Typs ausgewechselt wird, besteht Explosionsgefahr. Entsorgen Sie den Akku gemäß der Anleitung.
- Achten Sie darauf, dass sich die Netzsteckdose in der Nähe des Geräts befindet und leicht zugänglich ist, da hier die Hauptverbindung des Geräts zum Stromnetz getrennt wird.
- Dieses Gerät sollte mit einem Mindestabstand von 40 cm zwischen dem Funkgerät und Ihrem Körper installiert und betrieben werden.

**EU-Konformitätserklärung**

Hiermit erklärt Zyxel, dass sich dieses FWA710v2 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: https://www.zyxel.com/global/en/support/download

**Informationen zu Entsorgung und Wiederaufbereitung**

Die folgende Symbol bedeutet, dass Ihr Produkt und/oder seine Batterie gemäß den örtlichen Bestimmungen getrennt vom Hausmüll entsorgt werden muss. Wenn dieses Gerät entsorgt werden soll, geben Sie es in einer Recycling-Station ab. Die getrennte Sammlung von Produkt und/oder seiner Batterie trägt dazu bei, natürliche Ressourcen zu sparen und die Umwelt und die menschliche Gesundheit zu schützen.

