ZYXEL
NWA50AX
Dual-Radio AX1800 PoE Access Point
Quick Start Guide

Quick Start Guide

English · Deutsch · Español · Français · Italiano · Português · Polski · Čeština · Slovenčina · Русский · Українська · Türkçe · Magyar · Hrvatski · Ελληνικά · Nederlands · Slovenščina · Eesti · Latviešu valoda · Lietuvių kalba · العربية · Español (Latinoamérica) · Português (Brasil) · 繁體中文 · 简体中文 · 日本語 · 한국어

Contents

See contents in other languages.

Hardware Connection

Hardware Connection

Connect the hardware according to your application.

Cable Connection

1. Connect the Ethernet cable to the PoE port on the NWA50AX.
2. Connect the other end of the Ethernet cable to a PoE injector or PoE switch.
3. Connect the PoE injector or PoE switch to the Ethernet port on your gateway or router.

Power Adapter Connection

1. Connect the power adapter to the power port on the NWA50AX.
2. Plug the power adapter into an electrical outlet.

Video Tutorials

Watch the Zyxel Network Video Tutorials (YouTube) with the following QR code.

Watch the Zyxel Network Video Tutorials (YouTube) with the following QR code.

NWA50AX
How to Configure Nebula Mode

NWA50AX
How to Configure Standalone Mode

1. Wall mounted camera: ezviz The wall mounted camera supports the ezviz Cloud Storage.
2. Ceiling mounted camera: ezviz The ceiling mounted camera supports the ezviz Cloud Storage.
3. Wall mounted camera: Network Video Recorder The wall mounted camera supports the Network Video Recorder.
4. Ceiling mounted camera: Network Video Recorder The ceiling mounted camera supports the Network Video Recorder.
5. Wall mounted camera: Power Adapter The wall mounted camera supports the Power Adapter.
6. Ceiling mounted camera: Power Adapter The ceiling mounted camera supports the Power Adapter.
7. Wall mounted camera: Power Source The wall mounted camera supports the Power Source.
8. Ceiling mounted camera: Power Source The ceiling mounted camera supports the Power Source.

Note: The Network Video Recorder supports the Cloud Storage.

Note: The Power Adapter supports the Power Source.

Note: The Power Source supports the Power Source.

Note: The Power Source supports the Power Source.

Note: The Power Source