ZYXEL
XGS Series
IAP5000E
802.11be Wi-Fi 7 Dual Radio
Industrial Unified Access Point

Quick Start Guide

English | 繁體中文 | 简体中文 | 日本語 | Français | Deutsch | Español | Italiano | Русский | Polski | Čeština | Slovenčina | Magyar | Português | Română | Български | Українська | Suomi | Svenska | Dansk | Norsk | Nederlands | 한국어 | ภาษาไทย

Contents

Grounding
Hardware Connections
Power Options
Using PoE
Using DC Power
Front Panel Indicators
Rear Panel
Wall Mounting
Management Options
Website Management with the App
Website Management with the Web Portal
Device Management with the Nebula Control Center
Support Information

Grounding

Secure a green and yellow grounded cable (16 AWG) to a grounded metal object, such as a metal rack. Connect the other end of the grounded cable to the grounding terminal on the rear panel. Remove the insulation.

Sichern Sie ein grün-gelbes geerdetes Kabel (16 AWG) an einem geerdeten Metallobjekt, wie z. B. einem Metallrack. Verbinden Sie das andere Ende des geerdeten Kabels mit der Erdungsklemme auf der Rückseite. Entfernen Sie die Isolierung.

Fixez un câble mis à la terre vert et jaune (16 AWG) à un objet métallique mis à la terre, tel qu'un rack métallique. Connectez l'autre extrémité du câble mis à la terre à la borne de mise à la terre du panneau arrière. Retirez l'isolation.

Fissare un cavo di messa a terra verde e giallo (16 AWG) a un oggetto metallico messo a terra, come un rack metallico. Collegare l'altra estremità del cavo di messa a terra al terminale di messa a terra sul pannello posteriore. Rimuovere l'isolamento.

Asegure un cable a tierra verde y amarillo (16 AWG) a un objeto metálico conectado a tierra, como un bastidor metálico. Conecte el otro extremo del cable a tierra al terminal de conexión a tierra del panel posterior. Retire el aislamiento.

Sichern Sie ein grün-gelbes geerdetes Kabel (16 AWG) an einem geerdeten Metallobjekt, z. B. einem Metallrack. Verbinden Sie das andere Ende des geerdeten Kabels mit der Erdungsklemme auf der Rückseite. Entfernen Sie die Isolierung.

Fixe um cabo verde e amarelo aterrado (16 AWG) a um objeto metálico aterrado, como um rack metálico. Conecte a outra extremidade do cabo aterrado ao terminal de aterramento no painel traseiro. Remova o isolamento.

Закрепите заземленный кабель зеленого и желтого цвета (16 AWG) на заземленном металлическом объекте, например на металлической стойке. Подключите другой конец заземленного кабеля к заземляющей клемме на задней панели. Снимите изоляцию.

Przymocuj uziemiony kabel zielono-żółty (16 AWG) do uziemionego metalowego obiektu, takiego jak metalowy stojak. Podłącz drugi koniec uziemionego kabla do zacisku uziemienia na tylnym panelu. Zdejmij izolację.

Připevněte uzemněný kabel zelené a žluté barvy (16 AWG) k uzemněnému kovovému objektu, například kovovému stojanu. Připojte druhý konec uzemněného kabelu k uzemňovací svorce na zadním panelu. Odstraňte izolaci.

Pripevnite uzemnený kábel zelenej a žltej farby (16 AWG) k uzemnenému kovovému objektu, napríklad kovovému stojanu. Pripojte druhý koniec uzemneného kábla k uzemňovacej svorke na zadnom paneli. Odstráňte izoláciu.

Rögzítsen egy zöld-sárga földelt kábelt (16 AWG) egy földelt fémtárgyhoz, például egy fém állványhoz. Csatlakoztassa a földelt kábel másik végét a hátlapon található földelő csatlakozóhoz. Távolítsa el a szigetelést.

Prenda um cabo verde e amarelo aterrado (16 AWG) a um objeto metálico aterrado, como um rack metálico. Ligue a outra extremidade do cabo aterrado ao terminal de ligação à terra no painel traseiro. Remova o isolamento.

Fixați un cablu împământat verde și galben (16 AWG) de un obiect metalic împământat, cum ar fi un rack metalic. Conectați celălalt capăt al cablului împământat la terminalul de împământare de pe panoul din spate. Îndepărtați izolația.

Закрепете заземения зелен и жълт кабел (16 AWG) към заземен метален предмет, като например метална стойка. Свържете другия край на заземения кабел към заземителната клема на задния панел. Отстранете изолацията.

Прикріпіть заземлений зелений і жовтий кабель (16 AWG) до заземленого металевого предмета, наприклад металевої стійки. Підключіть інший кінець заземленого кабелю до заземлювального затискача на задній панелі. Зніміть ізоляцію.

Kiinnitä maadoitettu vihreä ja keltainen kaapeli (16 AWG) maadoitettuun metalliesineeseen, kuten metallitelineeseen. Liitä maadoitetun kaapelin toinen pää takapaneelin maadoitusliittimeen. Poista eristys.

Fäst en jordad grön och gul kabel (16 AWG) till ett jordat metallföremål, till exempel ett metallställ. Anslut den andra änden av den jordade kabeln till jordningsplinten på bakpanelen. Ta bort isoleringen.

Fastgør et jordet grønt og gult kabel (16 AWG) til en jordet metalgenstand, såsom et metalstativ. Tilslut den anden ende af det jordede kabel til jordforbindelsesterminalen på bagpanelet. Fjern isoleringen.

Fest en jordet grønn og gul kabel (16 AWG) til et jordet metallobjekt, for eksempel et metallstativ. Koble den andre enden av den jordede kabelen til jordingsterminalen på bakpanelet. Fjern isolasjonen.

Bevestig een geaarde groen-gele kabel (16 AWG) aan een geaard metalen object, zoals een metalen rek. Sluit het andere uiteinde van de geaarde kabel aan op de aardingsklem op het achterpaneel. Verwijder de isolatie.

접지된 녹색 및 노란색 케이블(16 AWG)을 랙과 같은 접지된 금속 물체에 고정합니다. 접지된 케이블의 다른 쪽 끝을 후면 패널의 접지 단자에 연결합니다. 절연체를 제거합니다.

ยึดสายดินสีเขียวและสีเหลือง (16 AWG) เข้ากับวัตถุโลหะที่ต่อสายดิน เช่น แร็คโลหะ เชื่อมต่อปลายอีกด้านของสายดินเข้ากับขั้วต่อสายดินบนแผงด้านหลัง ถอดฉนวนหุ้มออก

Hardware Connections

1 Attach the antennas to the front of the Guest Service. Turn the antennas upright.
2 Befestigen Sie die Antennen an der Vorderseite des Gast-Service. Drehen Sie die Antennen aufrecht.
3 Fixez les antennes à l'avant du service invité. Tournez les antennes vers le haut.
4 Fissare le antenne sulla parte anteriore del servizio ospiti. Orientare le antenne in posizione verticale.
5 Conecte las antenas a la parte delantera del servicio de invitados. Coloque las antenas en posición vertical.
6 Befestigen Sie die Antennen an der Vorderseite des Gast-Service. Drehen Sie die Antennen aufrecht.
7 Prenda as antenas à parte frontal do Serviço de convidados. Direcione as antenas para cima.
8 Прикрепите антенны к передней панели гостевой службы. Установите антенны в вертикальное положение.
9 Podłącz anteny do przedniej części usługi gościnnej. Ustaw anteny w pozycji pionowej.
10 Připojte antény k přední straně hostujícího servisu. Otočte antény svisle nahoru.
11 Pripojte antény k prednej strane hosťovskej služby. Otočte antény zvislo nahor.
12 Csatlakoztassa az antennákat a vendégszolgálat elejéhez. Állítsa függőlegesre az antennákat.
13 Prenda as antenas à parte frontal do Serviço de convidados. Direcione as antenas para cima.
14 Fixați antenele la partea frontală a serviciului pentru oaspeți. Poziționați antenele în poziție verticală.
15 Свържете антените към предната част на гостовата услуга. Завъртете антените в изправено положение.
16 Кріпіть антени до передньої частини гостьової служби. Поверніть антени вертикально.
17 Kiinnitä antennit vieraspalvelun etuosaan. Käännä antennit pystyasentoon.
18 Fäst antennerna på framsidan av gästtjänsten. Vrid antennerna upprätt.
19 Fastgør antennerne til forsiden af gæstetjenesten. Drej antennerne opretstående.
20 Fest antennene til forsiden av gjesteservicen. Vri antennene oppreist.
21 Bevestig de antennes aan de voorkant van de Guest Service. Draai de antennes rechtop.
22 게스트 서비스 전면에 안테나를 부착합니다. 안테나를 똑바로 세웁니다.
23 ติดเสาอากาศเข้ากับด้านหน้าของบริการสำหรับแขก หมุนเสาอากาศขึ้นในแนวตั้ง

Hardware Connections

1 Connect the ethernet cable to the Guest Service. Turn the antenna upright.
2 Verbinden Sie das Ethernet-Kabel mit dem Gast-Service. Drehen Sie die Antenne aufrecht.
3 Connectez le câble ethernet au service invité. Tournez l'antenne vers le haut.
4 Collegare il cavo ethernet al servizio ospiti. Orientare l'antenna in posizione verticale.
5 Conecte el cable ethernet al servicio de invitados. Coloque la antena en posición vertical.
6 Verbinden Sie das Ethernet-Kabel mit dem Gast-Service. Drehen Sie die Antenne aufrecht.
7 Conecte o cabo ethernet ao Serviço de convidados. Direcione a antena para cima.
8 Подключите кабель Ethernet к гостевой службе. Установите антенну в вертикальное положение.
9 Podłącz kabel ethernet do usługi gościnnej. Ustaw antenę w pozycji pionowej.
10 Připojte ethernetový kabel k hostujícímu servisu. Otočte anténu svisle nahoru.
11 Pripojte ethernetový kábel k hosťovskej službe. Otočte anténu zvislo nahor.
12 Csatlakoztassa az ethernet kábelt a vendégszolgálathoz. Állítsa függőlegesre az antennát.
13 Conecte o cabo ethernet ao Serviço de convidados. Direcione a antena para cima.
14 Conectați cablul ethernet la serviciul pentru oaspeți. Poziționați antena în poziție verticală.
15 Свържете ethernet кабела към гостовата услуга. Завъртете антената в изправено положение.
16 Підключіть кабель Ethernet до гостьової служби. Поверніть антену вертикально.
17 Kytke ethernet-kaapeli vieraspalveluun. Käännä antenni pystyasentoon.
18 Anslut ethernetkabeln till gästtjänsten. Vrid antennen upprätt.
19 Tilslut ethernetkablet til gæstetjenesten. Drej antennen opretstående.
20 Koble ethernetkabelen til gjesteservicen. Vri antennen oppreist.
21 이더넷 케이블을 게스트 서비스에 연결합니다. 안테나를 똑바로 세웁니다.
22 เชื่อมต่อสายอีเทอร์เน็ตเข้ากับบริการสำหรับแขก หมุนเสาอากาศขึ้นในแนวตั้ง

Power Options

Using PoE

1 Connect the other end of the Ethernet cable to a PoE Switch or PoE injector.
2 Schließen Sie das andere Ende des Ethernet-Kabels an den PoE-Switch oder den PoE-Injektor an.
3 Connectez l'autre extrémité du câble Ethernet à un commutateur PoE ou à un injecteur PoE.
4 Collegare l'altra estremità del cavo Ethernet a uno switch PoE o a un injector PoE.
5 Conecte el otro extremo del cable Ethernet a un conmutador PoE o a un inyector PoE.
6 Schließen Sie das andere Ende des Ethernet-Kabels an den PoE-Switch oder den PoE-Injektor an.
7 Conecte a outra extremidade do cabo Ethernet a um switch PoE ou a um injetor PoE.
8 Подключите другой конец кабеля Ethernet к коммутатору PoE или инжектору PoE.
9 Podłącz drugi koniec kabla ethernet do przełącznika PoE lub wstrzykiwacza PoE.
10 Připojte druhý konec ethernetového kabelu k přepínači PoE nebo injektoru PoE.
11 Pripojte druhý koniec ethernetového kábla k prepínaču PoE alebo injektoru PoE.
12 Csatlakoztassa az ethernet kábel másik végét egy PoE kapcsolóhoz vagy PoE injektorhoz.
13 Conecte a outra extremidade do cabo Ethernet a um switch PoE ou a um injetor PoE.
14 Conectați celălalt capăt al cablului Ethernet la un switch PoE sau la un injector PoE.
15 Свържете другия край на ethernet кабела към PoE суич или PoE инжектор.
16 Підключіть інший кінець кабелю Ethernet до комутатора PoE або інжектора PoE.
17 Liitä Ethernet-kaapelin toinen pää PoE-kytkimeen tai PoE-ruiskuttimeen.
18 Anslut den andra änden av ethernetkabeln till en PoE-switch eller PoE-injektor.
19 Tilslut den anden ende af ethernetkablet til en PoE-switch eller PoE-injektor.
20 Koble den andre enden av ethernetkabelen til en PoE-svitsj eller PoE-injektor.
21 이더넷 케이블의 다른 쪽 끝을 PoE 스위치 또는 PoE 인젝터에 연결합니다.
22 เชื่อมต่อปลายอีกด้านของสายอีเทอร์เน็ตเข้ากับสวิตช์ PoE หรืออินเจคเตอร์ PoE

Using DC Power

1 Front Panel Cover
2 Terminal Block

1 The Guest Service can be powered from two power supplies that range from 9 V~ 57 V.
2 Der Gast-Service kann von zwei Netzteilen mit Strom versorgt werden, die von 9 V bis 57 V reichen.
3 Le service invité peut être alimenté par deux alimentations, chacune allant de 9 V~ 57 V.
4 Il servizio ospiti può essere alimentato da due alimentatori che vanno da 9 V~ 57 V.
5 El servicio de invitados puede recibir energía de dos fuentes de alimentación que van de 9 V~ 57 V.
6 Der Gast-Service kann von zwei Netzteilen mit Strom versorgt werden, die von 9 V bis 57 V reichen.
7 O Serviço de convidados pode ser alimentado por duas fontes de alimentação que variam de 9 V~ 57 V.
8 Гостевая служба может питаться от двух источников питания, которые варьируются от 9 В~ 57 В.
9 Usługa gościnna może być zasilana z dwóch zasilaczy o napięciu od 9 V~ 57 V.
10 Hostující servis může být napájen ze dvou napájecích zdrojů v rozsahu 9 V~ 57 V.
11 Hosťovská služba môže byť napájaná z dvoch napájacích zdrojov v rozsahu 9 V~ 57 V.
12 A vendégszolgálat két tápegységről működtethető, amelyek 9 V~ 57 V közötti feszültséget biztosítanak.
13 O Serviço de convidados pode ser alimentado por duas fontes de alimentação que variam de 9 V~ 57 V.
14 Serviciul pentru oaspeți poate fi alimentat de la două surse de alimentare care variază între 9 V~ 57 V.
15 Гостовата услуга може да се захранва от две захранващи устройства, които варират от 9 V~ 57 V.
16 Гостьова служба може живитися від двох джерел живлення, що коливаються від 9 В~ 57 В.
17 Vieraspalvelua voidaan syöttää kahdella virtalähteellä, jotka vaihtelevat 9 V~ 57 V.
18 Gästtjänsten kan drivas av två strömförsörjningar som sträcker sig från 9 V~ 57 V.
19 Gæstetjenesten kan drives af to strømforsyninger, der spænder fra 9 V~ 57 V.
20 Gjesteservicen kan drives av to strømforsyninger som varierer fra 9 V~ 57 V.
21 게스트 서비스는 9V~57V 범위의 두 개의 전원 공급 장치로 전원을 공급할 수 있습니다.
22 บริการสำหรับแขกสามารถจ่ายไฟจากแหล่งจ่ายไฟสองแหล่งที่มีช่วงตั้งแต่ 9 V~ 57 V

Front Panel Indicators

1 Power LED
2 Ethernet LED
3 Console Port
4 Reset Button
5 USB 3.0 Port
6 Ethernet Port
7 Grounding Terminal
8 Power Connector

1 Power LED
2 Ethernet LED
3 Konsolenport
4 Reset-Taste
5 USB 3.0-Port
6 Ethernet-Port
7 Erdungsklemme
8 Stromanschluss
1 Voyant d'alimentation
2 Voyant Ethernet
3 Port console
4 Bouton de réinitialisation
5 Port USB 3.0
6 Port Ethernet
7 Borne de mise à la terre
8 Connecteur d'alimentation
1 LED di alimentazione
2 LED Ethernet
3 Porta console
4 Pulsante di reset
5 Porta USB 3.0
6 Porta Ethernet
7 Terminale di messa a terra
8 Connettore di alimentazione
1 LED de encendido
2 LED Ethernet
3 Puerto de consola
4 Botón de reinicio
5 Puerto USB 3.0
6 Puerto Ethernet
7 Terminal de conexión a tierra
8 Conector de alimentación
1 Power LED
2 Ethernet LED
3 Konsolenport
4 Reset-Taste
5 USB 3.0-Port
6 Ethernet-Port
7 Erdungsklemme
8 Stromanschluss
1 LED de energia
2 LED Ethernet
3 Porta de consola
4 Botão de reinicialização
5 Porta USB 3.0
6 Porta Ethernet
7 Terminal de aterramento
8 Conector de energia
1 Светодиод питания
2 Светодиод Ethernet
3 Консольный порт
4 Кнопка сброса
5 Порт USB 3.0
6 Порт Ethernet
7 Заземляющая клемма
8 Разъем питания
1 Dioda LED zasilania
2 Dioda LED Ethernet
3 Port konsoli
4 Przycisk resetowania
5 Port USB 3.0
6 Port Ethernet
7 Zacisk uziemienia
8 Złącze zasilania
1 LED napájení
2 LED Ethernet
3 Konzolový port
4 Tlačítko reset
5 Port USB 3.0
6 Ethernetový port
7 Uzemňovací svorka
8 Napájecí konektor
1 Tápfeszültség LED
2 Ethernet LED
3 Konzolport
4 Visszaállítás gomb
5 USB 3.0 port
6 Ethernet port
7 Földelő csatlakozó
8 Tápcsatlakozó
1 LED de energia
2 LED Ethernet
3 Porta de consola
4 Botão de reinicialização
5 Porta USB 3.0
6 Porta Ethernet
7 Terminal de aterramento
8 Conector de energia
1 LED de alimentare
2 LED Ethernet
3 Port consolă
4 Buton de resetare
5 Port USB 3.0
6 Port Ethernet
7 Terminal de împământare
8 Conector de alimentare
1 Светодиод за захранване
2 Светодиод Ethernet
3 Конзолен порт
4 Бутон за нулиране
5 USB 3.0 порт
6 Ethernet порт
7 Заземителна клема
8 Захранващ конектор
1 Світлодіод живлення
2 Світлодіод Ethernet
3 Консольний порт
4 Кнопка скидання
5 Порт USB 3.0
6 Порт Ethernet
7 Заземлювальний затискач
8 Роз'єм живлення
1 Virran merkkivalo
2 Ethernet-merkkivalo
3 Konsoliportti
4 Nollauspainike
5 USB 3.0 -portti
6 Ethernet-portti
7 Maadoitusliitin
8 Virtaliitin
1 Strömlysdiod
2 Ethernet-lysdiod
3 Konsolport
4 Återställningsknapp
5 USB 3.0-port
6 Ethernet-port
7 Jordningsplint
8 Strömkontakt
1 Strømindikator
2 Ethernet-indikator
3 Konsolport
4 Nulstillingsknap
5 USB 3.0-port
6 Ethernet-port
7 Jordforbindelsesterminal
8 Strømstik
1 Strømindikator
2 Ethernet-indikator
3 Konsollport
4 Tilbakestillingsknapp
5 USB 3.0-port
6 Ethernet-port
7 Jordingsterminal
8 Strømkontakt
1 전원 LED
2 이더넷 LED
3 콘솔 포트
4 재설정 버튼
5 USB 3.0 포트
6 이더넷 포트
7 접지 단자
8 전원 커넥터
1 ไฟ LED แสดงสถานะการจ่ายไฟ
2 ไฟ LED แสดงสถานะอีเทอร์เน็ต
3 พอร์ตคอนโซล
4 ปุ่มรีเซ็ต
5 พอร์ต USB 3.0
6 พอร์ตอีเทอร์เน็ต
7 ขั้วต่อสายดิน
8 ขั้วต่อไฟฟ้า

Rear Panel

1 Kensington Lock Slot
2 Grounding Terminal
3 Power Connector
4 Ethernet Port
5 USB 3.0 Port
6 Reset Button
7 Console Port

1 Kensington-Schloss-Steckplatz
2 Erdungsklemme
3 Stromanschluss
4 Ethernet-Port
5 USB 3.0-Port
6 Reset-Taste
7 Konsolenport
1 Fente pour verrou Kensington
2 Borne de mise à la terre
3 Connecteur d'alimentation
4 Port Ethernet
5 Port USB 3.0
6 Bouton de réinitialisation
7 Port console
1 Slot per lucchetto Kensington
2 Terminale di messa a terra
3 Connettore di alimentazione
4 Porta Ethernet
5 Porta USB 3.0
6 Pulsante di reset
7 Porta console
1 Ranura para candado Kensington
2 Terminal de conexión a tierra
3 Conector de alimentación
4 Puerto Ethernet
5 Puerto USB 3.0
6 Botón de reinicio
7 Puerto de consola
1 Slot para cadeado Kensington
2 Terminal de aterramento
3 Conector de energia
4 Porta Ethernet
5 Porta USB 3.0
6 Botão de reinicialização
7 Porta de consola
1 Гнездо для замка Kensington
2 Заземляющая клемма
3 Разъем питания
4 Порт Ethernet
5 Порт USB 3.0
6 Кнопка сброса
7 Консольный порт
1 Gniazdo zamka Kensington
2 Zacisk uziemienia
3 Złącze zasilania
4 Port ethernet
5 Port USB 3.0
6 Przycisk resetowania
7 Port konsoli
1 Slot pro zámek Kensington
2 Uzemňovací svorka
3 Napájecí konektor
4 Ethernetový port
5 Port USB 3.0
6 Tlačítko reset
7 Konzolový port
1 Kensington-zárnyílás
2 Földelő csatlakozó
3 Tápcsatlakozó
4 Ethernet port
5 USB 3.0 port
6 Visszaállítás gomb
7 Konzolport
1 Slot para cadeado Kensington
2 Terminal de aterramento
3 Conector de energia
4 Porta Ethernet
5 Porta USB 3.0
6 Botão de reinicialização
7 Porta de consola
1 Slot pentru lacăt Kensington
2 Terminal de împământare
3 Conector de alimentare
4 Port Ethernet
5 Port USB 3.0
6 Buton de resetare
7 Port consolă
1 Слот за ключалка Kensington
2 Заземителна клема
3 Захранващ конектор
4 Ethernet порт
5 USB 3.0 порт
6 Бутон за нулиране
7 Конзолен порт
1 Гніздо для замка Kensington
2 Заземлювальний затискач
3 Роз'єм живлення
4 Порт Ethernet
5 Порт USB 3.0
6 Кнопка скидання
7 Консольний порт
1 Kensington-lukkopaikka
2 Maadoitusliitin
3 Virtaliitin
4 Ethernet-portti
5 USB 3.0 -portti
6 Nollauspainike
7 Konsoliportti
1 Kensington-låsspår
2 Jordningsplint
3 Strömkontakt
4 Ethernet-port
5 USB 3.0-port
6 Återställningsknapp
7 Konsolport
1 Kensington-låseåbning
2 Jordforbindelsesterminal
3 Strømstik
4 Ethernet-port
5 USB 3.0-port
6 Nulstillingsknap
7 Konsollport
1 Kensington-låseåpning
2 Jordingsterminal
3 Strømkontakt
4 Ethernet-port
5 USB 3.0-port
6 Tilbakestillingsknapp
7 Konsollport
1 Kensington 잠금 슬롯
2 접지 단자
3 전원 커넥터
4 이더넷 포트
5 USB 3.0 포트
6 재설정 버튼
7 콘솔 포트
1 ช่องล็อค Kensington
2 ขั้วต่อสายดิน
3 ขั้วต่อไฟฟ้า
4 พอร์ตอีเทอร์เน็ต
5 พอร์ต USB 3.0
6 ปุ่มรีเซ็ต
7 พอร์ตคอนโซล

Wall Mounting

1 Drill two holes 6 mm in diameter and 25 mm deep in a wall. The holes should be 75 mm apart.
2 Bohren Sie zwei Löcher mit einem Durchmesser von 6 mm und einer Tiefe von 25 mm in eine Wand. Die Löcher sollten 75 mm voneinander entfernt sein.
3 Percez deux trous de 6 mm de diamètre et de 25 mm de profondeur dans un mur. Les trous doivent être espacés de 75 mm.
4 Praticare due fori del diametro di 6 mm e profondi 25 mm in una parete. I fori devono essere distanti 75 mm.
5 Perfore dos orificios de 6 mm de diámetro y 25 mm de profundidad en una pared. Los orificios deben estar separados por 75 mm.
6 Bohren Sie zwei Löcher mit einem Durchmesser von 6 mm und einer Tiefe von 25 mm in eine Wand. Die Löcher sollten 75 mm voneinander entfernt sein.
7 Faça dois furos com 6 mm de diâmetro e 25 mm de profundidade em uma parede. Os furos devem ficar a 75 mm de distância.
8 Просверлите два отверстия диаметром 6 мм и глубиной 25 мм в стене. Отверстия должны быть на расстоянии 75 мм друг от друга.
9 Wywierć dwa otwory o średnicy 6 mm i głębokości 25 mm w ścianie. Otwory powinny być oddalone od siebie o 75 mm.
10 Vyvrtejte dva otvory o průměru 6 mm a hloubce 25 mm do stěny. Otvory by měly být od sebe vzdáleny 75 mm.
11 Vyvŕtajte dva otvory s priemerom 6 mm a hĺbkou 25 mm do steny. Otvory by mali byť od seba vzdialené 75 mm.
12 Fúrjon két 6 mm átmérőjű és 25 mm mély lyukat a falba. A lyukak 75 mm távolságra legyenek egymástól.
13 Faça dois furos com 6 mm de diâmetro e 25 mm de profundidade em uma parede. Os furos devem ficar a 75 mm de distância.
14 Forați două găuri cu diametrul de 6 mm și adâncimea de 25 mm într-un perete. Găurile trebuie să fie la 75 mm distanță.
15 Пробийте два отвора с диаметър 6 мм и дълбочина 25 мм в стена. Отворите трябва да са на разстояние 75 мм.
16 Просвердліть два отвори діаметром 6 мм і глибиною 25 мм у стіні. Отвори повинні бути на відстані 75 мм.
17 Poraa seinään kaksi 6 mm halkaisijaltaan ja 25 mm syvää reikää. Reikien tulee olla 75 mm:n päässä toisistaan.
18 Borra två hål med en diameter på 6 mm och ett djup på 25 mm i en vägg. Hålen ska vara 75 mm från varandra.
19 Bor to huller med en diameter på 6 mm og en dybde på 25 mm i en væg. Hullerne skal være 75 mm fra hinanden.
20 Bor to hull med en diameter på 6 mm og en dybde på 25 mm i en vegg. Hullene skal være 75 mm fra hverandre.
21 벽에 지름 6mm, 깊이 25mm의 구멍 두 개를 뚫습니다. 구멍 사이의 간격은 75mm여야 합니다.
22 เจาะรูสองรูที่มีเส้นผ่านศูนย์กลาง 6 มม. และลึก 25 มม. ในผนัง รูควรห่างกัน 75 มม.

Management Options

Website Management with the App

Nebula Mobile App > Site-Wide > Devices > Access Points

Website Management with the Web Portal

Access the device's web portal to configure its settings.

Device Management with the Nebula Control Center

Nebula Control Center allows you to monitor and manage all Zyxel Nebula devices over the Internet.

Support Information

Support Notes, Knowledge Base, Product Registration
https://support.zyxel.com

DIN-Rail Mounting



1. Remove the 2 screws on the Zyxel Device and screw the DIN-Rail bracket to the Zyxel Device.
Hook the Zyxel Device over the DIN-rail.
Push the Zyxel Device down and screw the DIN-rail to the Zyxel Device.

Retirez les 2 vis sur le Zyxel Device et vissez le support de rail DIN sur le Zyxel Device.
Accrochez le Zyxel Device sur le rail DIN.
Poussez le Zyxel Device vers le bas et vissez le rail DIN sur le Zyxel Device.

Entfernen Sie die 2 Schrauben am Zyxel Device Zyxel und schrauben Sie die DIN-Schiene an das Zyxel Device.
Befestigen Sie das Zyxel Device Zyxel Device an der Hutschiene.
Drücken Sie das Zyxel Device nach unten und schrauben Sie die Hutschiene an das Zyxel Device.

Retire los 2 tornillos del Zyxel Device y atornille el soporte DIN-Rail en el Zyxel Device.
Enganche el Zyxel Device en el riel DIN.
Empuje la parte inferior del Zyxel Device hacia el riel DIN y atornille el riel DIN en el Zyxel Device.

Rimuovere le 2 viti su un Zyxel Device e avvitare la staffa per il rack DIN sul dispositivo Zyxel Device.
Agganciare il Zyxel Device Zyxel Device al rack DIN.
Premere in basso il Zyxel Device e avvitare il rack DIN al Zyxel Device.

Verwijder de 2 schroeven op het Zyxel Device Zyxel Device en schroef de DIN-rail beugel op het Zyxel Device.
Haak het Zyxel Device Zyxel Device over de DIN-rail.
Druk het Zyxel Device naar beneden en schroef de DIN-rail op het Zyxel Device.

Remova os 2 parafusos no Zyxel Device e aparafuse o suporte DIN-Rail no Zyxel Device.
Encaixe o Zyxel Device no trilho DIN.
Empurre o Zyxel Device para baixo e aparafuse o trilho DIN no Zyxel Device.

Usuń 2 śruby na Zyxel Device i przykręć wspornik do montażu na szynie DIN do Zyxel Device.
Zahacz Zyxel Device Zyxel Device o szynę montażową DIN.
Dociśnij Zyxel Device w dół i przykręć szynę montażową DIN do Zyxel Device.

Odstraňte 2 šrouby na Zyxel Device a připevněte držák DIN lišty na Zyxel Device.
Zavěste Zyxel Device Zyxel Device na DIN lištu.
Zatlačte Zyxel Device dolů a připevněte DIN lištu na Zyxel Device.

Távolítsa el a 2 csavart a Zyxel Device készüléken, majd csavarozza a DIN-sín tartókonzolt a Zyxel Device készülékre.
Akassza a Zyxel Device Zyxel Device készüléket a DIN-sínre.
Nyomja le a Zyxel Device készüléket, majd csavarozza a DIN-sínt a Zyxel Device készülékre.

Retirați cele 2 șuruburi de pe Zyxel Device și înșurubați suportul de montare DIN-Rail pe Zyxel Device.
Agățați Zyxel Device Zyxel Device de șina DIN.
Împingeți Zyxel Device în jos și înșurubați șina DIN pe Zyxel Device.

Извлеките 2 винта на Zyxel Device и прикрутите кронштейн DIN-рейки к Zyxel Device.
Зацепите Zyxel Device Zyxel Device за DIN-рейку.
Надавите Zyxel Device вниз и прикрутите DIN-рейку к Zyxel Device.

Odstranite 2 vijaka na Zyxel Device in privijte nosilec za montažo na DIN letev na Zyxel Device.
Obesite Zyxel Device Zyxel Device na DIN letev.
Potisnite Zyxel Device navzdol in privijte DIN letev na Zyxel Device.

Odstráňte 2 skrutky na Zyxel Device a naskrutkujte držiak DIN lišty na Zyxel Device.
Zaveste Zyxel Device Zyxel Device na DIN lištu.
Zatlačte Zyxel Device nadol a naskrutkujte DIN lištu na Zyxel Device.

Zyxel Device Zyxel Device üzerindeki 2 vidayı çıkarın ve DIN-raylı montaj aparatını Zyxel Device üzerine vidalayın.
Zyxel Device Zyxel Device'ı DIN rayına takın.
Zyxel Device'ı aşağı doğru bastırın ve DIN rayını Zyxel Device üzerine vidalayın.

Видаліть 2 гвинти на Zyxel Device та прикрутіть кронштейн DIN-рейки до Zyxel Device.
Зачепіть Zyxel Device Zyxel Device за DIN-рейку.
Натисніть Zyxel Device вниз та прикрутіть DIN-рейку до Zyxel Device.

Usuń 2 wkręty na Zyxel Device i przykręć wspornik montażowy DIN do Zyxel Device.
Zaczep Zyxel Device Zyxel Device na szynie montażowej DIN.
Dociśnij Zyxel Device w dół i przykręć szynę montażową DIN do Zyxel Device.

Odstranite 2 vijaka na Zyxel Device in privijte nosilec za montažo na DIN letev na Zyxel Device.
Obesite Zyxel Device Zyxel Device na DIN letev.
Potisnite Zyxel Device navzdol in privijte DIN letev na Zyxel Device.

Odstráňte 2 skrutky na Zyxel Device a naskrutkujte držiak DIN lišty na Zyxel Device.
Zaveste Zyxel Device Zyxel Device na DIN lištu.
Zatlačte Zyxel Device nadol a naskrutkujte DIN lištu na Zyxel Device.

Zyxel Device Zyxel Device üzerindeki 2 vidayı çıkarın ve DIN-raylı montaj aparatını Zyxel Device üzerine vidalayın.
Zyxel Device Zyxel Device'ı DIN rayına takın.
Zyxel Device'ı aşağı doğru bastırın ve DIN rayını Zyxel Device üzerine vidalayın.

Видаліть 2 гвинти на Zyxel Device та прикрутіть кронштейн DIN-рейки до Zyxel Device.
Зачепіть Zyxel Device Zyxel Device за DIN-рейку.
Натисніть Zyxel Device вниз та прикрутіть DIN-рейку до Zyxel Device.

Usuń 2 wkręty na Zyxel Device i przykręć wspornik montażowy DIN do Zyxel Device.
Zaczep Zyxel Device Zyxel Device na szynie montażowej DIN.
Dociśnij Zyxel Device w dół i przykręć szynę montażową DIN do Zyxel Device.

Management Options

Nebula Management with the App

Use the Zyxel Nebula Mobile app to register the Zyxel Device and set up initial settings. Download the app from the Apple App Store or Google Play.

Where to find the QR code:

Web Configurator or Label on the device

Download and open the Zyxel Nebula Mobile app. Log in with your Zyxel account.
Create an organization and site or select an existing site. Scan the QR code on the Zyxel Device or enter its MAC address and SN. Add the Zyxel Device to the site and power it on.
Follow the on-screen wizard to configure basic settings for the Zyxel Device.

Laden Sie die Zyxel Nebula Mobile App herunter und öffnen Sie sie. Melden Sie sich mit Ihrem Zyxel-Konto an.
Erstellen Sie eine Organisation und einen Standort oder wählen Sie einen bestehenden Standort. Scannen Sie den QR-Code auf dem Zyxel Device oder geben Sie dessen MAC-Adresse und SN ein. Fügen Sie das Zyxel Device dem Standort hinzu und schalten Sie es ein.
Befolgen Sie den Assistenten auf dem Bildschirm, um die Grundeinstellungen für das Zyxel Device zu konfigurieren.

Descargue y abra la aplicación móvil Zyxel Nebula. Inicie sesión con su cuenta Zyxel.
Cree una organización y un sitio o seleccione un sitio existente. Escanee el código QR del Zyxel Device o introduzca su dirección MAC y SN. Añada el Zyxel Device al sitio y enciéndalo.
Siga el asistente en pantalla para configurar los ajustes básicos del Zyxel Device.

Scaricare e aprire la app Nebula Mobile. Accedere con l'account Zyxel.
Creare un'organizzazione e un sito oppure selezionare un sito esistente. Passare alla scheda Siti di Zyxel Device per scansionare il codice QR sul Zyxel Device o inserire il relativo indirizzo MAC e SN. Aggiungere il Zyxel Device al sito e accenderlo.
Seguire la procedura guidata sullo schermo per configurare le impostazioni di base per il Zyxel Device.

Laad de Zyxel Nebula Mobile app van Apple App Store of Google Play. Log in met uw Zyxel account.
Maak een organisatie en site aan of selecteer een bestaande site. Scan de QR code op het Zyxel Device of voer het MAC adres en SN in. Voeg het Zyxel Device toe aan de site en zet het aan.
Volg de wizard op het scherm om de basisinstellingen voor het Zyxel Device te configureren.

Descarregue e abra a aplicação móvel Zyxel Nebula. Inicie sessão com a sua conta Zyxel.
Crie uma organização e um site ou selecione um site existente. Digitalize o código QR no Zyxel Device ou introduza o endereço MAC e o SN. Adicione o Zyxel Device ao site e ligue-o.
Siga o assistente no ecrã para configurar as definições básicas do Zyxel Device.

Pobierz i otwórz aplikację mobilną Zyxel Nebula. Zaloguj się na swoje konto Zyxel.
Utwórz organizację i witrynę lub wybierz istniejącą witrynę. Zeskanuj kod QR na urządzeniu Zyxel Device lub wprowadź jego adres MAC i numer seryjny. Dodaj urządzenie Zyxel Device do witryny i włącz je.
Postępuj zgodnie z instrukcjami kreatora wyświetlanymi na ekranie, aby skonfigurować podstawowe ustawienia urządzenia Zyxel Device.

Stáhněte a otevřete aplikaci Zyxel Nebula Mobile. Přihlaste se pomocí účtu Zyxel.
Vytvořte organizaci a web nebo vyberte existující web. Naskenujte QR kód na zařízení Zyxel Device nebo zadejte jeho adresu MAC a sériové číslo. Přidejte zařízení Zyxel Device na web a zapněte ho.
Podle pokynů na obrazovce nakonfigurujte základní nastavení zařízení Zyxel Device.

Töltse le és nyissa meg a Zyxel Nebula Mobile alkalmazást. Jelentkezzen be Zyxel-fiókjával.
Hozzon létre egy szervezetet és egy munkaterületet, vagy válasszon ki egy meglévőt. Szkennelje be a QR-kódot a Zyxel Device készüléken, vagy adja meg annak MAC-címét és sorozatszámát. Adja hozzá a Zyxel Device készüléket a munkaterülethez, majd kapcsolja be.
Kövesse a képernyőn megjelenő varázslót a Zyxel Device készülék alapbeállításainak konfigurálásához.

Descărcați și deschideți aplicația mobilă Zyxel Nebula. Conectați-vă cu contul Zyxel.
Creați o organizație și un amplasament sau selectați un amplasament existent. Scanați codul QR de pe Zyxel Device sau introduceți adresa MAC și SN. Adăugați Zyxel Device la amplasament și porniți-l.
Urmați expertul de pe ecran pentru a configura setările de bază pentru Zyxel Device.

Загрузите и откройте мобильное приложение Zyxel Nebula. Войдите в свою учетную запись Zyxel.
Создайте организацию и сайт или выберите существующий сайт. Отсканируйте QR-код на Zyxel Device, чтобы добавить его на сайт, или введите его MAC-адрес и серийный номер. Включите Zyxel Device.
Следуйте инструкциям мастера настройки на экране, чтобы настроить основные параметры Zyxel Device.

Prenesite in odprite mobilno aplikacijo Zyxel Nebula. Prijavite se s svojim računom Zyxel.
Ustvarite organizacijo in spletno mesto ali izberite obstoječe spletno mesto. Skenirajte kodo QR na napravi Zyxel Device ali vnesite njen naslov MAC in serijsko številko. Napravo Zyxel Device dodajte na spletno mesto in jo vklopite.
Sledite čarovniku na zaslonu, da konfigurirate osnovne nastavitve naprave Zyxel Device.

Stiahnite a otvorte mobilnú aplikáciu Zyxel Nebula. Prihláste sa pomocou svojho účtu Zyxel.
Vytvorte organizáciu a lokalitu alebo vyberte existujúcu lokalitu. Naskenujte QR kód na zariadení Zyxel Device alebo zadajte jeho adresu MAC a sériové číslo. Pridajte zariadenie Zyxel Device do lokality a zapnite ho.
Podľa pokynov sprievodcu na obrazovke nakonfigurujte základné nastavenia zariadenia Zyxel Device.

Töltse le és nyissa meg a Zyxel Nebula Mobile alkalmazást. Jelentkezzen be Zyxel-fiókjával.
Hozzon létre egy szervezetet és egy webhelyet, vagy válasszon ki egy meglévő webhelyet. Szkennelje be a QR-kódot a Zyxel Device készüléken, vagy adja meg annak MAC-címét és sorozatszámát. Adja hozzá a Zyxel Device készüléket a webhelyhez, majd kapcsolja be.
Kövesse a képernyőn megjelenő varázslót a Zyxel Device készülék alapbeállításainak konfigurálásához.

Descărcați și deschideți aplicația mobilă Zyxel Nebula. Conectați-vă cu contul Zyxel.
Creați o organizație și un amplasament sau selectați un amplasament existent. Scanați codul QR de pe Zyxel Device sau introduceți adresa MAC și SN. Adăugați Zyxel Device la amplasament și porniți-l.
Urmați expertul de pe ecran pentru a configura setările de bază pentru Zyxel Device.

Загрузите и откройте мобильное приложение Zyxel Nebula. Войдите в свою учетную запись Zyxel.
Создайте организацию и сайт или выберите существующий сайт. Отсканируйте QR-код на Zyxel Device, чтобы добавить его на сайт, или введите его MAC-адрес и серийный номер. Включите Zyxel Device.
Следуйте инструкциям мастера настройки на экране, чтобы настроить основные параметры Zyxel Device.

Prenesite in odprite mobilno aplikacijo Zyxel Nebula. Prijavite se s svojim računom Zyxel.
Ustvarite organizacijo in spletno mesto ali izberite obstoječe spletno mesto. Skenirajte kodo QR na napravi Zyxel Device ali vnesite njen naslov MAC in serijsko številko. Napravo Zyxel Device dodajte na spletno mesto in jo vklopite.
Sledite čarovniku na zaslonu, da konfigurirate osnovne nastavitve naprave Zyxel Device.

Stiahnite a otvorte mobilnú aplikáciu Zyxel Nebula. Prihláste sa pomocou svojho účtu Zyxel.
Vytvorte organizáciu a lokalitu alebo vyberte existujúcu lokalitu. Naskenujte QR kód na zariadení Zyxel Device alebo zadajte jeho adresu MAC a sériové číslo. Pridajte zariadenie Zyxel Device do lokality a zapnite ho.
Podľa pokynov sprievodcu na obrazovke nakonfigurujte základné nastavenia zariadenia Zyxel Device.

Zyxel Device Zyxel Device'ınızı indirin ve açın. Zyxel hesabınızla oturum açın.
Bir kuruluş ve site oluşturun veya mevcut bir siteyi seçin. Zyxel Device üzerindeki QR kodunu tarayın veya MAC adresini ve SN'yi girin. Zyxel Device'ı siteye ekleyin ve açın.
Zyxel Device'ın temel ayarlarını yapılandırmak için ekrandaki sihirbazı izleyin.

Завантажте та відкрийте мобільний додаток Zyxel Nebula. Увійдіть у свій обліковий запис Zyxel.
Створіть організацію та сайт або виберіть існуючий сайт. Відскануйте QR-код на Zyxel Device або введіть його MAC-адресу та SN. Додайте Zyxel Device до сайту та ввімкніть його.
Дотримуйтеся вказівок майстра на екрані, щоб налаштувати основні параметри Zyxel Device.


Pobierz i otwórz aplikację mobilną Zyxel Nebula. Zaloguj się na swoje konto Zyxel.
Utwórz organizację i witrynę lub wybierz istniejącą witrynę. Zeskanuj kod QR na urządzeniu Zyxel Device lub wprowadź jego adres MAC i numer seryjny. Dodaj urządzenie Zyxel Device do witryny i włącz je.
Postępuj zgodnie z instrukcjami kreatora wyświetlanymi na ekranie, aby skonfigurować podstawowe ustawienia urządzenia Zyxel Device.

Stáhněte a otevřete aplikaci Zyxel Nebula Mobile. Přihlaste se pomocí účtu Zyxel.
Vytvořte organizaci a web nebo vyberte existující web. Naskenujte QR kód na zařízení Zyxel Device nebo zadejte jeho adresu MAC a sériové číslo. Přidejte zařízení Zyxel Device na web a zapněte ho.
Podle pokynů na obrazovce nakonfigurujte základní nastavení zařízení Zyxel Device.

Töltse le és nyissa meg a Zyxel Nebula Mobile alkalmazást. Jelentkezzen be Zyxel-fiókjával.
Hozzon létre egy szervezetet és egy munkaterületet, vagy válasszon ki egy meglévőt. Szkennelje be a QR-kódot a Zyxel Device készüléken, vagy adja meg annak MAC-címét és sorozatszámát. Adja hozzá a Zyxel Device készüléket a munkaterületh

Direct Management with the Web Configurator

Use the web configurator to directly manage the Zyxel Device.



1. Point a WAN enabled computer, search for the Zyxel Device's default WiFi network name (SSID), and connect. Make sure it is the two-band characters of the MAC address and not the five-band characters. Check the label on the bottom of the Zyxel Device for the default WiFi network name (SSID) and password (See the Zyxel Device label). Login

2. Open a web browser and enter the default IP address (192.168.1.1) in the browser's address bar. Enter the default user name (admin) and password (1234) and click Login. Change the default password. Click Login again.

3. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

4. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

5. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

6. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

7. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

8. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

9. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

10. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

11. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

12. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

13. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

14. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

15. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

16. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

17. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

18. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

19. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

20. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

21. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

22. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

23. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

24. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

25. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

26. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

27. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

28. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

29. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

30. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

31. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

32. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

33. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

34. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

35. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

36. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

37. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

38. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

39. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

40. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

41. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

42. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

43. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

44. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

45. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

46. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

47. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

48. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

49. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

50. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

51. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

52. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

53. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

54. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

55. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

56. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

57. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

58. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

59. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

60. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

61. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

62. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

63. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

64. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

65. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

66. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

67. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

68. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

69. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

70. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

71. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

72. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

73. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

74. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

75. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

76. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

77. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

78. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

79. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

80. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

81. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

82. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

83. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

84. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

85. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

86. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

87. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

88. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

89. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

90. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

91. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

92. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

93. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

94. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

95. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

96. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

97. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

98. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

99. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

100. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

101. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

102. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

103. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

104. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

105. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

106. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

107. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

108. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

109. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

110. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

111. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

112. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

113. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

114. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

115. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

116. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

117. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

118. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

119. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

120. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

121. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

122. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

123. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

124. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

125. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

126. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

127. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

128. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

129. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

130. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

131. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

132. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

133. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

134. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

135. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

136. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

137. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

138. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

139. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

140. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

141. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

142. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

143. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

144. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

145. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

146. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

147. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

148. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

149. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

150. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

151. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

152. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

153. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

154. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

155. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

156. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

157. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

158. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

159. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

160. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

161. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

162. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

163. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

164. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

165. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

166. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

167. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

168. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

169. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

170. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

171. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

172. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

173. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

174. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

175. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

176. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

177. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

178. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

179. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

180. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

181. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

182. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

183. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

184. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

185. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

186. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

187. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

188. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

189. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

190. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

191. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

192. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

193. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

194. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

195. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

196. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

197. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

198. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

199. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

200. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

201. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

202. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

203. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

204. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

205. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

206. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

207. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

208. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

209. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

210. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

211. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

212. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

213. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

214. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

215. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

216. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

217. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

218. Click Configuration > Network > NAT. Configure NAT if you want to set up servers on your network. Click Apply.

219. Click Configuration > Network > Interface > Ethernet. Select the Ethernet interface (port) you want to configure. Select the Internet connection type (DHCP client, static IP address, or PPPoE) and configure the settings as directed by your ISP. Click Apply. Click Monitor > Network Status to check the Internet connection status.

220. Click Configuration > Network > Interface > Cellular. Configure the cellular Internet connection settings. Click Apply. Click Monitor > Network Status > Mobile Broadband to check the cellular Internet connection status.

221. Click Configuration > Network > DDNS. Configure DDNS if you want to use a static domain name with a dynamic WAN IP address. Click Apply.

222. Click Configuration > Network > NAT. Configure NAT