ZYXEL
NEBULA

NSG50/NSG50B

Unified Security Gateway Mobile Broadband Plus Nucleus Series

Quick Start Guide

NSG50 / NSG50 - NSG50U - NSG50B - NSG50B - NSG50BU
NSG50 - NSG50 - NSG50U - NSG50B - NSG50B - NSG50BU
NSG50 - NSG50 - NSG50U - NSG50B - NSG50B - NSG50BU

Contents

Hardware Connections

Part 1 – Nebula Device Management

Part 2 – Initial Setup (Standalone)

Section 1 Register your unit and activate your licenses

Section 2 Initial Setup (Standalone)

Part 3 – Initial Setup (Nebula)

Section 1 Nebula Initial Setup

Section 2 Nebula Initial Setup

Troubleshooting

Support Notes

Regulatory Information

Hardware Connections

Power Socket
Power Cord
Ethernet Cable
Internet Modem
Ethernet Cable
Ethernet Cable
Ethernet Cable

Wall Connector 墙连接器 **Wall Connector** 墙连接器 **Ceiling Connector** 吊顶连接器 **Ceiling Connector** 吊顶连接器 **Ceiling Connector** 吊顶