ZYXEL

NBA5561N

Dual-Band Wireless AC Media Gateway with Built-In Nexpeed Switch

Quick Start Guide

English • Deutsch • Español • Français • Italiano • Polski • Русский • Ukrainian • Türkçe • Čeština • Magyar • Slovenčina • Slovenščina • Hrvatski • Srpski • Bosanski • Eesti • Latviešu • Lietuvių • Română • Bulgarian • Ελληνικά • Português • Suomi • Norsk • Svenska • Dansk • Nederlands • Українська • العربية • Íslenska • Українська • Українська • Українська

Power Port Connect the power adapter to this port and power on the router.

Ethernet Port Connect your wired devices to these ports.

Power Indicator Solid green means the device is powered on. Flashing green means the device is starting up. Solid red means the device is in a fault state.

Reset Button Press and hold for about 5 seconds to restore the device to factory default settings.

Power Button Press to power on or off the device.

Ethernet Port Connect your wired devices to these ports.

Power Port Connect the power adapter to this port and power on the router.

Mounting Options

Wall / Ceiling Mounting

Mounting the device on the wall or ceiling. The device can be mounted on a wall or ceiling.

Wall mounting Drill holes for the screw and insert the screw into the wall. Hang the device on the screw.

Ceiling mounting Drill holes for the screw and insert the screw into the ceiling. Hang the device on the screw.

Wall mounting Mounting the device on the wall.

Ceiling mounting Mounting the device on the ceiling.