

Switch Series

Edition 2022.2

Handbook

Default Login Details	
LAN Port IP Address	https://192.168.1.1
User Name	admin
Password	1234

Copyright © 2017 ZyXEL Communications Corporation



Contents

Basic principles for network management	7
1.1 How to change the switch management IP address to avoid	
accessing the wrong device	7
1.1.1 Configuration in the Switch-2	8
1.1.2 Test the Result	
1.2 How to configure the switch with a device name to avoid access	ing
the wrong device	11
1.2.1 Configuration in Switch-1	. 12
1.2.2 Test the Result	. 13
1.3 How to configure the switch to update the time from an NTP serve	er14
1.3.1 Configuration in Switch	. 15
1.3.2 Test the Result	. 16
1.3.3 What could go wrong?	. 18
1.4 How to configure the switch to backup events on a SYSLOG serve	er19
1.4.1 Configure the Switch-1	. 20
1.4.2 Test the Result	
1.4.3 What could go wrong?	. 23
1.5 How to configure the switch with a port name to quickly identify	
directly connected devices	24
1.5.1 Configure Switch-1	. 25
1.5.2 Test the Result	. 26
1.6 How to collect the Diagnostic Info	27
1.6.1 Collect the Diagnostic Info from web GUI	. 28
1.6.2 Test the Result	. 29
1.7 How to change the default administrator password	30
1.7.1 Change the default administrator password	. 31
1.7.2 Test the Result	. 32
1.8 How to configure a whitelist for remote management to prevent	
unauthorized access	
1.8.1 Configure the whitelist of the remote management	
1.8.2 Test the Result	. 35
1.8.3 What could go wrong?	. 35
Designing the Local Area Network	37
2.1 How to configure the switch to separate traffic between	
departments using VLAN	
2.1.1 Configure Switch-1	
2.1.2 Configure Switch-2	
2.1.3 Test the Result	
2.2 How to configure the switch to route traffic across VLANs	
2.2.1 Configure VLAN 10	
2.2.2 Configure VLAN 20	. 47



2.2.3 Set the gateway on PC-1 and PC-2	49
2.2.4 Test the Result	51
2.2.5 What could go wrong	52
2.3 How to configure the switch to perform DHCP service in a VLAN.	53
2.3.1 Configure VLAN 10	54
2.3.2 Configure VLAN 20	
2.3.3 Configure the Switch and PC	58
2.3.4 Test the Result	
2.3.5 What Could Go Wrong	62
2.4 How to Configure the Switch to Translate Customer VLAN to Servi	
Provider VLAN	
2.4.1 Configuration on the Core Switch	
2.4.2 Configuration on the Edge Switch	
2.4.3 Test the Results	
Improving Network Reliability	
3.1 How to configure a stacked switch to ensure high server availab	
3.1.1 Configure Switch-1 and Switch-2 for Stacking	73
3.1.2 Configure Link Aggregation on Stacked switch	
3.1.3 Configure Link Aggregation on Switch-3	76
3.1.4 Test the Result	
3.1.5 What Could Go Wrong	78
3.2 How to configure RSTP in a ring topology	79
3.2.1 Configure Switch	
3.2.2 Test the Result	83
3.2.3 What Could Go Wrong	85
3.3 How to configure VRRP to provide hosts with a redundant gatewo	y
••••••	86
3.3.1 Configuration in the Gateway-A	87
3.3.2 Configuration in the Gateway-B	90
3.3.3 Test the Result	93
3.3.4 What Could Go Wrong?	95
3.4 How to configure bandwidth control to limit incoming or outgoing	g
traffic rate	96
3.4.1 Configure Switch	
3.4.2 Test the Result	
3.5 How to configure ACL to rate limit IP traffic	
3.5.1 Configure VLAN and Route Traffic	
3.5.2 Configure the Classifier	
3.5.3 Configure the ACL (Policy Rule)	103
3.5.4 Test the Result	
3.5.5 What Could Go Wrong	107



3.6 How to Implement VRRP with Multiple Routing Interface Combine	
with HA-pro Using Zyxel Enterprise Switch	
3.6.1 Configuration	
3.6.2 Verification	
3.6.3 What may go wrong?	127
3.7 How to Configure the Switch to Tunnel Layer 2 Protocol Packets	
Through Service Provider Network	128
3.7.1 Configuration on the Edge Switch	
3.7.2 Configuration on the Customer Switch	
3.7.3 Test the Results	
3.7.4 What Could Go Wrong	
Designing an IPTV Network	
4.1 Introduction for IGMP	
4.1.1 What are General Queries and Group Specific Queries?4.1.2 What are IGMP Snooping Querier Modes?	
4.1.2 What are the differences between IGMP Snoop	
fast/normal/immediate leave?	0
4.2 How to configure IGMP routing for multicast clients in a different l	
4.2.1 Configure Switch-1	
4.2.2 Configure Switch-2	
4.2.3 Test the Result	
4.2.4 What Could Go Wrong	145
4.3 How to configure IGMP Snooping for multicast clients in the same	è
LAN	
4.3.1 Configure Switch	
4.3.2 Test the Result	148
Network Security	
5.1 How to configure the port security to limit the number of connect	
devices	
5.1.1 Configure Switch-1	
5.1.2 Test the Result	
5.1.3 What Could Go Wrong	
5.2 How to configure MAC filter to block unwanted traffic	
5.2.1 Configure Switch-1	
5.2.2 Test the Result	
5.2.3 What Could Go Wrong	
5.3 How to configure the switch to prevent IP scanning 5.3.1 Configuration in the Switch	
5.3.2 Test the Result	
5.3.3 What Could Go Wrong?	162



5.4 How to Configure the Switch and RADIUS Server to Pre	ovide Network
Access through 802.1x Port Authentication	163
5.4.1 Configuration in the Switch	164
5.4.2 Configuration in the RADIUS-Server	
5.4.3 Test the Result	
5.4.4 What May Go Wrong?	
5.5 How to configure the switch to send unauthorized use	ers in a guest
VLAN	
5.5.1 Configure 802.1x Port Authentication on the Sw	
5.5.2 Configure VLAN for Guest VLAN	
5.5.3 Configure Guest VLAN for Failed Authenticatio	
5.5.4 Configure the RadiusServer	
5.5.5 Configure the setting on User-A, User-B and Gu	
5.5.6 Test the Result	
5.5.7 What Could Go Wrong	
5.6 How to Configure the Switch and RADIUS Server to Pro	
Access through Device MAC Address	
5.6.1 Configuration in the Switch	
5.6.2 Configuration in the RADIUS-Server	
5.6.3 Test the Result	
5.6.4 What Could Go Wrong?	
5.7 How to configure the switch to prevent ARP spoofing 5.7.1 Configuration in the Switch	
5.7.2 Test the Result	
5.7.3 What Could Go Wrong?	
5.8 How to Configure the Switch to Protect Against Rogu	
5.8.1 Configuration in the Switch	
5.8.2 Test the Result	
5.8.3 What Could Go Wrong?	
5.9 How to configure IPSG static binding for trusted netwo	
5.9.1 Configuration in the Switch	
5.9.2 Test the Result	
5.10 How to configure ACL to block unwanted traffic	
5.10.1 Configure VLAN and Route Traffic	
5.10.2 Configure the Classifier	
5.10.3 Configure the Policy Rule	
5.10.4 Test the Result	
5.10.5 What Could Go Wrong	
5.11 How to use ACL to mirror traffic of a specific criteria.	203
5.11.1 Configuration of ACL	
5.11.2 Test the Result	



5.11.3 What May Go Wrong	210
5.12 How to Separate Traffic through L2 Port Isolation	211
5.12.1 Configuration in the Switch	214
5.12.2 Test the Result	216
5.12.3 What May Go Wrong	218
Implementing VOIP	219
6.1 How to configure an IP Phone's VLAN using LLDP-MED	219
6.1.1 Configure VLAN for IP Phone	
6.1.2 Configure Switch	
6.1.3 Test the Result	223
6.1.4 What Could Go Wrong	224
6.2 How to configure the switch to separate VOIP traffic from data t	
- -	
6.2.1 Configure VLAN 100 for IP Phone	226
6.2.2 Configure Voice VLAN	
6.2.3 Test the Result	
6.2.4 What Could Go Wrong	229
6.3 How to configure the switch to improve Voice traffic quality	230
6.3.1 Configure VLAN for voice traffic	
6.3.2 Configure Voice VLAN	232
6.3.3 Configure Mirroring (For "Test the Result")	233
6.3.4 Test the Result	
6.3.5 What Could Go Wrong	
6.4 How to Configure Voice VLAN on Zyxel Switch	
6.4.1 Configuration	
6.4.2 Test the result	
6.4.3 What Could Go Wrong	242



Basic principles for network management

1.1 How to change the switch management IP address to avoid accessing the wrong device

This example shows administrators how to use the Web GUI to manage the IP addresses of the switches and avoid administrators from unintentionally accessing the wrong devices. As shown below, there are two switches in the environment. Both default IP addresses of the two switches are 192.168.1.1.




Figure 1 Two switches are using the same default IP address

`∲´ Note:



1.1.1 Configuration in the Switch-2

- 1 Disconnect the link between Switch-1 and Switch-2.
- 2 Set the PC's IP address on to the same subnet as the switches. For example, set the PC IP address as **192.168.1.100**.

Internet Protocol Version 4 (TCP/IPv4)	Properties ? X
General	
You can get IP settings assigned autor this capability. Otherwise, you need to for the appropriate IP settings.	
Obtain an IP address automatical	у
Ose the following IP address:	
IP address:	192.168.1.100
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	· · ·
Obtain DNS server address autom	natically
O Use the following DNS server add	resses:
Preferred DNS server:	
Alternate DNS server:	· · ·
Validate settings upon exit	Advanced
	OK Cancel

3 Open a browser (IE, Chrome, Safari, Firefox, etc....). Go to website http://192.168.1.1 (default management IP address). Key in "username: admin; password: 1234" and log in.

Authenticatior	n Required	×
http://192.168.1.1	requires a username and password.	
Your connection t	o this site is not private.	
User Name:		
Password:		
	Log In Cance	el



4 Enter the webpage and go to Menu > Basic Setting > IP Setup
> IP Configuration. Set the IP address you prefer, for example
192.168.1.2. Then click Add.

IP Interface			
IP Address	O DHCP C	lient	
	Static IP	Address	
		IP Address	192.168.1.2
		IP Subnet Mask	255.255.255.0
	VID	1	
		Add Cancel	

5 Log back in using the new IP address **192.168.1.2**. After logging in again, remember to click the **Save** icon to save the new configurations.

C Refresh 🛃 Save	e 🛈 Status	Pelp Help



1.1.2 Test the Result

 Log in via the web GUI and go to Menu > Basic Setting > IP Setup > IP Configuration. Check if the IP address is already configured as 192.168.1.2.

IP St	atus				ļ	P Configuration
Index	IP Address	IP Subnet Mask	VID	Туре	Renew	Release
1	192.168.1.2	255.255.255.0	1	Static		



1.2 How to configure the switch with a device name to avoid accessing the wrong device

This example shows administrators how to use the Web GUI to manage device name and avoid accessing the wrong devices. As shown below, the PC connects with Switch-1 in the environment. In the default setting, device name (System Name) will be the model name (XGS4600 in this example).




Figure 2 Change the device name of the switch

∛ Note:



1.2.1 Configuration in Switch-1

 Enter the web GUI and go to Menu > Basic Setting > General Setup. Change the System Name (Switch-1 in this example) and click Apply.

System Name	Switch-1	
Location		
Contact Person's Name		

2 Click "Save" to save the configuration.





1.2.2 Test the Result

Enter the web GUI and you will see the page of the switch information. Check if the **System Name** is the name you configured (**Switch-1** in this example) or not.

System into	
System Name	Switch-1
Product Model	XG\$4600-32



1.3 How to configure the switch to update the time from an NTP server

This example shows administrators how to use the NTP server to update the system time of the switch. As shown below, the PC connects with Switch and Switch connects with the USG in the environment.




Figure 3 Set up Switch to get time from NTP Server

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50). We use google free public NTP server (216.239.35.12) to be our NTP server. You can also choose another available NTP server. Furthermore, due to there is routing set up in this configuration, the user interface might be some difference for other models.



1.3.1 Configuration in Switch

 Enter the web GUI and go to Menu > Basic Setting > IP Setup
 IP Configuration. Set the default Gateway as USG IP: 192.168.1.1. Then click "Apply".

IP Configuration		<u>IP Status</u>
Default Gateway	192.168.1.1	
Default Management	● In-band ○ Out-of-band	
	Apply Cancel	

2 Go to Menu > Basic Setting > General Setup. Select "Use Time Server when Bootup" to NTP(RFC-1305) and set the "Time Server IP Address". In this scenario, we use the google free public NTP server (216.239.35.12) as an example. Also, select the "Time Zone" in your location. Finally, remember to click "Apply".

ime Server IP Address	216.3	216.239.35.12													
Current Time	00	: 3	4	:	29	U	C								
lew Time (hh:mm:ss)	00	: 3	4	:	29										
Current Date	2016		- 0	1	-	01									
lew Date (yyyy-mm-dd)	2016		- 0	1	-	01									
ime Zone	UTC	+0	800	, ,	1		_								
Daylight Saving Time				-	-										
itart Date	First		1		S	Jnd	ay	•	of	January	•	at	0:00	۳	
ind Date	First		,	,	S	Jnd	ay	٣	of	January	۲	at	0:00	۳	
vill take 60 seconds if time serv	er is uni	ea	ch	ab	le.										

3 Click **Save** to save the configuration.





1.3.2 Test the Result

1 Go to Menu > Basic Setting > General Setup. Both the Current Time and Current Date should be the current time in your location. If the current time is not updated as the correct time, click "Refresh".

Use Time Server when Bootup	NTP(RFC-1305) 🔻
Time Server IP Address	216.239.35.12
Current Time	14 : 18 : 44 UTC+08:00
New Time (hh:mm:ss)	14 : 18 : 44
Current Date	2017 - 06 - 20
New Date (yyyy-mm-dd)	2017 - 06 - 20
Time Zone	UTC+0800 V
Daylight Saving Time	
Start Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
End Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
It will take 60 seconds if time server	is unreachable.
	b one dendbler
	Apply Cancel
C Refresh	Save 🕜 Status 🕞 Logout 😰 Help

2 Try to select the "User Time Server when Bootup" as **None**. Few second later, change back to **NTP(RFC-1305)**. The time will still update to the current time.

Use Time Server when Bootup	None
Time Server IP Address	216.239.35.12
Current Time	14 : 18 : 45 UTC+08:00
New Time (hh:mm:ss)	14 : 18 : 45
Current Date	2017 - 06 - 20
New Date (yyyy-mm-dd)	2017 - 06 - 20
Time Zone	UTC+0800 V
Daylight Saving Time	
Start Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
End Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
t will take 60 seconds if time serve	er is unreachable.



Use Time Server when Bootup	NTP (RFC-1305)
Time Server IP Address	216.239.35.12
Current Time	14 : 19 : 18 UTC+08:00
New Time (hh:mm:ss)	14 : 19 : 18
Current Date	2017 - 06 - 20
New Date (yyyy-mm-dd)	2017 - 06 - 20
Time Zone	UTC+0800 V
Daylight Saving Time	
Start Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
End Date	First ▼ Sunday ▼ of January ▼ at 0:00 ▼
t will take 60 seconds if time serve	r is unreachable.
	Apply Cancel



1.3.3 What could go wrong?

 Switch may not be able to access the NTP Server successfully. Follow the step to test if NTP Server is available. Go to Menu > Management > Diagnostic. Select IPv4 as in-band and type the IP address of NTP Server (216.239.35.12) into the IP Address field. Click "Ping".

Diagnostic			
Resolving 216.239.35.12			
	avg mdev max mi 0 10 10 216.23		
	0 10 10 216.23		
	0 10 10 216.23		
	IPv4	in-band 🔻	
	○ IPv6	- T	
Ping Test	○ IPv6 IP Address/Host Name	- v 216.239.35.12	Ping
Ping Test			Ping
Ping Test	IP Address/Host Name		Ping



1.4 How to configure the switch to backup events on a SYSLOG server

The example shows administrators how to set up the switch to send system log events to a remote syslog server.



∛ Note:



1.4.1 Configure the Switch-1

1 Enter the web GUI and go to Menu > Management > Syslog Setup > Syslog Server Setup. Activate the syslog server setup and set up the server IP address. In this example, it is 192.168.1.200. Choose the Log Level you prefer (Level 0-7 in this example). The wider the range, the more detailed log will be recorded. Remember to click "Add".


Syslog Server Setup	
Active	
Server Address	192.168.1.200
UDP Port	514
Log Level	Level 0-7 🔻
	Add Cancel Clear
	ich events should be sent to the Syslog Server. (0), Alert (1), Critical (2), Error (3), Warning (4), Notice and Debug (7).

2 In the same page, activate the **Syslog** and activate the logging type you prefer. Also, remember to click "**Apply**".

iyslog	Active 🗹	
Logging type	Active	
System		local use 0 🔻
Interface		local use 0 🔻
Switch		local use 0 🔻
AAA		local use 0 🔻
IP		local use 0 🔻



3 Click **Save** to save the configuration.






1.4.2 Test the Result

- 1 Unplug and re-plug PC-1 from the switch.
- 2 The Syslog Server should receive an event log from the switch.

🏘 Tftpd64 by Ph. Jounin		
Current Directory C:\app\Tftpd64	•	Browse
Server interfaces 192.168.1.200 Realtek RTL8168C(P)/8111C(F	P) Family PCI-E 💌	Show Dir
Tftp Server Tftp Clien <mark>t Syslog server</mark> Log viewer		
text	from	date
<134> Jan 01 02:54:47 XGS4600 authentication: Console user admin login	192.168.1.1	12/06 18:21:53.786
<135> Jan 01 02:55:22 XGS4600 interface: Port 1 link down	192.168.1.1	12/06 18:22:29.097
<135> Jan 01 02:55:27 XGS4600 interface: Port 1 link up	192.168.1.1	12/06 18:22:33.498
Clear Copy		
About Settings		Help

3 We can also check the **directory** ("C:\app\Tftpd64" in this example) to find out if a text file is created on the Syslog Server.





1.4.3 What could go wrong?

- 1 If Switch-1 and Syslog Server are in different subnets, remember to set **default gateway** so that Switch-1 and the Syslog Server can communicate with each other.
- 2 Confirm the service port number of the Switch-1 and the Syslog Server are the same. (Default service port for the Syslog Server in the Switch-1 is **514**).

Syslog Server Setup	
Active	
Server Address	192.168.1.200
UDP Port	514
Log Level	Level 0-7 V
	Add Cancel Clear



1.5 How to configure the switch with a port name to quickly identify directly connected devices

The example shows administrators how to configure the switch with a port name to quickly identify directly connected devices. By doing this, administrators and quickly identify which port connects to which device, location, or section of the network.




Figure 5 Configure the port name of the switch

℃ Note:



1.5.1 Configure Switch-1

1 Enter the web GUI and go to Menu > Basic Setting > Port Setup. Type the name of each directly connected devices on the corresponding port name. For example, you can type Switch-2 in port 2 and AP in port 3. Then click "Apply".

	Port Set	up							
Port			Туре	Speed / Duplex	F	ow Control	802.1p Priority		Media Type
*			-	10G / Full Duplex	•		0 🔻	Peer •	sfp_plus ▼
1			10/100/1000M	Auto-1000M	•		0 🔻	Peer •	•
2		Switch-2	10/100/1000M	Auto-1000M	•		0 🔻	Peer •	
3		AP	10/100/1000M	Auto-1000M	•		0 •	Peer •	,

2 Click Save to save the configuration.





_

1.5.2 Test the Result

1 Go to **Menu > Maintenance > Port Status**. You will see the name you type in the column of name.

										Utilization
Port				LACP		RxPkts	Errors	Tx kB/s	Rx kB/s	Up Time
1		1000M/F	FORWARDING	Disabled	3180	7509	0	30.299	2.238	0:01:55
2	Switch-2	1000M/F	FORWARDING	Disabled	699	3636	0	0.168	0.0	0:00:12
3	AP	1000M/F	FORWARDING	Disabled	250	404	0	0.168	0.0	0:01:27
4		Down	STOP	Disabled	3140	756	0	0.0	0.0	0:00:00
5		Down	STOP	Disabled	0	0	0	0.0	0.0	0:00:00



1.6 How to collect the Diagnostic Info

The example shows local administrators how to collect the Diagnostic Info by web GUI. The Diagnostic Info is a set of logs that includes useful information such as System Information, CPU utilization history, system logs and debug reports for issue analysis.




Figure 6 Collect the Diagnostic Info from web GUI

∛ Note:



1.6.1 Collect the Diagnostic Info from web GUI

1 Enter the web GUI and go to Menu > Management > Maintenance > Tech-Support > <u>Click Here</u>. Click the Download button for All. You can also select the specific Diagnostic Info you need. (Ex: Crash, ROM,.....)

All	Download
Crash	Download
CPU history	Download
Memory section	Download
Mbuf	Download
ROM	Download
L3	Download



1.6.2 Test the Result

1 Open the file and you can view the Diagnostic Info. (In this example, we use the **Notepad++** to open the .txt file.)

-		_
File Ed	dit Search View Encoding Language Settings Tools Macro Run Plugins Window ?	×
6	🗄 🛍 💫 🖧 🍐 🎖 🛍 🛅 🤿 😋 📾 🍇 🔍 🔍 🖫 💁 11 🌉 🖉 🔊 🖉 🖾 🖉 🔍 🔍 🔍	
😑 techSı	npport_all log 🖸	
2		
3	Time : 8:38:24 ====== show system-information ========== msclock :31104300	
4		
5		
6	Product Model : XGS4600-32	
7	System Name : XGS4600	
8	System Mode : Standalone	
9	System Contact :	
	System Location :	
	System up Time : 8:38:24 (2f761e ticks)	
	Ethernet Address : 42:73:74:20:55:56	
13	Bootbase Version : V1.00 02/21/2016	
	ZyNOS F/W Version : V4.50(ABBH.0)b3 04/18/2017	
	Config Boot Image : 1	
	Current Boot Image : 1	
	Current Configuration : 1	
	RomRasSize : 8825622	
19		-
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
Normal	text file length:1,134,963 lines:10,036 Ln:1 Col:1 Sel:0 0 Unix (LF) UTF-8 IN	>



1.7 How to change the default administrator password

The example shows administrators how to change the default administrator password used for management access. Failure to change the default administrator password is a security risk that allows unauthorized user access to your device's management.




Figure 7 Change the default administrator password

∛ Note:



1.7.1 Change the default administrator password

 Enter the web GUI and go to Menu > Management > Access Control > Logins > <u>Click Here</u>. Enter the Old Password and New Password. Then click "Apply".

Logins		Access Contro
Administrator		
Old Password	••••	
New Password	••••	
Retype to confirm	••••	

2 After clicking the "**Apply**", the browser will show a message similar below.

Password Changed
Please close the browser before using the new password.



1.7.2 Test the Result

1 Close the web GUI and login again with the **OLD** password. The "Authentication Required" window will pop up again.

Authentication Required										
http://192.168.1.1 requires a username and password.										
Your connection to this site is not private.										
User Name:										
Password:	Password:									
	Log In Cancel									
		_								

2 Use the **new** password to login. Switch-1 web GUI should be accessible.



1.8 How to configure a whitelist for remote management to prevent unauthorized access

The example shows administrators how to configure a whitelist for host devices that prevents attempted access from unauthorized devices or subnets. The whitelist inspects the source IP addresses of hosts and the types of services accessing the switch (Ex: Telnet, FTP, HTTP.....).




Figure 8 Configure the whitelist for remote management

🏹 Note:



1.8.1 Configure the whitelist of the remote management

1 Enter the web GUI and go to Menu > Management > Access Control > Remote Management > <u>Click Here</u> using AdministratorPC. Enter the range of IP addresses and the corresponding types of services that are allowed to access the Switch. Then click "Apply".

Remole Management <u>Access Con</u> Secured Client Setup										<u>is Control</u>	
Entry	Active	Start Address		End Address	Telnet	FTP	HTTP	ICMP	SNMP	SSH	HTTPS
1		192.168.10.100		192.168.10.120		√			√		
2		192.168.1.100		192.168.1.100		√			√		
3		0.0.0.0		0.0.0.0							
4		0.0.0.0		0.0.0.0							
5		0.0.0.0		0.0.0.0							
6		0.0.0.0		0.0.0.0							
7		0.0.0.0		0.0.0.0							
8		0.0.0.0		0.0.0.0							
9		0.0.0.0		0.0.0.0							
10		0.0.0.0		0.0.0.0							
11		0.0.0.0		0.0.0.0							
12		0.0.0.0		0.0.0.0							
13		0.0.0.0		0.0.0.0							
14		0.0.0.0		0.0.0							
15		0.0.0.0		0.0.0							
16		0.0.0.0		0.0.0							
				Apply C	Cancel						



1.8.2 Test the Result

1 In the setting, we set the IP range: 192.168.10.100-192.168.10.120, which is allowed to access the Switch by all protocol types, EXCEPT HTTP. Therefore, if we use PC-1 (192.168.10.100) to access the Switch by HTTP, the Switch will refuse the connection. If we try to access the web GUI by HTTPS (Enter the https://192.168.10.1), PC-1 can connect to the Switch successfully.



2 The PC-2 (192.168.10.200) is not in the range which is allowed to access the Switch. PC-2 cannot access or ping the switch's management IP address.



3 AdministratorPC can access the Switch by **all** service types successfully.

1.8.3 What could go wrong?

1 The IP address is setting up repeatedly, but the setting is different. The logic rule of whitelist is **OR**.



For example, if we set the range of the IP addresses shown below. **192.168.10.120** is repeatedly set up accidently. The result is that all types of services are **ALLOWED** for **192.168.10.120**.

	lemote Ma Client Setu	inagement IP								Acces	<u>is Control</u>
Entry	Active	Start Address		End Address	Telnet	FTP	HTTP	ICMP	SNMP	SSH	HTTPS
1		192.168.10.100		192.168.10.120							
2	1	192.168.10.120		192.168.10.120			-				
3		0.0.0.0]	0.0.0.0							
4		0.0.0]	0.0.0							

2 If the administrator has forgotten or lost track of the whitelisted IP addresses, the administrator will not be able to access the Switch. To solve this problem, use **Console** to verify the settings. Administrators can find out which IP addresses are allowed to access the Switch by reviewing the running configurations.



Vote:

If the Switch **does not support Console**, please check the manual of your Switch model to find out how to restore device to factory default settings.



Designing the Local Area Network

2.1 How to configure the switch to separate traffic between departments using VLAN

The example shows administrators how to set up the switch to make separate traffic between departments. Using **Static VLAN**, hosts accessing the same VLAN will only be able to communicate with hosts accessing the same VLAN.




Figure 9 Set up VLAN to separate the traffic between departments

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XG\$4600-32 (Firmware Version: V4.50).



2.1.1 Configure Switch-1

1 Use AdministratorPC to set VLAN 1 in Switch-1: Port 1, 2 as Normal port. (Prevent VLAN 1 broadcast packets to port 1, 2). Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup > VID > 1. Select port 1, 2 as Normal. Click "Add".

Static VLAN						VLAN Configuration
ACTIVE						
Name			1			
VLAN Group ID			1			
VLAN Type			NormalPrivate		•	
Association VLAN List						
Port		c	Control			Tagging
•		Nor	mal 🔻			🗹 Tx Tagging
1	Normal	🔍 Fixe	ed	Forbide	den	Tx Tagging
2	Normal	🔍 Fixe	ed	Forbide	den	Tx Tagging
3	Normal	Fixe	ed	Forbide	den	Tx Tagging
4	Normal	Fixe	ed	Forbide	den	Tx Tagging
5	Normal	Fixe	ed	Forbide	den	Tx Tagging

2 Use AdministratorPC to create VLAN 10 in Switch-1: Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the "ACTIVE" box. Type the Name and VLAN Group ID=10. Select port 1, 5 as Fixed and uncheck Tx Tagging (Untagged) on port 1 and check Tx Tagging (Tagged) on port 5. Click "Apply".



Static VLAN				VLAN Configuration
ACTIVE		v		
Name		VLAN	10	
VLAN Group ID		10		
VLAN Type		 No Pri 		
Association VLAN List				
Port		Control		Tagging
•		Normal	T	🗹 Tx Tagging
1	Normal	Fixed	Forbidden	Tx Tagging
2	Normal	Fixed	Forbidden	🗹 Tx Tagging
3	Normal	Fixed	Forbidden	🗹 Tx Tagging
4	Normal	Fixed	Forbidden	🗹 Tx Tagging
5	Normal	Fixed	Forbidden	🗹 Tx Tagging

3 Use AdministratorPC to create VLAN 20 in Switch-1: Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the "ACTIVE" box. Type the Name and VLAN Group ID=20. Select port 2, 5 as Fixed and uncheck Tx Tagging (Untagged) on port 2 and check Tx Tagging (tagged) on port 5. Click "Apply".

Static VLAN					VLAN Configuration
ACTIVE		V)		
Name		V	LAN20		
VLAN Group ID		20)		
VLAN Type) Normal) Private	v	
Association VLAN List					
Port		Col	ntrol		Tagging
•		Norma	al 🔻		Ix Tagging
1	Normal	Fixed	Forbid	den	🗹 Tx Tagging
2	Normal	Fixed	Forbid	den	Tx Tagging
3	Normal	Fixed	Forbid	den	🗹 Tx Tagging
4	Normal	Fixed	🔍 Forbid	den	🗹 Tx Tagging
5	Normal	Fixed	Forbid	den	🗹 Tx Tagging

4 Set the PVID on Switch-1: Go to Menu > Advanced Application
 > VLAN > VLAN Configuration > VLAN Port Setup. Set port 1 as
 PVID=10 (VLAN 10) and port 2 as PVID=20 (VLAN 20).



Port	Ingress Check	PVID	GVRP	Acceptable F	rame Type	VLAN Trunking	Isolation
•				All	•		
1		10		All	•		
2		20		All	•		
3		1		All	•		
4		1		All	٣		



2.1.2 Configure Switch-2

 Use AdministratorPC to set VLAN 1 in Switch-2: Port 3, 4 as Normal port (this prevents VLAN 1 from broadcasting packets to port 3, 4). Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup > VID > 1. Select port 3, 4 as Normal. Click "Add".

Static VLAN					VLAN Configuration
ACTIVE		v			
Name		1			
VLAN Group ID		1			
VLAN Type			lormal rivate	T	
Association VLAN List					
Port		Contro	əl		Tagging
•		Normal	•		🗹 Tx Tagging
1	Normal	Fixed	Forbide	den	Tx Tagging
2	Normal	Fixed	Forbide	den	Tx Tagging
3	Normal	Fixed	Forbide	den	Tx Tagging
4	Normal	Fixed	Forbide	den	Tx Tagging
5	Normal	Fixed	Forbid	den	Tx Tagging

2 Use AdministratorPC to create VLAN 10 in Switch-2. Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the "ACTIVE" box. Type the Name and VLAN Group ID=10. Select port 3, 5 as Fixed and uncheck Tx Tagging (Untagged) on port 3 and check Tx Tagging (tagged) on port 5. Click "Apply".

Static VLAN				VLAN Configuration
ACTIVE				
Name		VLAN10)	
VLAN Group ID		10		
VLAN Type		 Norr Privo 		
Association VLAN Li	st			
Port		Control		Tagging
•		Normal	•	🗹 Tx Tagging
1	Normal	Fixed	Forbidden	Tx Tagging
2	Normal	Fixed	Forbidden	Tx Tagging
3	Normal	Fixed	Forbidden	Tx Tagging
4	Normal	Fixed	Forbidden	🗹 Tx Tagging
5	Normal	Fixed	Forbidden	🗹 Tx Tagging

3 Use AdministratorPC to create VLAN 20 in Switch-2. Enter the web GUI and go to Menu > Advanced Application > VLAN >



VLAN Configuration > Static VLAN Setup. Check the "ACTIVE" box. Type the Name and VLAN Group ID=20. Select port 4, 5 as Fixed and uncheck Tx Tagging (Untagged) on port 4 and check Tx Tagging (tagged) on port 5. Click "Apply".

Static VLAN				VLAN Configuration
ACTIVE		Ø		
Name		VLAN	120	
VLAN Group ID		20		
VLAN Type			ormal ivate 🔹	
Association VLAN List				
Port		Contro		Tagging
•		Normal	v	🕑 Tx Tagging
1	Normal	Fixed	Forbidden	🕑 Tx Tagging
2	Normal	Fixed	Forbidden	Tx Tagging
3	Normal	Fixed	Forbidden	Tx Tagging
4	Normal	Fixed	Forbidden	Tx Tagging
5	Normal	Fixed	Forbidden	🗹 Tx Tagging

4 Set the PVID on Switch-2: Go to Menu > Advanced Application
 > VLAN > VLAN Configuration > VLAN Port Setup. Set port 3 as
 PVID=10 (VLAN 10) and port 4 as PVID=20.

Port	Ingress Check	PVID	GVRP	Acceptable Frame Type	VLAN Trunking	Isolation
•				All		
1		1		All		
2		1		All		
3		10		All		
4		20		All		



2.1.3 Test the Result

1 The PC in the same VLAN can ping each other. PC-1 can ping PC-3 successfully, but PC-1 cannot ping PC-2.

C:\Users\User>ping 192.168.10.103 -t
Pinging 192.168.10.103 with 32 bytes of data:
Reply from 192.168.10.103: bytes=32 time<1ms TTL=128
Reply from 192.168.10.103: bytes=32 time<1ms TTL=128
Reply from 192.168.10.103: bytes=32 time<1ms TTL=128
C:\Users\User>ping 192.168.20.102
Pinging 192.168.20.102 with 32 bytes of data:
PING: transmit failed. General failure.

2 PC-2 can ping PC-4 successfully, but PC-2 cannot ping PC-3.



2.2 How to configure the switch to route traffic across VLANs

The purpose of VLANs are to isolate one broadcast domain from another. If we would like hosts from different VLANs to communicate with each other, we have to set the switch to route traffic. The example shows how to configure the switch to route traffic across one VLAN to another.




Figure 10 Set up switch to route traffic across VLANs

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).



2.2.1 Configure VLAN 10

1 Use AdministratorPC to create VLAN 10. Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the ACTIVE box. Type the Name and VLAN Group ID=10. Select port 1 as Fixed and uncheck Tx Tagging (Untagged). Click "Apply".

Static VLAN						VLAN Configuration
ACTIVE						
Name			VLAN10			
VLAN Group ID			10			
VLAN Type			NormalPrivate		•	
Association VLAN List						
Pori		c	Control			Tagging
•		Nor	mal 🔻			🗹 Tx Tagging
1	Normal	Fixe	ed	Forbid	lden	Tx Tagging
2	Normal	Fixe	ed	Forbid	lden	🗹 Tx Tagging
3	Normal	🔍 Fixe	ed	Forbid	lden	🗹 Tx Tagging
4	Normal	🔍 Fixe	d	Forbid	lden	🗹 Tx Tagging
5	Normal	Fixe	ed	Forbid	lden	🗹 Tx Tagging

2 Go to Menu > Advanced Application > VLAN > VLAN Configuration > VLAN Port Setup. Set the PVID. Set port 1 as PVID=10 (VLAN 10). Click "Apply".

Port	ingress Check	PVID	GVRP	Acceptable I	irame Type	e VLAN Trunking	
•				All	•		
1		10		All	•		
2		20		All	T		
3		1		All	•		
4		1		All	•		

3 Create a Static IP Address for Switch in VLAN 10 (To be the gateway in VLAN 10): Go to Menu > Basic Setting > IP Setup > IP Configuration > IP Interface. Set the Static IP Address: 192.168.10.1 for Switch in VLAN 10. Click "Add".



IP Interface							
IP Address		lient					
	Static IP	Static IP Address					
		IP Address	192.168.10.1				
		IP Subnet Mask	255.255.255.0				
	VID	10					
Add Cancel							



2.2.2 Configure VLAN 20

 Create VLAN 20. Follow the same steps. Go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the ACTIVE box. Type the Name and VLAN Group ID=20. Select port 2 as Fixed and uncheck Tx Tagging (Untagged). Click "Apply".

Static VLAN				VLAN Configuration
ACTIVE				
Name		VLAN	120	
VLAN Group ID		20		
VLAN Type			lormal rivate	T
Association VLAN List				
Port		Confrc	si.	Tagging
•		Normal	Ŧ	🗹 Tx Tagging
1	Normal	Fixed	Forbidder	Tx Tagging
2	Normal	Fixed	Forbidder	Tx Tagging
3	Normal	Fixed	Forbidder	n 🕑 Tx Tagging
4	Normal	Fixed	Forbidder	n 🕑 Tx Tagging
5	Normal	Fixed	Forbidder	n 🕑 Tx Tagging

2 Go to Menu > Advanced Application > VLAN > VLAN Configuration > VLAN Port Setup. Set the PVID. Set port 2 as PVID=20 (VLAN 20). Click "Apply".

Port	ingress Check	PVID	GVRP	Acceptable Frame Type	e VLAN Trunking	
•				All 🔻		
1		10		All 🔻		
2		20		All 🔻		
3		1		All 🔻		
4		1		All 🔻		

3 Create a Static IP Address for Switch in VLAN 20 (To be the gateway in VLAN 20). Go to Menu > Basic Setting > IP Setup > IP Configuration > IP Interface. Set a Static IP Address: 192.168.20.1 for Switch in VLAN 20. Click "Add".



_

IP Interface							
IP Address	DHCP Client Static IP Addre	255					
		IP Address	192.168.20.1				
		IP Subnet Mask	255.255.255.0				
	VID	20					
Add Cancel							



2.2.3 Set the gateway on PC-1 and PC-2

1 Set the Gateway of **PC-1** as **192.168.10.1** (The Static IP Address of Switch in **VLAN 10**).

Internet Protocol Version 4 (TCP/IPv4) Properties							
General							
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.							
Obtain an IP address automatical	ly						
• Use the following IP address:							
IP address:	192 . 168 . 10 . 100						
S <u>u</u> bnet mask:	255.255.255.0						
Default gateway:	192.168.10.1						
Obtain DNS server address auton	natically						
• Use the following DNS server add	resses:						
Preferred DNS server:							
Alternate DNS server:							
Validate settings upon exit Advanced							
	OK Cancel						

2 Set the Gateway of PC-2 as 192.168.20.1 (The Static IP Address of Switch in VLAN 20).



Internet Protocol Version 4 (TCP/IPv4) Properties								
General								
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.								
Obtain an IP address automaticall	у							
• Use the following IP address:								
IP address:	192 . 168 . 20 . 100							
Subnet mask:	255 . 255 . 255 . 0							
Default gateway:	192.168.20.1							
Obtain DNS server address autom	natically							
• Use the following DNS server add	resses:							
Preferred DNS server:								
Alternate DNS server:	•••							
Validate settings upon exit Advanced								
	OK Cancel							



2.2.4 Test the Result

PC-1 can ping PC-2 successfully.
 C:\Users\User>ping 192.168.20.100

Pinging 192.168.20.100 with 32 bytes of data: Reply from 192.168.20.100: bytes=32 time<1ms TTL=128 Ping statistics for 192.168.20.100: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 0ms, Maximum = 0ms, Average = 0ms



2.2.5 What could go wrong

- 1 If PC-1 cannot reach PC-2:
 - a. Verify that the subnet of PC-1 is not using the same subnet as that of PC-2.
 - b. Verify that the default gateways of PC-1 and PC-2 matches the Switch's IP interface on their respective VLANs.
 - c. Make sure that there are no policy routes using the subnet of PC-1 or PC-2 as a destination IP criteria.



2.3 How to configure the switch to perform DHCP service in a VLAN

The example shows administrators how to configure the switch to provide dynamic IP addresses to hosts in each VLANs.




Figure 11 Perform DHCP service in different VLAN



All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).

Only L3 Switch supports the function of DHCP Server. (The models: 3700 series, 4500 series and 4600 series)



2.3.1 Configure VLAN 10

1 Use AdministratorPC to create VLAN 10. Enter the web GUI and go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the ACTIVE box. Type the Name and VLAN Group ID=10. Select port 1 as Fixed and uncheck Tx Tagging (Untagged). Click "Apply".

Static VLAN					VLAN Configuration
ACTIVE					
Name		VLA	N10		
VLAN Group ID		10			
VLAN Type			Normal Private	¥	
Association VLAN List					
Port		Conh			Tagging
•		Normal	•		🗹 Tx Tagging
1	Normal	Fixed	Forbic	dden	Tx Tagging
2	Normal	Fixed	Forbic	dden	🗹 Tx Tagging
3	Normal	Fixed	Forbic	den	🗹 Tx Tagging
4	Normal	Fixed	Forbic	dden	🗹 Tx Tagging
5	Normal	Fixed	Forbic	dden	🗹 Tx Tagging

2 Go to Menu > Advanced Application > VLAN > VLAN Configuration > VLAN Port Setup. Set the PVID. Set port 1 as PVID=10 (VLAN 10). Click "Apply".

Port	ingress Check	PVID	GVRP	Acceptable I	irame Type	e VLAN Trunking	
•				All	•		
1		10		All	•		
2		20		All	T		
3		1		All	•		
4		1		All	•		

3 Create a Static IP Address for Switch in VLAN 10 (IP Address to be DHCP Server in VLAN 10): Go to Menu > Basic Setting > IP Setup > IP Configuration > IP Interface. Set the Static IP Address: 192.168.10.1 for Switch in VLAN 10. Click "Add".



IP Interface							
IP Address		lient					
	Static IP	Static IP Address					
		IP Address	192.168.10.1				
		IP Subnet Mask	255.255.255.0				
	VID	10					
Add Cancel							



2.3.2 Configure VLAN 20

 Create VLAN 20. Follow the same steps. Go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the ACTIVE box. Type the Name and VLAN Group ID=20. Select port 2 as Fixed and uncheck Tx Tagging (Untagged). Click "Apply".

Static VLAN				VLAN Configuration
ACTIVE				
Name		VLAN	120	
VLAN Group ID		20		
VLAN Type			lormal rivate	T
Association VLAN List				
Port		Confrc	si.	Tagging
•		Normal	Ŧ	🗹 Tx Tagging
1	Normal	Fixed	Forbidder	Tx Tagging
2	Normal	Fixed	Forbidder	Tx Tagging
3	Normal	Fixed	Forbidder	n 🗹 Tx Tagging
4	Normal	Fixed	Forbidder	n 🕑 Tx Tagging
5	Normal	Fixed	Forbidder	n 🕑 Tx Tagging

2 Go to Menu > Advanced Application > VLAN > VLAN Configuration > VLAN Port Setup. Set the PVID. Set port 2 as PVID=20 (VLAN 20). Click "Apply".

Port	ingress Check	PVID	GVRP	Acceptable Fro	ime Type	VLAN Trunking	
•				All	•		
1		10		All	•		
2		20		All	•		
3		1		All	•		
4		1		All	•		

3 Create Static IP Address for Switch in VLAN 20 (IP Address to be DHCP Server in VLAN 20): Go to Menu > Basic Setting > IP Setup > IP Configuration > IP Interface. Set the Static IP Address: 192.168.20.1 for Switch in VLAN 20. Click "Add".



_

IP Interface							
IP Address	 DHCP Client Static IP Add 						
		IP Address IP Subnet Mask	192.168.20.1 255.255.255.0				
	VID	20					
Add Cancel							



2.3.3 Configure the Switch and PC

Set up DHCP Server in VLAN 10: Go to Menu > IP Application > DHCP > DHCPv4 > Click Here > VLAN. Set up the VID (VLAN of PC-1) and DHCP Status as Server. The Client IP Pool Starting Address refers to the first IP Address the Switch will assign to DHCP clients. The Size of Client IP Pool refers to the maximum number of IP addresses the switch will provide. Set the gateway as the IP of the Switch in VLAN 10 (192.168.10.1). Click "Add".

VLAN Setting	<u>Status</u> <u>Port</u>
VID	10
DUCD 21 1	Server
DHCP Status	Relay
Server	
Client IP Pool Starting Address	192.168.10.11
Size of Client IP Pool	10
IP Subnet Mask	255.255.255.0
Default Gateway	192.168.10.1
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Lease Time	Infinite
Ledse lime	Days Hours 00 🔻 Minutes 00 🔻
Relay	
Remote DHCP Server 1	0.0.0.0
Remote DHCP Server 2	0.0.0.0
Remote DHCP Server 3	0.0.0.0
Source Address	0.0.0.0
Option 82 Profile	T
Add Ca	ncel Clear
	I the starting IP address is 192.168.10.11. DHCP Server will assign is between

2 Set up DHCP Server in VLAN 20: Go to Menu > IP Application > DHCP > DHCPv4 > Click Here > VLAN. Set up the VID (VLAN of PC-2) and DHCP Status as Server. The Client IP Pool Starting



Address refers to the first IP Address the Switch will assign to DHCP clients. The Size of Client IP Pool refers to the maximum number of IP addresses the switch will provide. Set the gateway as the IP of the Switch in VLAN 20 (**192.168.20.1**). Click "Add". Click "Add".

VLAN Setting	<u>Status</u> Port
VID	20
DHCP Status	Server
DHCF SIGIOS	O Relay
Server	
Client IP Pool Starting Address	192.168.20.11
Size of Client IP Pool	10
IP Subnet Mask	255.255.255.0
Default Gateway	192.168.20.1
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Lease Time	Infinite
Lease time	Days Hours 00 V Minutes 00 V
Relay	
Remote DHCP Server 1	0.0.0.0
Remote DHCP Server 2	0.0.0.0
Remote DHCP Server 3	0.0.0.0
Source Address	0.0.0.0
Option 82 Profile	T
Add Ca	ncel Clear
	the starting IP address is 192.168.20.11. DHCP Server will assign is between

3 Set PC-1 and PC-2 as DHCP clients by configuring IPv4 to "**Obtain an IP Address automatically**".



Internet Protocol Version 4 (TCP/IPv4) Properties	? ×
General Alternate Configuration	
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.	
• Obtain an IP address automatically	
C Use the following IP address:	- 1
IP address:	
Sybnet mask:	
Default gateway:	
Obtain DNS server address automatically	
C Use the following DNS server addresses:	- 1
Preferred DNS server:	
<u>A</u> lternate DNS server:	
Validate settings upon exit Advanced	
OK Canc	el




2.3.4 Test the Result

 PC-1 can get the IP Address assigned by Switch successfully. We can check this by using the command "ipconfig" in command prompt. PC-1 will get an IP address in the range of: 192.168.10.11-192.168.10.20 and the aateway is 192.168.10.1.

Administrator: C:\Windows\system	
C:\Users\User>ipconfig	
Windows IP Configuration	
Ethernet adapter Bluetoot	Network Connection:
Media State Connection-specific DN	: Media disconnected S Suffix . :
Ethernet adapter Local Ar	ea Connection:
Subnet Mask	Suffix : 192.168.10.11 : 255.255.0 : 192.168.10.1

2 PC-2 can get the IP Address assigned by Switch successfully. We can check this by using the command "ipconfig" in command prompt. PC-2 will get an IP address in the range of: 192.168.20.11-192.168.20.20 and the gateway is 192.168.20.1.





2.3.5 What Could Go Wrong

- 1 If some devices are no longer receiving any dynamic IP address from the DHCP server, consider increasing the Size of Client Pool.
- 2 If you want to surf the Internet using a URL or domain name, please remember to set up **DNS Server**.


VLAN Setting	<u>Status</u> Port
VID	20
DHCP Status	Server Relay
Server	- Keidy
Client IP Pool Starting Address	192.168.20.11
Size of Client IP Pool	20
IP Subnet Mask	255.255.255.0
Default Gateway	192.168.20.1
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Lease Time	 Infinite Days Hours Hours Minutes Minutes
Relay	
Remote DHCP Server 1	0.0.0.0
Remote DHCP Server 2	0.0.0.0
Remote DHCP Server 3	0.0.0.0
Source Address	0.0.0.0
Option 82 Profile	T
Add	Cancel Clear




2.4 How to Configure the Switch to Translate Customer VLAN to Service Provider VLAN

VLAN Mapping provides a mechanism to map a Customer VLAN to a service provider's VLAN (Translated-VLAN). Packets received on a port will map to a Translated VLAN based on a port ID and customer VLAN ID from packets.

VLAN Mapping also can be used to prevent traffic from forwarding between different customers when they use the same VLAN in their own networks. In the following example, both of company A and company B use the same VLAN 10. When company A sends traffic to an ISP network, the traffic is possible to be forwarded to company B across a core switch because both of the companies are in the same VLAN 10.




Once VLAN Mapping is configured on edge switches, it can translate customer VLANs of company A and company B to different VLANs respectively. Thus, the traffic will not be forwarded between company A and company B since they are in the different VLANs after processing VLAN translation on edge switches.





The following example will instruct how an administrator configures a switch to achieve VLAN translation.





2.4.1 Configuration on the Core Switch

- 1 Access to the web GUI, Go to Menu > Advanced Application
 - > VLAN Mapping. Check the Active box and activate port 1.

VLAN Mapping	VLAN Mapping Configure
Active	Ø
	A = 12
Port	Active
1	
2	
3	
4	
5	
2	-

2 Go to Menu > Advanced Application > VLAN Mapping > Configure. Check the Active box and type the Name. Set Port as 1, VID as 100, and Translated VID as 1001. Select Priority value as 3 (Optional), and click "Apply".

VLAN Mappir	ng Configure	VLAN Mapping
Active		
Name	c_VID100_P3	
Port	1	
VID	100	
Translated VID	1001	
Priority	3 •	
	de de	

Add Cancel

3 Go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the Active box, type the Name and VLAN Group ID= as 1001. Select port 1, 26 as Fixed, and click "Apply".



Static VLAN	VLAN Configure
ACTIVE	2
Name	VLAN 1001
VLAN Group ID	1001
VLAN Type	Normal Private
Association VLAN List	

Port		Control		Tagging
		Normal	T	🗷 Tx Tagging
1	Normal	Fixed	Forbidden	🗹 Tx Tagging
2	Normal	Fixed	Forbidden	🗹 Tx Tagging
3	Normal	Fixed	Forbidden	🗹 Tx Tagging
4	Normal	Fixed	Forbidden	🖉 Tx Tagging
5	Normal	Fixed	Forbidden	🖉 Tx Tagging
6	Normal	Fixed	Forbidden	🗹 Tx Tagging
7	Normal	Fixed	Forbidden	🖉 Tx Tagging
0.0255	~			-
23	Normal	Fixed	Forbidden	🗹 Tx Tagging
24	Normal	Fixed	Forbidden	🗹 Tx Tagging
25	Normal	Fixed	Forbidden	🗹 Tx Tagging
26	Normal	Fixed	Forbidden	🗹 Tx Tagging
27	Normal	Fixed	Forbidden	🗹 Tx Tagging
28	Normal	Fixed	Forbidden	🗹 Tx Tagging
29	Normal	Fixed	Forbidden	🗹 Tx Tagging
30	Normal	Fixed	Forbidden	🗹 Tx Tagging
31	Normal	Fixed	Forbidden	🗹 Tx Tagging
32	Normal	Fixed	Forbidden	🗹 Tx Tagging



∛ Note:

Create a Static VLAN only for the Translated VLAN, and set both of ports as members for the Translated VLAN. Otherwise the packets from the Translated VLAN received on port 26 will

NOT be forwarded to port 1.



2.4.2 Configuration on the Edge Switch

 Setup Customer Switch-1: Access to the web GUI. Go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the Active box, type the Name and VLAN Group ID= as 100. Select port 1 as Fixed and uncheck Tx Tagging (Untagged). Select port 9 as Fixed, and click "Apply".

VLAN Confi			-	Static VLAN
		8		TIVE
	00	VLAN 1		ome
		100		AN Group ID
	41			
Tagging		Control		₽orl
Tx Tagging	•	and plantation of the		
🗉 Tx Tagging	Forbidden	Fixed	Ø Normal	1
🗷 Tx Tagging	Forbidden	Fixed	Normal	2
🗹 Tx Topping	Forbidden	Fixed	Normal	3
🕅 Tx Togging	Forbidden	Fixed	Normal	4
🗭 Tx Togging	Forbidden	Fixed	Normal	5
🗹 Tx Togging	Forbidden	Fixed	Normal	6
🗷 Tx Togging	Forbidden	Fixed	Normal	7
🖉 Tx Togging	Forbidden	Fixed	Normal	8
🗹 Tx Topging	Forbidden	Fixed	Normal	9
It Tx Togging	Forbidden	Fixed	Normal	10

Setup Customer Switch-1: Go to Menu > Advanced Application
 > VLAN > VLAN Configuration > VLAN Port Setup. Set port 1
 PVID= as 100 (VLAN 100), and click "Apply".

	VLAN Port Settin	g				VLAN	Configurati
GVRP							
Port	Ingress Check	PVID	GVRP	Acceptable F	frame Type	VLAN Trunking	Isolation
•	0			All	•		
1		100		All	•		
2		1		All	•		
3		1		All	•		
.4		1		All	•		
5		1		All	¥		



3 Setup Customer Switch-2: Go to Menu > Advanced Application > VLAN > VLAN Configuration > Static VLAN Setup. Check the Active box, type the Name and VLAN Group ID= as 1001. Select port 1 as Fixed and uncheck Tx Tagging (Untagged). Select port 9 as Fixed, and click "Apply".

ACTIVE		
Name	VLAN 1001	
VLAN Group ID	1001	

Port		Control		Tagging
•		Normal	•	🗹 Tx Tagging
1	Normal	Fixed	Forbidden	🔲 Tx Tagging
2	Normal	Fixed	Forbidden	🗹 Tx Tagging
3	Normal	Fixed	Forbidden	🕑 Tx Tagging
4	Normal	Fixed	Forbidden	🗹 Tx Tagging
5	Normal	Fixed	Forbidden	🕑 Tx Tagging
6	Normal	Fixed	Forbidden	🗹 Tx Tagging
7	Normal	Fixed	Forbidden	🗷 Tx Tagging
8	Normal	Fixed	Forbidden	🗹 Tx Tagging
9	Normal	Fixed	Forbidden	🗹 Tx Tagging
10	Normal	Fixed	O Forbidden	🗹 Tx Tagging

Add Cancel Clear

Setup Customer Switch-2: Go to Menu > Advanced Application
 > VLAN > VLAN Configuration > VLAN Port Setup. Set port 1
 PVID= as 1001 (VLAN 1001), and click "Apply".

	VLAN Port Settin	g				VLAN	Configurat
GVRP		0					
Port	Ingress Check	PVID	GVRP	Acceptable f	Frame Type	VLAN Trunking	Isolation
•				All	•		
1		1001		All	•		
2		1		All	•		
3		1		All	•		
4		1		All	•		
5	0	1		All	T		



2.4.3 Test the Results

1 PC-1 can ping PC-2 successfully.

C:\>ping 192.168.1.200
Pinging 192.168.1.200 with 32 bytes of data:
Reply from 192.168.1.200: bytes=32 time<1ms TTL=128
Reply from 192.168.1.200; bytes=32 time<1ms TTL=128
Reply from 192.168.1.200; bytes=32 time<1ms TTL=128
Reply from 192.168.1.200: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.1.200:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 0ms, Average = 0ms

2 Configure Mirroring to verify the VLAN ID/Priority value in the packets which are received on port 1 of the core switch, and ensure they are the original value VLAN=100/Priority=0). Access to the web GUI and go to Menu > Advanced Application > Mirroring. Check the "Active" box. Set the Monitor port as port 2, which is used to monitor the traffic, and check the destination port 1 in this example. Select the direction as "Both", and click "Apply".

ive		
or Port	2	
Port	Mirrored	Direction
*		Ingress 🔻
1		Both 🔻
2		Ingress 🔻
4		
3		Ingress 🔻
R .		Ingress T Ingress T
3		the second s

3 Connect with another PC to port 2 of the core switch. Open wireshark to monitor the packets, and filter "icmp".



No.	Time	Source	Destination	Protocol	Length	Se Sy Info		
1	10 2019-11-29 1	4:22:42.868199 192.16	8.1.100 192.168	.1.200 ICMP	78	Echo	(ping)	request
-	13 2019-11-29 1	4:22:42.868908 192.16	8.1.200 192.168	.1.100 ICMP	78	Echo	(ping)	reply
	18 2019-11-29 1	4:22:43.869101 192.16	8.1.100 192.168	.1.200 ICMP	78	Echo	(ping)	request
	19 2019-11-29 1	4:22:43.869397 192.16	8.1.200 192.168	.1.100 ICMP	78	Echo	(ping)	reply
	23 2019-11-29 1	4:22:44.871108 192.16	8.1.100 192.168	.1.200 ICMP	78	Echo	(ping)	request
	24 2019-11-29 1	4:22:44.871432 192.16	8.1.200 192.168	.1.100 ICMP	78	Echo	(ping)	reply
	28 2019-11-29 1	4:22:45.873120 192.16	8.1.100 192.168	.1.200 ICMP	78	Echo	(ping)	request
-	29 2019-11-29 1	4:22:45.873521 192.16	8.1.200 192.168	.1.100 ICMP	78	Echo	(ping)	reply
Eth802	ernet II, Src: Wis .1Q Virtual LAN, P	tronI 30:0e:b8 (3c:97 RI: 0, DEI: 0, ID: 10	bytes captured (624 bits) :00e:30:0e:b8), Dst: Inver 00 1.100, Dst: 192.168.1.200	tec_27:04:93 (00:1e:3	3:27:04	1:93)		
		age Protocol						

4 Configure Mirroring to verify the VLAN ID/Priority in the packets sent out from port 26 of the core switch and ensure they should be the translated values (VLAN=1001/Priority=3). Go to Menu > Advanced Application > Mirroring. Uncheck port 1 and check port 26. Select the direction as "Both", and click "Apply".

Mirroring		RMirro
Active	Ø	
Monitor Port	2	

Port	Mirrored	Direction
•		Ingress 🔻
1		Both 🔻
2		Ingress 🔻
3		Ingress 🔻
4		Ingress 🔻
5		Ingress 🔻
Lo		Ingress 🔻
24		Ingress 🔻
25		Ingress 🔻
26	×	Both 🔻
27		Ingress 🔻
28		Ingress 🔻
29		Ingress 🔻
30		Ingress 🔻
31		Ingress 🔻
32		Ingress 🔻





5 Connect with another PC to port 2 of the core switch. Open wireshark to monitor the packets, and filter "icmp".

No.	Time	Source	Destination	Protocol	Length	Se Sy Info		
F	11 2019-11-29 14:31:57.053	356 192.168.1.100	192.168.1.200	ICMP	78	Echo	(ping)	request
	14 2019-11-29 14:31:57.053	673 192.168.1.200	192.168.1.100	ICMP	78	Echo	(ping)	reply
+	16 2019-11-29 14:31:58.054	182 192.168.1.100	192.168.1.200	ICMP	78	Echo	(ping)	request
-	17 2019-11-29 14:31:58.054	606 192.168.1.200	192.168.1.100	ICMP	78	Echo	(ping)	reply
	19 2019-11-29 14:31:59.055	558 192.168.1.100	192.168.1.200	ICMP	78	Echo	(ping)	request
	20 2019-11-29 14:31:59.055	908 192.168.1.200	192.168.1.100	ICMP	78	Echo	(ping)	reply
	22 2019-11-29 14:32:00.058	421 192.168.1.100	192.168.1.200	ICMP	78	Echo	(ping)	request
_	23 2019-11-29 14:32:00.058	888 192.168.1.200	192.168.1.100	ICMP	78	Echo	(ping)	reply


Prame 1b: 78 bytes on wire (624 bits), 78 bytes captured (624 bits) on interface 0
Ethernet II, Src: WistronI 30:00:18 (3c:97:00:30:00:b8), Dst: Inventec_27:04:93 (00:10:33:27:04:93)
802.10 Virtual LAN, PRI: 3) DEI: 0, ID: 1001
Internet Protocol Version 4, Src: 192.168.1.100, Dst: 192.168.1.200
Internet Control Message Protocol



Improving Network Reliability

3.1 How to configure a stacked switch to ensure high server availability

The example shows administrators how to configure a stacked switch to ensure high server availability. In this example, we stack Switch-1 and Switch-2 into one logical switch. By stacking the switch together, even if one switch goes offline, clients can still reach the server. This ensures high availability for servers. This example instructs administrators to disconnect all links before configuring the switches to avoid any network outages caused by broadcast storms.





∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50) and GS2210-48HP (Firmware Version: V4.30).



3.1.1 Configure Switch-1 and Switch-2 for Stacking

 Set up Switch-1: Enter the web GUI and go to Menu > Basic Setting > Stacking > Configuration. Key in the system priority (The higher the number is, the higher priority it is to become a master) and click "Apply". Check "Active" and click "Apply". Switch-1 will reboot.

Stacking Configuration	1	itacking Status
Active		
	Apply Cancel	
Force Master Mode		
System Priority	40	
	Apply Cancel	
∛ Note:		
•	e priority of Switch-1 higher thar	n Switch-2.
Therefore, Switch-1 will bec	come the Master.	

2 Set up Switch-2: Enter the web GUI and go to Menu > Basic Setting > Stacking > Configuration. Key in the system priority (The higher the number is, the higher priority it is to become a master) and click "Apply". Check "Active" and click "Apply". Switch-2 will reboot.

Stacking Configuration		Stacking Status
Active		
	Apply Cancel	
		_
Force Master Mode		
System Priority	32	
	(Ctrl) -	
	Apply Cancel	

3 Connect Switch-1 and Switch-2 together on port 32 using a 10-Gigabit transceiver.



∛ Note:

The last two ports are usually reserved for stacking channels when the switch is in stacking mode. These are ports 31 and 32 for the XGS4600-32 switch. If you are using other stackable models, please refer to the user manual to confirm the ports used for stacking.

- 4 Switch-1 and Switch-2 becomes a stacked switch. The Stack ID LED on the front panel of the switches should display "1" and "2".
- **5** Remember to save the configuration.



3.1.2 Configure Link Aggregation on Stacked switch

 Connect to the stacked switch. Enter web GUI and go to Menu
 Advanced Application > Link Aggregation > Link Aggregation Setting. Active T1 and T2. Select SLOT 1 and set the Group of port 1/1 and 1/2 as T1 and T2, respectively. Click "Apply". Select SLOT 2 and set the Group of port 2/1 and 2/2 as T1 and T2 respectively. Click "Apply".

Link Aggregation Setting		<u>Status</u> LACP
Group ID	Active	Criteria
TI		src-dst-mac ▼
T2		src-dst-mac ▼
T3		src-dst-mac ▼
Τ4		src-dst-mac ▼
SLOT 1 V Port 1/1 1/2 1/3 1/4		Group T1 V T2 V None V None V
SLOT 2 ▼ Port 2/1 2/2 2/3 2/4		Group T1 T T2 T None T None T

2 Go to Menu > Advanced Application > Link Aggregation > Link Aggregation Setting >LACP. Check the "Active" box, as well as for T1 and T2.

Link Aggregation Control Prot	Link Aggregation Control Protocol		
Active System Priority			
Group ID T1 T2		LACP Active	



3.1.3 Configure Link Aggregation on Switch-3

1 Go to Menu > Advanced Application > Link Aggregation > Link Aggregation Setting. Check the Active box for T1 and select the port 1 and 2 as Group T1. Click "Apply".

Link Aggregation Setting		<u>Status</u> <u>LACP</u>
Group ID	Active	Criteria
TI		src-dst-mac ▼
T2		src-dst-mac ▼
T3		src-dst-mac ▼
T4		src-dst-mac ▼
Port		Group
1		T1 🔻
2		T1 🔻
3		None 🔻
4		None 🔻

2 Go to Menu > Advanced Application > Link Aggregation > Link Aggregation Setting >LACP. Check the "Active" box and T1. Click "Apply".

Link Aggregation Contro	Link Aggregation Control Protocol	
Active		
System Priority	65535	
Group ID		LACP Active
TI		
T2		
ТЗ		
T4		



3.1.4 Test the Result

- 1 Configure Link Aggegation between the Server's two NIC and connect these ports to port 1/2 and 2/2 of the stacked switch.
- 2 Use PC to ping the Server (192.168.1.40). After few times of ping, try to shut down Switch-1 (Master down). The ping will display "timed out" a few times and then ping will be successful again when Switch-2 (Backup) becomes the new Master.

C:\Users\User>ping 192.168.1.40 -t
Pinging 192.168.1.40 with 32 bytes of data:
Reply from 192.168.1.40: bytes=32 time=4ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time=2ms TTL=254
Reply from 192.168.1.40: bytes=32 time=28ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=20ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time=9ms TTL=254
Request timed out.
Request timed out.
Reply from 192.168.1.40: bytes=32 time=21ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254
Reply from 192.168.1.40: bytes=32 time<1ms TTL=254



3.1.5 What Could Go Wrong

- 1 The stacking ports are usually the last 2 ports of the switch. If you connect the two switches using a non-stacking port, you will find that the two switches will not form a stacking system.
- 2 Remember to save the configuration before doing the test. If you forget to save the configuration, after rebooting, all the configurations will be lost. Therefore, the Link Aggregation will disappear.



3.2 How to configure RSTP in a ring topology

The example shows administrators how to set up RSTP (Rapid Spanning Tree Protocol) in the ring topology to implement network redundancy.




Figure 13 Configure RSTP in a ring topology

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).



3.2.1 Configure Switch

- 1 Make sure that the link between **Switch-2** and **Switch-3** is not connected to prevent unintended loops before finishing the RSTP setup.
- 2 Set up Switch-1: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > Configuration. Check if the Spanning Tree Configuration is Rapid Spanning Tree. If not, select it and click "Apply".

Spanning Tree Co	Spanning Tree Configuration	
Spanning Tree Mode	 Rapid Spanning Tree Multiple Rapid Spanning Tree Multiple Spanning Tree 	
	Apply Cancel	

3 Set up Switch-1: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > RSTP. Check the "Active" box. Set the Bridge Priority = 4096. Active port 1, 2. Click "Apply".

	apid Spanning	Tree Protoco	bl		<u>Statu</u>
Active					
Bridge Priorit	ty		4096	7	
Hello Time			2 Sec	onds	
MAX Age			20 Sec	onds	
Forwarding	Delay		15 Sec	onds	
Port	Active	Edge	Root Guard	Priority	Path Cost
Port •	Aclive	Edge	Root Guard	Priority	Path Cost
Port • 1	Active	Edge	Root Guard	Priority 128	Path Cost
Port • 1 2	Active	Edge	Root Guard		
•		Edge	Root Guard	128	4

4 Set up Switch-2: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > Configuration. Check



if the Spanning Tree Configuration is **Rapid Spanning Tree**. If not, select it and click "**Apply**".

5 Set up Switch-2: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > RSTP. Check the "Active" box. Set the Bridge Priority = 20480. Active port 1, 2. Click "Apply".

	apid Spanning		oi		<u>Statu</u>
Active				_	
Bridge Priorit	у		20480	*	
Hello Time			2 Se	conds	
MAX Age			20 Se	conds	
Forwarding (Delav		15 Se	conds	
ronvarang i					
Port	Active	Edge	Root Guard	Priority	Path Cost
		Edge	Root Guard	Priority	Path Cost
		Edge	Root Guard	Priority 128	Path Cost
	Active	Edge	Root Guard		
Port • 1	Active	Edge	Root Guard	128	4

- 6 Set up Switch-3: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > Configuration. Check if the Spanning Tree Configuration is Rapid Spanning Tree. If not, select it and click "Apply".
- 7 Set up Switch-3: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > RSTP. Check the "Active" box. Set the Bridge Priority = 32768. Active port 1, 2. Click "Apply".



					<u>State</u>
Active					
Bridge Priorit	y		32	768 🔻	
Hello Time			2	Seconds	
MAX Age			20	Seconds	
Forwarding [Delay		15	Seconds	
Port	Active	Edge	Root Gua	rd Priority	Path Cost
Port	Active	Edge	Root Gua	rd Priority	Path Cost
	Active	Edge	Root Gua	rd Priority	Path Cost
		Edge	Root Gua		
• 1		Edge	Root Gua	128	4

8 Finally, connect the link between **Switch-2** and **Switch-3**.



3.2.2 Test the Result

1 Verify the status of Switch-1: Go to Menu > Advanced Application > Spanning Tree Protocol. The Root Bridge ID and the Our Bridge ID should be the same. This means that Switch-1 is the Root Bridge. Both port 1 and 2 should be in FORWARDING state, while both their Port Roles are Designated Ports.

Bridge	Root		Our Bridge	
Bridge ID	1000-427374205	556	1000-427374205556	
Hello Time (second)	2		2	
Max Age (second)	20		20	
orwarding Delay (second)	15		15	
Cost to Bridge	0			
Port ID	0X0000			
lopology Changed Times	7			
ïme Since Last Change	0:00:28			
Port Port State Port I	tole Designated Bridge ID	Designated Port ID	Designated Cost	Root Guard State
1 FORWARDING Design	ated 1000-427374205556	0x8001	0	Forwarding
2 FORWARDING Design	ated 1000-427374205556	0x8002	0	Forwarding

2 Verify the status of Switch-2: Go to Menu > Advanced Application > Spanning Tree Protocol. Check the port status of Switch-2. Port 1 should be the Root Port in FORWARDING state, while port 2 should be a Designated Port also in FORWARDING state.

Bridge	Root		Our Bridge	
Bridge ID	1000-42737420555	56	5000-5cf4abf58768	
Hello Time (second)	2		2	
Max Age (second)	20		20	
Forwarding Delay (second)	15		15	
Cost to Bridge	4			
Port ID	0X8001			
lopology Changed Times	10			
îme Since Last Change	0:00:09			
Port Port State Port Pole	Designated Bridge ID	Designated Port ID	Designated Cost	Root Guard State
1 FORWARDING Root	1000-427374205556	0x8001	0	Forwarding
2 FORWARDING Designated	5000-5cf4abf58768	0x8002	4	Forwarding



3 Verify the status of Switch-3: Go to Menu > Advanced Application > Spanning Tree Protocol. Check the port status of Switch-3. Port 1 should be the Root Port in FORWARDING state, while Port 2 is an Alternate Port in DISCARDING state.

Spanning Tree Protocol Sta	lus		<u>Configurati</u>	on <u>RSTP MRSTP MSTP</u>
Spanning Tree Protocol: RSTP				
Bridge	ridge Root			
Bridge ID	1000-42737420555	6	8000-b0b2dc70f4e	1
Hello Time (second)	2		2	
Max Age (second)	20		20	
Forwarding Delay (second)	Forwarding Delay (second) 15			
Cost to Bridge	Cost to Bridge 4			
Port ID	0X8001			
Topology Changed Times	12			
Time Since Last Change	0:05:15			
Port Port State Port Role	Designated Bridge ID		Designated Cost	
1 FORWARDING Root	1000-427374205556	0x8002	0	Forwarding
2 DISCARDING Alternate	5000-5cf4abf58768	0x8002	4	Forwarding



3.2.3 What Could Go Wrong

- 1 If your Root Bridge is not the device you expected:
- a. Decrease the Spanning Tree priority of this device.
- b. Increase the Spanning Tree priority of the other devices.
 The switch with the LOWEST bridge priority will be the Root Bridge. If the priority is the same, the switch LOWEST MAC address will be the Root Bridge.
- 2 If it is not possible to access the management of the switches and the switch's port LEDs are constantly flashing, you can recover management access by removing or disconnecting any redundant links to break the ring topology. This frequently occurs before Spanning Tree is configured on the devices or if Spanning Tree is configured incorrectly.



3.3 How to configure VRRP to provide hosts with a redundant gateway

This example shows how to configure gateway redundancy. Virtual **Router Redundancy Protocol (VRRP)** is a feature that allows two gateways to use the same IP address. This allows hosts in the local network continues access to the Internet in the event of a failure on one of the gateways.




Figure 14 Two gateways running VRRP on the same LAN

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. Only the GS/XGS/XS3700 Series Switch and XGS4600 Series Switch supports VRRP. The L2 Switch can be any Zyxel switch using default configurations. This example relies on two different Internet Service Providers (ISP) for Internet access.

All UI displayed in this article are taken from the XGS4600 series switch.



3.3.1 Configuration in the Gateway-A

- 1 Access the Gateway-A's web GUI.
- 2 Go to Advance Application > VLAN > VLAN Configuration > Static VLAN Setup. Create/Edit VLAN 1 to make sure only Port 23 is a fixed port. Click Add.

Static VLAN				VLAN Configuration
ACTIVE		v		
Name		1		
VLAN Group ID		1		
VLAN Type		 Nor Priv 		
Association VLAN	List			
21	Normal	Fixed	Forbidden	Tx Tagging
22	Normal	Fixed	Forbidden	Tx Tagging
23	Normal	Fixed	Forbidden	Tx Tagging
24	Normal	Fixed	Forbidden	Tx Tagging
25	Normal	Fixed	Forbidden	🔲 Tx Tagging

3 Go to Advance Application > VLAN > VLAN Configuration > Static VLAN Setup. Create/Edit VLAN 10 to make sure only Port 24 is a fixed port. Click Add.

Static VLAN				VLAN Configuration
ACTIVE				
Name		10		
VLAN Group ID		10		
VLAN Type		 Nor Prive 		
Association VLAN	List			
21	Normal	O Fixed	Forbidden	🔲 Tx Tagging
22	Normal	Fixed	Forbidden	Tx Tagging
23	Normal	Fixed	Forbidden	Tx Tagging
24	Normal	Fixed	Forbidden	Tx Tagging
25	Normal	Fixed	Forbidden	🔲 Tx Tagging

4 Go to Advance Application > VLAN > VLAN Configuration > VLAN Port Setup. Configure port 24 with PVID 10. Click Apply.

www.zyxel.com



21	1	All	•	
22	1	All	•	
23	1	All	•	
24	10	All	•	
25	1	All	•	

5 Go to **Basic Setting > IP Setup**. Configure the IP address for VLAN 1. Click **Add** and do the same for VLAN 10.

IP Interface							
10.4.1.1	0						
IP Address	DHCP Client	DHCP Client					
	Static IP Address						
		IP Address	192.168.1.252				
		IP Subnet Mask	255.255.255.0				
	VID	1					
	Add	Cancel					
IP Interface							
IP Address	DHCP Client						
	Static IP Addres	s					
		IP Address	192.168.10.1				
		IP Subnet Mask	255.255.255.0				
	VID	10					
	Add	Cancel					

6 Go to **Basic Setting > IP Setup**. Configure the In-band Default Gateway. Click **Apply**.

IP Configuration		<u>IP Status</u>		
Default Gateway	192.168.10.2			
Default Management	In-band ○ Out-of-band			
Apply Cancel				

7 Go to IP Application > VRRP > Configuration. Enable VRRP for network "192.168.1.252/24". Make sure that the priority is "200". Click Add.

www.zyxel.com



_

Active	✓			
Name	VLAN1			
Network	192.168.1.252/24 🔻			
Virtual Router ID	1 •			
Advertisement Interval	1			
Preempt Mode				
Priority	200			
Uplink Gateway	192.168.10.2			
Response Ping				
Primary Virtual IP	192.168.1.254			
Secondary Virtual IP	0.0.0.0			
Add Cancel Clear				



3.3.2 Configuration in the Gateway-B

- 1 Access the Gateway-B's web GUI.
- 2 Go to Advance Application > VLAN > VLAN Configuration > Static VLAN Setup. Create/Edit VLAN 1 to make sure only Port 23 is a fixed port. Click Add.

Static VLAN				VLAN Configuration
ACTIVE		 ✓ 		
Name		1		
VLAN Group ID		1		
VLAN Type		 Nor Prive 		
Association VLAN	List			
21	Normal	Fixed	Forbidden	🔲 Tx Tagging
22	Normal	Fixed	Forbidden	Tx Tagging
23	Normal	Fixed	Forbidden	Tx Tagging
24	Normal	Fixed	Forbidden	Tx Tagging
25	Normal	Fixed	Forbidden	🔲 Tx Tagging

3 Go to Advance Application > VLAN > VLAN Configuration > Static VLAN Setup. Create/Edit VLAN 20 to make sure only Port 24 is a fixed port. Click Add.

Static VLAN				VLAN Configuration
ACTIVE		e		
Name		20		
VLAN Group ID		20		
VLAN Type		 Norm Privation 		
Association VLAN L	ist			
21	Normal	Fixed	Forbidden	🔲 Tx Tagging
22	Normal	Fixed	Forbidden	Tx Tagging
23	Normal	Fixed	Forbidden	🔲 Tx Tagging
24	Normal	Fixed	Forbidden	🔲 Tx Tagging
25	Normal	Fixed	Forbidden	🔲 Tx Tagging

4 Go to Advance Application > VLAN > VLAN Configuration > VLAN Port Setup. Configure port 24 with PVID 20. Click Apply.

www.zyxel.com



21	1	All	•	
22	1	All	•	
23	1	All	•	
24	20	All	•	
25	1	All	•	

5 Go to **Basic Setting > IP Setup**. Configure the IP address for VLAN 1. Click **Add** and do the same for VLAN 20.

IP Interface							
	0						
IP Address	OHCP Client						
	Static IP Address						
		IP Address	192.168.1.253				
		IP Subnet Mask	255.255.255.0				
	VID	1					
	VID	1					
	Add	Cancel					
IP Interface							
IP Address	O DHCP Client						
II Address	-						
	Static IP Addres	S					
		IP Address	192.168.20.1				
		IP Subnet Mask	255.255.255.0				
	VID	20					
	Add	Cancel					

6 Go to **Basic Setting > IP Setup**. Configure the Default Gateway. Click **Apply**.

IP Configuration		<u>IP Status</u>
Default Gateway	192.168.20.2	
Default Management	In-band Out-of-band	
	Apply Cancel	

7 Go to IP Application > VRRP > Configuration. Enable VRRP for network "192.168.1.252/24". Click Add.

www.zyxel.com



Active				
Name	VLANI			
Network	192.168.1.253/24 🔻			
Virtual Router ID	1 🔻			
Advertisement Interval	1			
Preempt Mode	✓			
Priority	100			
Uplink Gateway	192.168.20.2			
Response Ping				
Primary Virtual IP	192.168.1.254			
Secondary Virtual IP	0.0.0.0			
Add Cancel Clear				



3.3.3 Test the Result

 Verify that Gateway-A is the Master VRRP Router. Go to IP Application > VRRP. VR Status should display Master.

۷	/RRP Status			Configuration	
Index	Network	VRID	VR Status	Uplink Status	
1	192.168.1.252/24	1	Master	Alive	

2 Verify that Gateway-B is the Backup VRRP Router. Go to **IP Application > VRRP**. VR Status should display **Backup**.

V	RRP Status			Configuration
Index	Network	VRID	VR Status	Uplink Status
1	192.168.1.253/24	1	Backup	Alive

3 Verify that Gateway-A and Gateway-B has a default route to their respective USG in Maintenance > Routing Table.

Ro	uting Table Status					
Index	Destination	Gateway	Interface	Metric	Туре	Uptime
1	192.168.1.0/24	192.168.1.252	192.168.1.252	1	LOCAL	0:00:54
2	192.168.10.0/24	192.168.10.1	192.168.10.1	1	LOCAL	0:00:44
3	127.0.0.0/16	127.0.0.1	127.0.0.1	1	LOCAL	138:42:02
4	default	192.168.10.2	192.168.10.1	1	STATIC	0:00:23
Rou	uting Table Status					
Rou Index	uting Table Status Destination	Gateway	Interface	Metric	Туре	Uptime
		Gateway 192.168.1.253	Interface 192.168.1.253	Metric 1	Type LOCAL	Uptime 0:04:41
	Destination			Metric 1		
Index 1	Destination 192.168.1.0/24	192.168.1.253	192.168.1.253	Metric 1 1	LOCAL	0:04:41
Index 1 2	Destination 192.168.1.0/24 192.168.20.0/24	192.168.1.253 192.168.20.1	192.168.1.253 192.168.20.1	Metric 1 1 1	LOCAL	0:04:41 0:04:29

4 Configure the Host with a Static IP. The Host should be able to ping the virtual IP address **192.168.1.254**.

```
C: Windows \system32>ping 192.168.1.254

Pinging 192.168.1.254 with 32 bytes of data:

Reply from 192.168.1.254: bytes=32 time<1ms TTL=254

Ping statistics for 192.168.1.254:

Packets: Sent = 4, Received = 4, Lost = 0 <0% loss),

Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms
```



5 Disconnect port 23 or port 24 of Gateway-A. Hosts should still be able to ping the virtual IP address **192.168.1.254**.



3.3.4 What Could Go Wrong?

- 1 If the hosts are not able to access the Internet when Gateway-A has been disconnected from the network, the following problems may have occurred:
 - a. Verify that the hosts and Gateway-B IP interface are in the same subnet and VLAN.
 - b. Check for link failures on port 23 or port 24 of Gateway-B.
 - c. Check whether Gateway-B has a default route to USG-B.



3.4 How to configure bandwidth control to limit incoming or outgoing traffic rate

This example shows administrators how to configure bandwidth control to manage traffic rates. We can limit either incoming traffic, outgoing traffic, or both. In this example, we use two computers: FTP Client (PC) and FTP Server (FTPServer). PC will either be uploading files or downloading files from the FTP Server.




Figure 15 Configure bandwidth control to limit the traffic rate

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XG\$4600-32 (Firmware Version: V4.50).



3.4.1 Configure Switch

1 Enter the web GUI. Go to Menu > Advanced Application > Bandwidth Control. Check the "Active" box. Key in the rate in Ingress Rate (PC Upload rate) = 10240 kbps and Egress Rate (PC Download rate) = 20480 kbps. Remember to check the port "Active" boxes as well. Click "Apply".

Band	Bandwidth Control							
Active								
Port	Active	Ingre Commit Rate	ss Rate Active	Peak F	late	Active	Egress	Rate
•		kbps			kbps			kbps
1		1 kbps		10240	kbps	1	20480	kbps
2		1 kbps		1	kbps		1	kbps



3.4.2 Test the Result

1 Use PC to upload a file to the FTP Server. Transfer rate should be more or less 1.2 MB/s (or 10240 Mb/s).

Server/Local file	Directi Remote file	Size Priority Status
↓ test@192.168.1.200 D:\Test\TestFile.avi	>> /TestFile.avi	83.1 MB Normal Transferring
00:00:14 elapsed	00:00:58 left 21.3%	18,612,224 bytes (1.2 MB/s)

2 Use PC to download a file from the FTP Server. Transfer rate should be more or less 2.4 MB/s (or 20480 Mb/s).

Server/Local file	Directi	Remote file	Size	Priority	Status
↓ test@192.168.1.200 D:\Test\TestFile.avi 00:00:28 elapsed	<< 00:23:37 le	/TestFile.avi ft 2.0% 71,70	3.4 GB 52,000 bytes <mark>(</mark> 2		Transferring



3.5 How to configure ACL to rate limit IP traffic

In some networks, it is necessary to configure rate limits among VLANs. For example, VLAN 10 is for employees within the organization; VLAN 20 is for guests. By rate limiting VLAN 20, we can ensure better bandwidth or network performance for users in VLAN 10. This example shows administrators how to configure ACL to rate limit VLAN traffic. Results are verified by observing and comparing the upload and download rate between VLAN 10 and VLAN 20.




Figure 16 Configure ACL to rate limit VLAN traffic

Vote:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50) and GS2210-48HP (Firmware Version: V4.30).



3.5.1 Configure VLAN and Route Traffic

- 1 Configure the VLAN setting (VLAN 10 and VLAN 20) on Switch-1 and Switch-2 (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments).
- 2 Configure the route traffic on Switch-1 and Switch-2 (Please refer to the topic: 2.2 How to configure the switch to route traffic across VLANs)



3.5.2 Configure the Classifier

 Set up the Classifier on Switch-2: Go to Menu > Advanced Application > Classifier > Classifier Configuration. Set up 4 Classifier: Classifier for download and upload in VALN 10 and VLAN 20. Therefore, there are total 4 Classifiers.

∛ Note:
ACL causes traffic that matches the criteria of a Classifier to follow its
corresponding Policy Rule.

2 The Classifier for download traffic in VLAN 10: Check the "Active" box and key in the Name. Set Layer 3 > Destination as 192.168.10.0/24 (Means the destination is in VLAN 10) and Source as 192.168.1. 100/32 (Means the source is FTPServer). Press "Add".

Classifi	er Configuration	Classifier Status Classifier Global Setting
Active Name Weight	 ✓ ✓	
	IP Packet Length	Any To Bytes
	DSCP	IPv4 Any IPv6 Any IPv6 IPv6
	Precedence	Any
Layer 3	ToS	Any
	IP Protocol	All Establish Only Others (Dec)
	IPv6 Next Header	All Establish Only Others (Dec)
	Source	IP Address / Address Prefix / 192.168.1.100 / 32
	Destination	IP Address / Address Prefix / 192.168.10.1 / 24

3 The Classifier for upload traffic in VLAN 10: Check the "Active" box and key in the Name. Set Layer 3 > Destination as



192.168.1.100/32 (Means the destination is FTPServer) and **Source** as **192.168.10.0/24** (Means the source is from VLAN 10). Press "Add".

Classifie	er Configuration	Classifier Status Classifier Global Setting
Active Name Weight	UL10 32767	
	DSCP	IPv4 • Any IPv6 • Any
	Precedence	Any
Layer 3	ToS	Any
	IP Protocol	All All Establish Only Others (Dec)
	IPv6 Next Header	All Chers (Dec)
	Source	IP Address / Address Prefix / 192.168.10.1 / 24
	Destination	IP Address / Address Prefix / 192.168.1.100 / 32

- 4 The Classifier of download in VLAN 20: Check the "Active" and key in the Name. Set Layer 3 > Destination as 192.168.20.0/24 (Means the destination is in VLAN 20) and Source as 192.168.1.100/32 (Means the source is FTPServer). Press "Add".
- 5 The Classifier of upload in VLAN 20: Check the "Active" and key in the Name. Set Layer 3 > Destination as 192.168.1.100/32 (Means the destination is FTPServer) and Source as 192.168.20.0/24 (Means the source is from VLAN 20). Press "Add".



3.5.3 Configure the ACL (Policy Rule)

- Set up the Policy Rule on Switch-2: In section 3.5.2, we created 4 Classifiers. We can find that they are shown in the Policy Rule window for us to match. Go to Menu > Advanced Application > Policy Rule.
- 2 The Policy Rule of download traffic in VLAN 10: Check the "Active" box and key in the Name. Select the Classifier of download in VLAN 10 (DL10). Set up the action to do if match this Classifier: Bandwidth Metering=40960 kbps. Enable Metering and set the Out-of-profile action (Means what to do if the rate is over the bandwidth) as "Drop the packet" (Means Switch-2 will drop the traffic which is over the bandwidth). Press "Add".

Policy				
Active				
Name	PolicyDL10			
Classifier(s)	DL10 DL20 UL10 UL20	* *		
Parameters	Gene Egress Port Priority DSCP TOS	1 0 • 0 •	M Bandwidth Out-of-Profile DSCP	etering 40960 kbps



6						
		Forwarding				
		No change				
		Discard the packet				
		Do not drop the matching frame previously marked for dropping				
		Priority				
		No change				
		Set the packet's 802.1p priority and send the packet to priority queue				
		Replace the 802.1 p priority field with the IP TOS value and send the packet to priority queue				
		Replace the 802.1p priority field with the inner 802.1p priority value and send the packet to				
		priority queue				
		Diffserv				
		No change				
AC	tion	Set the packet's TOS field				
		Replace the IP TOS field with the 802.1 p priority value				
		Set the Diffserv Codepoint field in the frame				
		Outgoing				
		Send the packet to the mirror port				
		Send the packet to the egress port				
		Metering				
		🗹 Enable				
		Drop the packet				
		Change the DSCP value				
		Out-of-profile action Set Out-Drop Precedence				
		Do not drop the matching frame previously marked for dropping				

- 3 The Policy Rule of upload in VLAN 10: Check the "Active" and key in the Name. Select the Classifier of upload in VLAN 10 (UP10). Set up the action to do if match this Classifier: Bandwidth Metering=20480 kbps. Enable Metering and set the Out-of-profile action as "Drop the packet". Press "Add".
- 4 The Policy Rule of download in VLAN 20: Check the "Active" and key in the Name. Select the Classifier of download in VLAN 20 (DP20). Set up the action to do if match this Classifier: Bandwidth Metering=20480 kbps. Enable Metering and set the Out-of-profile action as "Drop the packet". Press "Add".
- 5 The Policy Rule of upload in VLAN 20: Check the "Active" and key in the Name. Select the Classifier of upload in VLAN 20 (UP20). Set up the action to do if match this Classifier:
 Bandwidth Metering=10240 kbps. Enable Metering and set the Out-of-profile action as "Drop the packet". Press "Add".



3.5.4 Test the Result

1 Go to Menu > Advanced Application > Classifier. Check "Count". If the traffic matches the classifier, the Match Count for this classifier should be increasing every time the web page refreshes.

Classifier Configuration					<u>Classifier Status</u>	Classifier Global Setting
Active	st.					
Name	DL_	10				
Weight	327	67				
Log						
Count						
	Classifier Status					Classifier Configuration
Index	Active	Weight	Name	Match Count	Rule	
1	Yes	32767	DL_10	.10	SrcIP = 192.168.1.150/32; DestIP =	: 192.168.10.0/24; count;
				L	1	

2 Use PC-1 to download a file from the FTP Server. Transfer rate should be more or less 5 MB/s (or 40960 Mb/s).

		Priority	Status
<< /TestFile.avi	87.1 MB	Normal	Transferring
0:00:03 left 89.6%	78,086,956 bytes (5	.0 MB/s)	

3 Use PC-1 to upload a file to the FTP Server. Transfer rate should be more or less 2.6 MB/s (or 20480 Mb/s).

Server/Local file	Directi R	Remote file	Size	Priority	Status
Itest@192.168.1.100					
D:\Test\TestFile.avi	<< /	TestFile.avi			Transferring
00:00:21 elapsed	00:23:21 left	1.5%	56,150,564 bytes (2	2.6 MB/s)	

4 Use PC-2 to download a file from the FTP Server. Transfer rate should be more or less 2.6 MB/s (or 20480 Mb/s).

Server/Local file	Directi Remote file	Size Priority	Status
test@192.168.1.100			
D:\Test\TestFile.avi	>> /TestFile.avi	87.1 MB Normal	Transferring
00:00:15 elapsed	00:00:20 left 45.4%	39,583,744 bytes (2.6 MB/s)	

5 Use PC-2 to upload a file to the FTP Server. Transfer rate should be more or less 1.2 MB/s (or 10240 Mb/s).

www.zyxel.com



Server/Local file	Directi	Remote file	Size	Priority	Status
test@192.168.1.100					
D:\Test\TestFile.avi	>>	/TestFile.avi	87.1 MB	Normal	Transferring
00:00:11 elapsed	00:00:59 le	eft 17.1%	14,942,208 bytes (1	1.3 MB/s)	




3.5.5 What Could Go Wrong

1 When setting up the Classifier, remember to consider both the source and destination of the traffic. In the example, if we only set up the source as VLAN 10 (192.168.10.0/24) during file upload the Server, but didn't set up the destination (Server IP: 192.168.1.150), it will cause all the traffic to be rate limited when the PC try to send traffic to others from VLAN 10.



3.6 How to Implement VRRP with Multiple Routing Interface Combine with HA-pro Using Zyxel Enterprise Switch

In the previous chapter, we have introduced VRRP and how to configure it to do redundancy. However, the example in the chapter is talking about how to do redundancy when a company has two Internet Service Provider (ISP). In fact, some companies may only have one ISP and there is only one gateway device connected to it. What if the cable connected between ISP and gateway device is not working or the cable is bitten by a mouse. Or, the gateway device somehow has an abnormal behavior. These situations may cause a single point failure and the customers can't connect to the Internet. To avoid this failure happen, we can use two gateway devices and combine VRRP with HA-pro to do the redundancy.



Upon the topology, the normal traffic flow will be like figure 1. However, somehow the gateway device USG310-1 (Master) or the link 1 or 2 has some issues. It will cause all hosts that connected to Switch-1 (Master) not be able to surf the Internet.

In this situation, VRRP & Device HA-Pro is a very useful method to provide redundancy. USG310-2 (Backup) will take all over as the Master and clockwise for Switch-2 (Backup) to ensure that all of the hosts can still access the Internet. For now, the traffic flow will be like figure 2.






Figure 2

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks.



3.6.1 Configuration

L3 Switch:

1. Access switch-1 (Master) web GUI

2. Go to Advanced Application > VLAN > VLAN Configuration >Static VLAN Setup

3. Create VLAN 10 and VLAN 100 for host.

Static VLAN				VLAN Config
ACTIVE				
Name		PC_Po	rt11	
VLAN Group ID		10		
VLAN Type		 Nor Priv 		
Association VLAN	List			
24	Normal	C Fixed	Forbidden	🗹 Tx Tagging
25	Normal	Fixed	Forbidden	☑ Tx Tagging
26	Normal	Fixed	O Forbidden	🗹 Tx Tagging
27	Normal	Fixed	O Forbidden	🗹 Tx Tagging
28	Normal	Fixed	Forbidden	🗹 Tx Tagging
29	Normal	Fixed	Forbidden	🗹 Tx Tagging
30	Normal	C Fixed	Forbidden	🗹 Tx Tagging
31	Normal	Fixed	Forbidden	🗹 Tx Tagging
01	Normal	Fixed	Forbidden	🗹 Tx Tagging



ACTIVE Name VLAN Group ID		PC_Por	t10	
Name			t10	
		FC_FO		
VLAN Group ID		100		
		100		
VLAN Type		Nor		
		Prive	ote 🔹 🔻	
Association VLAN List				
24 🔘	Normal	Fixed	O Forbidden	🗹 Tx Tagging
25 💿	Normal	Fixed	Forbidden	🗹 Tx Tagging
26 🔘	Normal	Fixed	Forbidden	🗹 Tx Tagging
27 🔘	Normal	Fixed	Forbidden	🗹 Tx Tagging
28 🔘	Normal	Fixed	Forbidden	🗹 Tx Tagging
29 💿	Normal	Fixed	Forbidden	🗹 Tx Tagging
30 💿	Normal	Fixed	Forbidden	🗹 Tx Tagging
31 💿	Normal	Fixed	Forbidden	🗹 Tx Tagging
32 💿	Normal	Fixed	O Forbidden	🗹 Tx Tagging

- 4. Got to the Basic Setting >IP Setup > IP Configuration
- 5. Configure IP interface to VLAN 1 for uplink.

IP Address	DHCP Client				
	Static IP Address				
		IP Address	192.168.1.251		
		IP Subnet Mask	255.255.255.0		
	VID	1			

6. Configure IP interface to VLAN 10 & VLAN 100 for hosts.



IP Address	DHCP Client				
	Static IP Address				
		IP Address	192.168.10.1		
		IP Subnet Mask	255.255.255.0		
	VID	10			

VLAN 100:

IP Address	DHCP Client				
	Static IP Address				
		IP Address	192.168.100.1		
		IP Subnet Mask	255.255.255.0		
	VID	100			

7. Configure IP default gateway for VLAN 1 interface.

IP Configuration		IP Status
Default Gateway	192.168.1.1	
Default Management	In-band Out-of-band	
	Apply Cancel	

8. Go to IP Application > VRRP > Configuration

 Configure VRRP on all VLAN interface, "Response Ping" is optional. However, if response ring is inactive, you won't be able to ping virtual IP.

VLAN 1:



Active	e
Name	VLAN1
Network	192.168.1.251/24 ▼
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	200
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.1.254
Secondary Virtual IP	192.168.1.253

Add Cancel Clear

VLAN 10:

Active	
Name	VLAN10
Network	192.168.10.1/24 🔻
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	200
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.10.254
Secondary Virtual IP	192.168.10.253

Active	
Name	VLAN100
Network	192.168.100.1/24 🔻
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	200
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.100.254
Secondary Virtual IP	192.168.100.253



10. Access the Switch-2 (Backup) web GUI.

11.Go to Advanced Application > VLAN > VLAN Configuration >Static VLAN Setup

12. Create VLAN 10 & VLAN 100 for hosts.

				VLAN Configu
ACTIVE				
Name		VLAN1	0	
VLAN Group ID		10		
VLAN Type		 Nor Priv 		
Association VLAN	List			
24	Normal	Fixed	Forbidden	🗷 Tx Tagging
25	Normal	Fixed	Forbidden	Ix Tagging
26	Normal	Fixed	Forbidden	🕑 Tx Tagging
27	Normal	Fixed	Forbidden	Tx Tagging
28	Normal	Fixed	Forbidden	🗷 Tx Tagging
20	Normal	Fixed	Forbidden	🗹 Tx Tagging
20		0	Forbidden	🗹 Tx Tagging
12773	Normal	Fixed	 Forbidden 	
29	NormalNormal	O Fixed	 Forbidden 	☑ Tx Tagging



ACTIVE				
Name		VLAN1	00	
VLAN Group ID		100		
VLAN Type		 Nor Priv 		
Association VLAN	List			
24	Normal	Fixed	Forbidden	🖉 Tx Tagging
25	Normal	Fixed	Forbidden	🗹 Tx Tagging
26	Normal	Fixed	Forbidden	🗷 Tx Tagging
	Normal	Fixed	Forbidden	🗹 Tx Tagging
27		Fixed	Forbidden	🗹 Tx Tagging
27 28	Normal	Fixed	Porbidden	
	NormalNormal	 Fixed Fixed 	 Forbidden 	✓ Tx Tagging
28				
28 29	Normal	O Fixed	Forbidden	🗹 Tx Tagging

13.Go to Basic Settings > IP Setup > IP Configuration

14. Configure IP interface on VLAN 1 for uplink.

IP Address	DHCP Client			
	Static IP	Address		
		IP Address	192.168.1.252	
		IP Subnet Mask	255.255.255.0	
	VID	1		

15. Configure IP interface on VLAN 10 & VLAN 100 for hosts.



^o Address	O DHCP Client				
	Static IP Address				
		IP Address	192.168.10.2		
		IP Subnet Mask	255.255.255.0		
	VID	10			

VLAN 100:

P Address	DHCP Client				
	Static IP Address				
		IP Address	192.168.100.2		
		IP Subnet Mask	255.255.255.0		
	VID	100			

16. Configure IP default gateway on VLAN 1 for the uplink.

IP Configuration		<u>IP Status</u>
Default Gateway	192.168.1.1	
Default Management	In-band Out-of-band	
	Apply Cancel	

17.Go to IP Application > VRRP > Configuration

18.Configure VRRP on all VLAN interface, "Response Ping" is optional. However, if response ring is inactive, you won't be able to ping virtual IP.

VLAN 1:



Active	
Name	Backup
Network	192.168.1.252/24 ▼
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	100
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.1.254
Secondary Virtual IP	192.168.1.253

VLAN 10:

Active	
Name	Backup
Network	192.168.10.2/24 🔻
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	100
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.10.254
Secondary Virtual IP	192.168.10.253



Active	
Name	Backup
Network	192.168.100.2/24 ▼
Virtual Router ID	1 🔻
Advertisement Interval	1
Preempt Mode	
Priority	100
Uplink Gateway	192.168.1.1
Response Ping	
Primary Virtual IP	192.168.100.254
Secondary Virtual IP	192.168.100.253

L2 switch:

- 1. Access layer 2 switch via web GUI.
- 2. Go to Advanced Application > VLAN > VLAN Configuration >Static VLAN Setup.
- 3. Configure VLAN 10 & VLAN 100 for hosts.

VLAN 10:

	ACTIVE		v	
	Name		VLAN10	
VL	AN Group ID		10	
VLAN Type			Normal Private	
Assoc	iation VLAN List			
Port		Contr	rol	Tagging
*		Normal	•	Tx Taggir
1	Normal	Fixed	Forbidden	🗹 Tx Taggir
2	Normal	Fixed	Forbidden	🗹 Tx Taggir
3	Normal	Fixed	Forbidden	🗹 Tx Taggir
4	Normal	Fixed	Forbidden	🗹 Tx Taggir
5	Normal	Fixed	Forbidden	🗹 Tx Taggir
6	Normal	Fixed	Forbidden	🗷 Tx Taggir
7	Normal	Fixed	Forbidden	🗹 Tx Taggir
8	Normal	Fixed	Forbidden	🗷 Tx Taggir
9	Normal	Fixed	Forbidden	🗹 Tx Taggir
10	Normal	Fixed	Forbidden	🗹 Tx Taggir
11	Normal	Fixed	Forbidden	🔲 Tx Taggir



VLAN Confi				Static VLA
			ACTIVE	
	_AN100	VI	Name	
	0	10	VLAN Group ID	VL
	VLAN Type Normal Private VLAN Type		VLAN Type	
			ociation VLAN List	Assoc
Tagging		Control		Port
Tx Tagging	▼			*
Tx Tagging	Forbidden	Fixed	Normal	1
Tx Tagging	Forbidden	Fixed	Normal	2
Tx Tagging	Forbidden	Fixed	Normal	3
Tx Tagging	Forbidden	Fixed	Normal	4
	Forbidden	Fixed	Normal	5
Tx Tagging				
 Tx Tagging Tx Tagging 	Forbidden	Fixed	Normal	6
🗹 Tx Tagging	Forbidden Forbidden	 Fixed Fixed 	 Normal Normal 	6 7
 Tx Tagging Tx Tagging 				
🗹 Tx Tagging	Forbidden	Fixed	Normal	7

- 4. Go to Basic Setting > IP Setup > IP Configuration
- 5. Configure IP interface for VLAN 10 & VLAN 100

IP Address	DHCP Client			
	Static IP A	Address		
		IP Address	192.168.10.10	
	IP Subnet Mask		255.255.255.0	
	VID	10		



IP Address	O DHCP Client				
	Static IP /	Address			
		IP Address	192.168.100.10		
		IP Subnet Mask	255.255.255.0		
	VID	100			

- 6. Go to Advanced Application > VLAN > VLAN Configuration> Static VLAN Setup
- 7. Enter VLAN 1 to inactivate VLAN.

/ID	Active	Name	VLAN Type	Association VLAN List	
1	Yes	VLAN1	Normal		
10	Yes	VLAN10	Normal		
100	Yes	VLAN100	Normal		

8. Uncheck the "Active" to inactive VLAN 1 then click Add.

	7	
	1	
•		

9. Go to Advanced Application > VLAN > VLAN Configuration > VLAN Port Setting

10. Configure PVID on port 10 & 11



Port	Ingress Check	PVID	GVRP	Acceptable Frame Type	VLAN Trunking	Isolation
*				All 🔻		
1		1		All		
2		1		All		
3		1		All		
4		1		All		
5		1		All		
6		1		All		
7		1		All		
8		1		All 🔻		
9		1		All		
10		100		All		
11		10		All		
12		1		All 🔻		
13		1		All		

Gateway:

1. Access USG310-1 (Master) web GUI.

2. Go to Configuration > Device HA > Device HA Pro

 Configure device HA-pro on USG310-1, Active/Passive device management IP and password can be modified depends on your settings. Click "Apply & switch to Device HA pro first then click Apply.



Serial Number of Licensed Device for License Synchronization Active Device Management IP: Passive Device Management IP:	n: \$142L22570056	
Passive Device Management IP:	1.1.1.1	
	1.1.1.2	
Subnet Mask:	255.255.255.0	
Password:		
Retype to Confirm:		
Heartbeat Interval:	2	seconds (1-10)
Heartbeat Lost Tolerance:	2	(1-10)
	or Interface	
onitor Interface		
=== Object ===	=== Object ===	
ge2 ge1 de3		
ge5 +		
ge6		

- 4. Go to Configuration > Device HA > General.
- 5. Enable the Device HA on General Settings.

General Settings	Configuration Walkthrough	Troubleshooting	1
Enable Device HA	Device		(Switch to Device HA page)
Device HA Mode.	Device	IIA IIO	ISWIICH TO DEVICE HA DOGE

Reset

- 6. Access the USG310-2(Backup) web GUI.
- 7. Go to Configuration > Device HA > General.

Apply

8. Enable the Device HA on General Settings.



Device HA Mode:	Device HA Pro	(Switch to Device HA page

- 9. Go to Configuration > Routing > Static Route
- **10.**Configure the routing path for destination 192.168.100.0/24 & 192.168.10.0/24.
- 192.168.10.0/24

Pv4 Static Route Setting			? ×
Destination IP:	192.168.1	0.0]
Subnet Mask:	255.255.2	55.0	
Gateway IP	192.168.1	.254	
🔘 Interface	gel	~	-
Metric:	0		
	[OK	Cancel



192.168.100.0/24

Pv4 Static Route Setting	9		?
Destination IP:	192.168.100.0		
Subnet Mask:	255.255.255.0		
Gateway IP	192.168.1.254		
🔘 Interface	gel	~	
Metric:	0		
		OK C	ancel
			and a second second

∛ Note:

Remember to finish all configurations before connecting the link between USG, otherwise it will not sync successfully.



3.6.2 Verification

L3 Switch (VRRP):

- 1. Access Switch-1 (Master) via web GUI.
- 2. Go to IP Application > VRRP, the figure below is the successful VRRP status due to switch-1 can reach the gateway IP.

atus	us				Configuratio
	Network	VRID	VR	Status	Uplink Status
192.1	2.168.100.1/24	1	M	aster	Alive
192.	2.168.10.1/24	1	Me	aster	Alive
192.1	2.168.1.251/24	1	M	aster	Alive

3. Access Switch-2 (Backup) via web GUI.

4. Go to IP Application > VRRP,

5. The figure below is the successful VRRP status. It is normal that the status displays "Init" due to the USG310-2 still in backup status which is down. Therefore, the gateway is unreachable.

VR	RP Status			Configuration
Index	Network	VRID	VR Status	Uplink Status
1	192.168.100.2/24	1	Init	Dead
2	192.168.10.2/24	1	Init	Dead
3	192.168.1.252/24	1	Init	Dead

 $rac{1}{2}$ Note: "Init" VR status means that the gateway is not reachable.

Gateway (Device HA-Pro):

1. Access USG310-1 (Master) via web GUI.



2. Go to Configuration > Device HA, the figure below is

the successful Device HA Pro status.

On	\$142L35530028	4C9EFF85219B	n/a
4 4 Page 1	of 1 🕨 🕅 Show 50 💌 items	8	Displaying 1 - 1 of 1
assive Device Status			
Health Status	\$/N	MAC -	Sync Status
On	\$142L35530247	4C9EFF85219B	Success
N A Page 1	of 1 🕨 🔰 Show 50 👻 items		Displaying 1 - 1 of 1
Active Device			assive Device
Tue Apr 30 05:26:37 2019 E	Enter Active mode	Т	ue Apr 30 05:46:43 2019 Enter Passive mode ue Apr 30 05:46:52 2019 Start to synchronize with ue Apr 30 05:49:39 2019 Synchronize complete
			1

2. All hosts (e.g. PC) default gateway must be configured with VRRP primary



3.6.3 What may go wrong?


- 1. Switch VRRP uplink gateway must be configured with USG's IP.
- 2. Remember to configure the VLAN member on the downlink switch.



3.7 How to Configure the Switch to Tunnel Layer 2 Protocol Packets Through Service Provider Network

Zyxel switch models support Layer-2 Protocol Tunneling (L2PT) that allows edge switches to tunnel layer-2 protocol packets through service provider networks. It could be used when customer switches are located at different sites and connected across a service provider network.

Therefore, the customer networks can implement independent layer 2 protocol solutions. For example, it could provide a single and independent spanning tree domain for customer networks across a service provider network.



When Edge switch-1 receives Layer-2 protocol packets, it will encapsulate these packets and rewrite their destination MAC addresses with a specific MAC address. All the switches inside the service provider network treat these encapsulated packets as data packets and forward them to the other side. When Edge switch-2 receives these encapsulated packets, it will de-capsulate them and change their destination MAC addresses back to the original one before forwarding them to the destination switch.


Each port on edge switch has two modes:

- Access Port: For ingress ports which reside on the service provider's edge switch and connect to a customer switch, incoming layer 2 protocol packets received on an access port are encapsulated and forwarded to the tunnel ports.
- **Tunnel** Port: For egress ports which reside on the edge of the service provider's network and connect to another service provider's switch,



incoming encapsulated layer 2 protocol packets received on a tunnel port are decapsulated and sent to an access port.

The following example will instruct how an administrator configures a switch to tunnel STP packets through a service provider network.





3.7.1 Configuration on the Edge Switch

1 Setup Edge Switch-1: Access to the web GUI. Go to

Advanced Application > Layer 2 Protocol Tunneling. Check "Active", and set the "Destination MAC Address".

	Active							
L	Destination	MAC Addres	5	01:80:c2:1	1:22:33			
Ì	Port	CDP	STP	VTP		Point to Poin		Mode
					PAGP	LACP	UDLD	14
	ា							Access
-	2		0		-		8	Access
-	3	8				8		Access
	4	-						Access
nc	te: ation MAC	C Address	can be	e either a	unicast N	MAC add	ress or a	100000
nc es	te: ation MAC s.	C Address						multicas
nc es Fo	te: ation MAC s. or unicast		dress: m	ake sure ⁻	the MAC	address	does NC	multicas DT exist in
nc es: Fo M.	te: ation MAC s. or unicast AC table	MAC add	dress: m es whic	ake sure ⁻ h reside ir	the MAC n the serv	address vice provi	does NC der's ne	multicas DT exist in
nc es: Fo M.	te: ation MAC s. or unicast AC table or multica	MAC add	dress: m es whic ddress:	ake sure ⁻ h reside ir make sure	the MAC In the service the MA	address vice provi	does NC der's ne ss is	multicas DT exist in
nc es: Fo M.	te: ation MAC s. or unicast AC table or multica	MAC add of switch st MAC a	dress: m es whic ddress:	ake sure ⁻ h reside ir make sure	the MAC In the service the MA	address vice provi	does NC der's ne ss is	multicas DT exist in

All the edge switches in the service provider's network should use the **same** MAC address for encapsulation.

2 Setup Edge Switch-1: On the same page. Check "STP" and set "Mode" as "Access" on port 26 which connects to the customer switch.



3 Setup Edge Switch-1: On the same page. Set "Mode" as "Tunnel" on port 28 which connects to another edge switch in service provider's network, and click "Apply".

Active		
Destination MAC Address	01:80:c2:11:22:33	

Port	CDP	STP	VTP	PAGP	oint to Poir LACP	t UDLD	Mode
							Access 1
1							Access 1
2							Access 1
3							Access 1
4							Access 1
· -		-	-	-	677)	(T)	· -
47	1000	Name of Street		_	-	1000	
25							Access
26							Access
27							Access
28							Tunnel
29							Access
30							Access
31							Access
32							Access

Apply Cancel

∛ Note:

Activate L2PT services for supported protocols on the access port(s) only.

4 Setup Edge Switch-2: Access to the web GUI. Go to Advanced Application > Layer 2 Protocol Tunneling. Activate Layer 2 Protocol Tunnel, and set the "Destination MAC Address".



Layer 2 Protocol Tunnel	
Active	
Destination MAC Address	01:80:c2:11:22:33

	0.000				oint to Poir	tt.	
Port	CDP	STP	VTP	PAGP	LACP	UDLD	Mode
•							Access 🔻
1							Access ¥
2							Access V
3							Access V
4							Access V
849	(m)	- 670	673	-	-	100	

Vote:

Destination MAC Address can be either a unicast MAC address or multicast MAC address.

- For unicast MAC address: make sure the MAC address does NOT exist in the MAC table of switches which reside in the service provider's network.
- 2. For multicast MAC address: make sure the MAC address is

NOT used for specific protocols, such as STP, VTP,

∛ Note:

All the edge switches in the service provider's network should use the **same** MAC address for encapsulation.

- 5 Setup Edge Switch-2: On the same page. Activate STP and set mode as "Access" on port 26 which connects to the customer switch.
- 6 Setup Edge Switch-2: On the same page. Set mode as "Tunnel" on port 28 which connects to another edge switch in service provider's network, and click "Apply".



Layer 2 Protocol Tunnel		
Active		
Destination MAC Address	01:80:c2:11:22:33	

Mode		oint to Poin		VTP	STP	CDP	Port
	UDLD	LACP	PAGP				
Access							
Access							1
Access							2
Access							3
Access							4
· ·	1773	(TT)	673		63		-
100000	1000	Annual Control of Cont		-	1000	1000	67
Access							25
Access							26
Access							27
Tunnel							28
Access							29
Access							30
Access							31
Access							32

Apply Cancel

∛ Note:


Activate L2PT services for supported protocols on the access port(s) only.



3.7.2 Configuration on the Customer Switch

 Setup Customer Switch-A: Access to the Web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > Configuration. Check if the Spanning Tree Configuration is Rapid Spanning Tree. If not, select it and click "Apply".

Spanning Tree Co	onfiguration	<u>Status</u>
Spanning Tree Mode	 Rapid Spanning Tree Multiple Rapid Spanning Tree Multiple Spanning Tree 	
	Apply Cancel	



2 Set up Customer Switch-A: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > RSTP. Check the "Active" box, and set the Bridge Priority = 4096. Activate port 10, and click "Apply".



Rapid Spanning Tree	Protocol	Sta
Active		
Bridge Priority	40	96 🔻
H <mark>ell</mark> o Time	2	Seconds
MAX Age	20	Seconds
Forwarding Delay	15	Seconds

Port	Active	Edge	Root Guard	Priority	Path Cost
•					
1				128	4
2				128	4
3				128	4
4				128	4
5				128	4
6				128	4
7				128	4
8				128	4
9				128	4
10				128	4

Apply Cancel

3 Setup Customer Switch-B: Access to the Web GUI. Go to
 Menu > Advanced Application > Spanning Tree Protocol >
 Configuration. Check if the Spanning Tree
 Configuration is Rapid Spanning Tree. If not, select it and click
 "Apply".

Spanning Tree Co	onfiguration	<u>Status</u>
Spanning Tree Mode	 Rapid Spanning Tree Multiple Rapid Spanning Tree Multiple Spanning Tree 	
-	Apply Cancel	



4 Set up Customer Switch-B: Enter the web GUI. Go to Menu > Advanced Application > Spanning Tree Protocol > RSTP. Check the "Active" box. Activate port 10, and click "Apply".

Rapid Spanning Tree P	rotocol	Ste
Active		
Bridge Priority	327	768 🔻
Hello Time	2	Seconds
MAX Age	20	Seconds
Forwarding Delay	15	Seconds

Port	Active	Edge	Roof Guard	Priority	Path Cost
•					
1				128	4
2				128	4
3				128	4
4				128	4
5				128	4
6				128	4
7				128	4
8				128	4
9				128	4
10	2			128	4

Apply Cancel



3.7.3 Test the Results

1 Verify the status of Customer Switch-A: Go to Menu > Advanced Application > Spanning Tree Protocol. The Root Bridge ID and the Our Bridge ID should be the same. This means that Customer Switch-A is the Root Bridge. Port 10 should be in FORWARDING state, and its Port Role is Designated Ports.

ridge	Root	Our Bridge
ridge ID	1000-a0e4cb7ef5a0	1000-a0e4cb7ef5a0
lello Time (second)	2	2
Nax Age (second)	20	20
orwarding Delay (second)	15	15
Cost to Bridge	0	
ort ID	0X0000	
opology Changed Times	1	
ime Since Last Change	0:09:50	

2 Verify the status of Customer Switch-B: Go to Menu > Advanced Application > Spanning Tree Protocol. Check the port status of Customer Switch-A. Port 10 should be the Root Port in FORWARDING state.

Spanning Tree Protocol Sta panning Tree Protocol: RSTP	TUS	Configuration RSTP MRSTP MST
Bridge	Root	Our Bridge
Bridge ID	1000-a0e4cb7ef5a0	8000-0019cb222222
Hello Time (second)	2	2
Max Age (second)	20	20
Forwarding Delay (second)	15	15
Cost to Bridge	4	
Port ID	0X800a	
Topology Changed Times	2	
Time Since Last Change	0:12:36	

Port	Port State	Port Role	Designated Bridge ID	Designated Port ID	Designated Cost	Root Guard State
10	FORWARDING	Root	1000-a0e4cb7ef5a0	0x800a	0	Forwarding



3.7.4 What Could Go Wrong

 Make sure you configure the same destination MAC address of Layer-2 Protocol Tunneling on all the edge switches.
 Otherwise the encapsulated packets cannot be recognized during the forwarding process between the edge switches.



Designing an IPTV Network

4.1 Introduction for IGMP

Before we begin designing an IPTV Network, there are 3 important concepts of Zyxel's IGMP (Internet Group Management Protocol) and IGMP Snooping that administrators should be aware of.

4.1.1 What are General Queries and Group Specific Queries?

General Query: The querier will send query messages to the multicast clients to learn which multicast groups still have active members within the network.

Group Specific Query: When the client leaves a multicast group and sends a leave group message, the querier will send this query message to learn if a particular group has any other active members on a downlink port.

4.1.2 What are IGMP Snooping Querier Modes?

There are 3 Querier Modes: Auto, Fixed and Edge.

Fixed: To have the Switch always use the port as an IGMP query port. Select this when you connect an IGMP multicast server to the port.

Edge: Prevents the switch from using the port as an IGMP query port. The Switch will not keep any record of an IGMP router being connected to this port. The switch does not forward IGMP join or leave packets to this port.

Auto: The port behaves as a Fixed port if the port receives any IGMP queries. The port behaves as an Edge port if the port receives no IGMP queries within a period of time.

4.1.3 What are the differences between IGMP Snooping fast/normal/immediate leave?

Fast leave:

In fast leave mode, the switch itself sends out an IGMP Group-Specific Query (GSQ) message right after receiving an IGMP leave message from a host on a port. This determines whether other hosts connected to the



port should remain in the specific multicast group. This helps speed up the leave process.

Normal leave:

In normal leave mode, when the Switch receives an IGMP leave message from a host on a port, it forwards the message to the multicast router. The multicast router then sends out an IGMP Group-Specific Query (GSQ) message to determine whether other hosts connected to the port should remain in the specific multicast group. The switch forwards the query message to all hosts connected to the port and waits for IGMP reports from hosts to update the forwarding table.

Immediate leave:

Select this option to set the Switch to remove this port from the multicast tree once the ports receive an IGMP leave message. Select this option if there is only one host connected to this port.



4.2 How to configure IGMP routing for multicast clients in a different LAN

The example shows administrators how to configure IGMP routing on the Zyxel Layer 3 switch. This is necessary when the multicast clients are in a different LAN or VLAN from the streaming server.




Figure 17 Configure IGMP routing for multicast clients in different VLAN

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50) and GS2210-48HP (Firmware Version: V4.30).



4.2.1 Configure Switch-1

- Configure the VLAN 10 on Switch-1. (Please refer to the topic:
 2.1 How to configure the switch to separate traffic between departments)
- 2 Configure the IGMP Snooping: Enter the web GUI and go to Menu > Advanced Application > Multicast > IPv4 Multicast > IGMP Snooping. Check the "Active" box and select Unknown Multicast Frame as Drop. Select the port 5 as Fixed. Click "Apply".

	IGMP Sr	noopin	9				IPv4 Mul	ticast Status	l	GMP Snooping VLAN	IGMP Filtering Profile
						Active					
			Querier								
IGMP 3	IGMP Snooping			Host Timeout	260)					
				802.1 p Priority	802.1 p Priority No-Change 🔻						
IGMP Filtering			Active								
Unknor	Unknown Multicast Frame				Flooding	۲	Drop				
Reserved Multicast Group			Flooding	0	Drop						
Port		Norm			Leave		Max Group Num.	Throttling		IGMP Filtering Profile	Mode
Port •	Immed.	Norm		0	Leave				7	IGMP Filtering Profile	e Mode
	Immed. Leave	Norm		0	Leave	Group Limited		Deny	7		Mode Auto
	Immed. Leave	Norm	al Leav	0		Group Limited	Num.	Deny Deny		Default •	Mode Auto V Auto V
•	Immed. Leave	Norm () ()	al Leave	0	200	Group Limited	Num.	Deny Deny Deny	-	Default • Default •	Auto V Auto V Auto V
• 1 2	Immed. Leave	Norm	al Leav 4000 4000	0	200 200	Group Limited	Num. 0 0	Deny Deny Deny Deny	•	Default Default Default	Auto V Auto V Auto V Auto V



4.2.2 Configure Switch-2

- 1 Configure the VLAN 10 and VLAN 20 on Switch-2. Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments.
- 2 Configure the IP addresses for Switch on BOTH VLAN 10 and VLAN 20 as shown in the figure. Please refer to the topic: 1.1 How to change the switch management IP address to avoid accessing the wrong device.
- 3 Configure the IGMP Routing: Enter the web GUI and go to Menu > IP Application > IGMP. Check the "Active" box and select VLAN 10 and VLAN 20 as IGMP-v2. Select "Unknown Multicast Frame" as "Drop". Click "Apply".

IGMP		
Active		
Unknown Multicast Frame	🔘 Flooding 💿 Drop	
Index	Network	Version
•	-	None 🔻
1	192.168.1.1/24	None 🔻
2	192.168.10.1/24	IGMP-v2 ▼
3	192.169.20.1/24	IGMP-v2 ▼
	Apply Cancel	



4.2.3 Test the Result

- **1** Play the stream on Media Server using Multicast IP address 239.1.1.2.
- 2 Have PC send an IGMP join message for 239.1.1.2.
- **3** Go to Menu > Advanced Application > Multicast > IPv4 Multicast. PC connected to port 10 joins the Multicast Group-239.1.1.2.

IPv4 Multicast Status			Multicast Setup IGMP Snooping
Index	VID	Port	Multicast Group
1	10	.1	224.0.0.251
2	10	1	224.0.0.252
3	10	1	239.1.1.2
4	10	1	239.255.255.250



4.2.4 What Could Go Wrong

1 The Switch-2 (IGMP Router) must contain both VLAN of Media Server (VLAN 20) and PC (Client) (VLAN 10) so that the IGMP stream can route successfully. If the stream is not received by the Client, try to check the configuration of the VLAN.



4.3 How to configure IGMP Snooping for multicast clients in the same LAN

The example shows administrators how to configure IGMP Snooping for multicast clients and steaming servers in the same VLAN. When Media Server multicasts the stream, IGMP snooping allows the switch to learn multicast groups without having the user to manually configure the each switch. This prevents the switch from flooding multicast streams on ports that have no members for these multicast addresses.




Figure 18 Configure IGMP Snooping for multicast clients in the same LAN

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).



4.3.1 Configure Switch

- 1 Configure the VLAN 10 on Switch. (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments).
- 2 Configure the IGMP Snooping: Enter the web GUI and go to Menu > Advanced Application > Multicast > IPv4 Multicast > IGMP Snooping. Check the "Active" box and select Unknown Multicast Frame as Drop. Check Querier. Click "Apply".

IGMP Snooping		IPv4 Multicast Status	IGMP Snooping VLAN	IGMP Filtering Profile
	Active			
	Querier			
IGMP Snooping	Host Timeout	260		
	802.1 p Priority	No-Change 🔻		
IGMP Filtering	Active			
Unknown Multicast Frame	Flooding	Drop		
Reserved Multicast Group	Flooding	Drop		



4.3.2 Test the Result

- **1** Play the stream on Media Server using Multicast IP address 239.1.1.1.
- 2 Have PC send an IGMP join message for 239.1.1.1.
- 3 Go to Menu > Advanced Application > Multicast > IPv4 Multicast. PC connected to port 2 joins Multicast Group-239.1.1.1.

Index	MUS	Port	Mullia and Crown
index	VID	Pon	Multicast Group
1	10	1	224.0.0.251
2	10	1	224.0.0.252
3	10	1	239.255.255.250
4	10	2	224.0.0.251
5	10	2	224.0.0.252
6	10	2	239.1.1.1
7	10	2	239.255.255.250



Network Security

5.1 How to configure the port security to limit the number of connected devices

The example shows administrators how to configure port security to limit the number of connected devices. In a real environment, port security controls the number of users connecting to a server.




Figure 19 Configure the port security to limit the number of connected devices

ϔ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50) and GS2210-48HP (Firmware Version: V4.30).



5.1.1 Configure Switch-1

 Enter web GUI and go to Menu > Advanced Application > Port Security. Check port 3 and set the "Limited Number of Learned MAC Address" to 2.

Active				
Port	Active	Address Learning	Limited Number of Learned MAC	Address
•				
1			0	
2			0	
3		v	2	

∛ Note:

The Zyxel switch sends Link Layer Discovery Protocol (LLDP) packets every period of time by default. If Switch-2 does not support LLDP or is disabled, Limited Number of Learned MAC Address can be set to 1. Otherwise, set this to 2.



5.1.2 Test the Result

1 PC-1 can ping Server successfully.

C:\Users\User>ping 192.168.1.150 Pinging 192.168.1.150 with 32 bytes of data: Reply from 192.168.1.150: bytes=32 time=766ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128 Ping statistics for 192.168.1.150: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 0ms, Maximum = 766ms, Average = 191ms

- **2** Connect PC-2 to port 2.
- **3** PC-2 cannot ping Server.

C:\Users\User>ping 192.168.1.150
Pinging 192.168.1.150 with 32 bytes of data:
Reply from 192.168.1.200: Destination host unreachable.
Reply from 192.168.1.200: Destination host unreachable. Reply from 192.168.1.200: Destination host unreachable.
Reply from 192.168.1.200: Destination host unreachable.
Ping statistics for 192.168.1.150: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

4 Access Switch-1 web GUI. Go to Menu > Management > MAC Table > Search. The MAC Address Table should show MAC address of PC-1 (and Switch-2), but not the MAC address of PC-2.

Index	MAC Address	VID	Port	Туре
1	00:23:54:2e:98:b9	1	1	Dynamic
2	00:e0:4c:00:00:03	1	3	Dynamic
3	42:73:74:20:55:56	1	CPU	Static
4	f0:de:f1:91:74:f8	1	3	Dynamic



5.1.3 What Could Go Wrong

 The MAC address of Switch-2 will also be learned in Switch-1 MAC address table. Therefore, remember to consider Switch-2's MAC address when setting the number of Limited Number of Learned MAC Address.



5.2 How to configure MAC filter to block unwanted traffic

The example shows administrators how to configure MAC filter to block unwanted traffic. In this example, Switch-1 will block traffic based on which device sends the packet or which device receives the packet.




Figure 20 Configure MAC filter to block unwanted traffic

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50) and GS2210-48HP (Firmware Version: V4.30).



5.2.1 Configure Switch-1

1 Enter web GUI and go to Menu > Advanced Application > Filtering. Check the "Active" box and set the filter Name. Choose the Action as "Discard source". Key in the MAC you want to block and the VID. Click "Add".

Filtering	
Active	
Name	MACfilter
Action	C Discard source
Action	Discard destination
MAC	00:1E:33:27:04:93
VID	1

∛ Note:

Use **Discard source** to drop traffic sent **by** the device with the configured MAC entry.

Use **Discard destination** to drop traffic sent to the device with the configured MAC entry.



5.2.2 Test the Result

- PC-1 (with MAC address 00:1E:33:27:04:93) fails to ping Server. C:\Users\User>ping 192.168.1.150 Pinging 192.168.1.150 with 32 bytes of data: Reply from 192.168.1.100: Destination host unreachable. Ping statistics for 192.168.1.150: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
- 2 PC-2 can ping Server successfully.

C:\Users\User>ping 192.168.1.150				
Pinging 192.168.1.150 with 32 bytes of data:				
Reply from 192.168.1.150: bytes=32 time=766ms TTL=128				
Reply from 192.168.1.150: bytes=32 time<1ms TTL=128				
Reply from 192.168.1.150: bytes=32 time<1ms TTL=128				
Reply from 192.168.1.150: bytes=32 time<1ms TTL=128				
Ping statistics for 192.168.1.150:				
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),				
Approximate round trip times in milli-seconds:				
Minimum = Oms, Maximum = 766ms, Average = 191ms				



5.2.3 What Could Go Wrong

1 The MAC address set on Switch-1 should be identical to the MAC address of PC-1 so that the traffic can be blocked successfully.



5.3 How to configure the switch to prevent IP scanning

In this example, we will use **Anti-ARP Scan** to prevent attackers from identifying all network devices in the local area network. ARP Scanning is a method by which attackers send multiple ARP request packets in a very short period of time to flood across the entire broadcast domain.




Figure 21 IP Scanning from Wired and Wireless Devices

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. The Access Point in this section uses the default Radio and SSID Profile. For this section, we will refer to "Zenmap" as the IP Scanning tool. All UI displayed in this article are taken from the XGS4600 series switch.



5.3.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Go to Advance Application > Anti-Arpscan > Configure. Check the Active box and configure the uplink port (port 24) as "Trusted" state. Click Apply.

Anti-Arpscan Configure				<u>Status</u>
Active				
Port Threshold	100	pps		
Host Threshold	10	pps		
21			Untrusted T	
22			Untrusted T	
23			Untrusted 🔻	
24			Trusted 🔻	
25			Untrusted T	

-Optional-

3 Go to **Advance Application > Errdisable > Errdisable Recovery**. Check the Active box and anti-arpscan box. Click **Apply**.

Errdisable Recove	ny	<u>Errdisable</u>
Active	✓	
Reason	Timer Status	Interval
•		
loopguard		300
ARP		300
BPDU		300
IGMP		300
anti-arpscan		300
bpduguard		300
zuld		300
	Apply Cancel	
L		



5.3.2 Test the Result

- 1 Download and install an IP Scanning software into Host-A and Host-C.
- 2 Connect Host-A and Host-B via the Wireless Access Point.
- **3** Host-A should initiate a scan for IP address 192.168.1.1 to 192.168.1.20.

۲	Zenmap	_ 🗆 🗙
Sc <u>a</u> n <u>T</u> ools <u>P</u> rofile <u>H</u> elp		
Target: 192.168.1.1-20	✓ Profile: Intense scan ✓	Scan Cancel
Command: nmap -T4 -A -	/ 192.168.1.1-20	
Hosts Services	Nmap Output Ports / Hosts Topology Host Details Scar	15
OS 4 Host		✓
Filter Hosts		

4 Host-A should no longer be able to reach the USG.

C:\Windows\system32>ping	192.168.1.1	
Pinging 192.168.1.1 with Request timed out.	32 bytes of	data:
Request timed out.		
Reply from 192.168.1.30:	Destination	host unreachable.
Reply from 192.168.1.30:	Destination	host unreachable.
Ping statistics for 192.1	68.1.1:	
Packets: Sent = 4, Re	ceived = 2,	Lost = 2 (50% loss),

5 Access the Switch's Web GUI. Go to Advance Application > Anti-Arpscan > Host Status. An entry for Host-A should appear with an "Err-Disable" state.



Filtered hos	t				
Index	Host IP	MAC	VLAN	Port	State
1	192.168.1.30	74:d4:35:f4:6b:4e	1	1	Err-Disable
recove	sable Recove	ry has been coi rdisable Recover wards.	•		•

- 6 Host-B should still be able to reach the USG.
- 7 Connect Host-C to the Switch.
- 8 Host-C should perform a quick scan for IP address 192.168.1.1 to 192.168.1.100.

۹۶	Zenmap – 🗆 🗙
Sc <u>a</u> n <u>T</u> ools <u>P</u> rofile <u>H</u> el	p
Target: 192.168.1.1-100	✓ Profile: Quick scan ✓ Scan Cancel
Command: nmap -T4 -F 1	92.168.1.1-100
Hosts Services	Nmap Output Ports / Hosts Topology Host Details Scans
OS ◀ Host ▲	nmap - T4 - F 192.168.1.1-101 🗸 📱 Details
 192.168.1.1 192.168.1.2 192.168.1.30 	32768/tcp unknown filenet-tms 49152/tcp unknown unknown 49153/tcp unknown unknown 49154/tcp unknown unknown 49155/tcp unknown unknown 49156/tcp unknown unknown 49157/tcp unknown unknown Mmap done: 101 IP addresses (3 hosts up) scanned in
Filter Hosts	2.88 seconds

9 Host-C should no longer be able to reach the USG.

```
C: Windows\system32>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Request timed out.

Request timed out.

Reply from 192.168.1.30: Destination host unreachable.

Reply from 192.168.1.30: Destination host unreachable.

Ping statistics for 192.168.1.1:

Packets: Sent = 4, Received = 2, Lost = 2 (50% loss),
```



10 Access the Switch's Web GUI. Go to Advance Application > Anti-Arpscan. Port 2 should now be in an Err-disabled state.

Anti-Arpscan Status Anti-Arpscan is enabled		Host Status Trust Host Configure
Port	Trusted	State
1	No	Forwarding
2	No	Err-disable
3	No	Forwarding
4	No	Forwarding
5	No	Forwarding

∛ Note:

If Errdisable Recovery has been configured, Port 2 state should change to forwarding after the Errdisable Recovery Interval. Host-C will be able to reach the USG, afterwards.



5.3.3 What Could Go Wrong?


- 1 If access to servers or the local gateway is no longer possible after enabling Anti-Arpscan, make sure that only ports directly connected to hosts or Wireless Access Points are "untrusted". Ports to servers and the local gateway should be "trusted".
- 2 If all hosts connected through a Wireless Access Point can no longer reach the local gateway, check whether the port to the Wireless Access Point has changed to the err-disable state in Advance Application > Anti-Arpscan. If so, consider increasing the Port Threshold in Advance Application > Anti-Arpscan > Configure.

010105



5.4 How to Configure the Switch and RADIUS Server to Provide Network Access through 802.1x Port Authentication

This example will instruct the administrator on how to configure the switch to provide access to machines that provides valid user credentials. With 802.1x Port Authentication, the organization can ensure that only authorized personnel can access core network resources.



Authorized Users

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. The authentication server used in this example is FreeRADIUS running in Ubuntu server. All UI displayed in this article are taken from the XGS4600 series switch.



5.4.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Go to Advance Application > AAA > RADIUS Server Setup. Configure the RADIUS server's IP address and set the shared secret. Click Apply.

RADI Authenticati	IUS Server Setup on Server			AAA
Mode Timeout		index-priority	y V	
Integer		00 3	econas	
Index	IP Address	UDP Port	Shared Secret	Delete
1	192.168.1.100 0.0.0.0	1812	zyxel1234	
Y Not The sho profile.	ared secret must	match the secr	et of your RADIUS serve	er's client

3 Go to Advance Application > Port Authentication > 802.1x. Check the 802.1x Active box as well as for all ports connected to end devices. Do not check active box of ports connected to either the USG, RADIUS-Server, or Private-Server.

802.	.lx					Port Authentic	ation <u>Guest Vlan</u>
Active			v				
Port	Active	Max-Req	Reauth	Reauth-perioc secs	l Quiet-perioo secs	Tx-period secs	Supp-Timeout secs
•	1		On 🔻				
1	4	2	On 🔻	3600	60	30	30
2	1	2	On 🔻	3600	60	30	30
3	1	2	On 🔻	3600	60	30	30
4	1	2	On 🔻	3600	60	30	30
5	A	2	On 🔻	3600	60	30	30
30		2	On 🔻	3600	60	30	30
31		2	On 🔻	3600	60	30	30
32		2	On 🔻	3600	60	30	30
				Apply Cancel			



5.4.2 Configuration in the RADIUS-Server

1 Edit the client profile in **/etc/freeradius/clients.conf**. Save the file and exit.

<pre>client 192.168.1.2 { secret = zyxel1234 shortname = Switch nastype = other }</pre>
َلُا Note:
The client IP address and secret must match the management IP and shared secret of the Switch.

2 Add the following user profiles in **/etc/freeradius/users**. Save the file and exit.

User-A	Cleartext-Password := "zyxeluserA" Service-Type = Administrative-User
User-B	Cleartext-Password := "zyxeluserB" Service-Type = Administrative-User

3 Restart FreeRADIUS service.

root@dhcppc68:/etc/freeradius# stop freeradius stop: Unknown instance: root@dhcppc68:/etc/freeradius# start freeradius freeradius start/running, process 8800 root@dhcppc68:/etc/freeradius#



5.4.3 Test the Result

- 1 Access User-A, User-B, and Guest device.
- 2 If using Windows OS, click the **Start button** and type **services.msc** into the search box.
- 3 In the Services window, locate the service named Wired AutoConfig. Make sure the service status is "Started".

File Action View	v Help 🟟 🐟 🛛 🕜 📻 🕨 🔳 🕕 🕪					
Services (Local)	Services (Local)					
	Wired AutoConfig	Name	Description	Status	Startup Type	
	Stop the service Restart the service	Windows Time Windows Update WinHTTP Web Pr	Maintains d Enables the WinHTTP i		Manual Automatic (D Manual	
	Description: The Wired AutoConfig (DOT3SVC) service is responsible for performing IEEE 802.1X authentication on	Wired AutoConfig WLAN AutoConfig WMI Performance Workstation		Started	Manual Automatic Manual Automatic	I
	Extended (Standard /	•	III		•	

- 4 Right-click on your network adapter and select Properties.
- 5 Click on the Authentication tab and check "Enable IEEE 802.1X authentication". Make sure that the network authentication method is Microsoft: Protected EAP (PEAP)




Local Area Connection Properties			
Networking Authentication Sharing			
Select this option to provide authenticated network access for this Ethemet adapter.			
Choose a network authentication method:			
Microsoft: Protected EAP (PEAP) Settings			
Remember my credentials for this connection each time I'm logged on			
Fallback to unauthorized network access			
Additional Settings			
OK Cancel			

6 Click on Additional Settings, select Specify authentication mode and specify User authentication.

Advanced settings	X
802.1X settings	
Specify authentication mode	
User authentication Save creden	itials
Delete credentials for all users	
Enable single sign on for this network	
Perform immediately before user logon	
Perform immediately after user logon	
Maximum delay (seconds): 10	×
✓ Allow additional dialogs to be displayed during singli sign on	e
This network uses separate virtual LANs for machin and user authentication	ie
OK	Cancel

7 Connect User-A device to the Switch. User-A should show an "Additional information is needed to connect to this network." pop-up message.





8 Enter the username (**User-A**) and password (**zyxeluserA**) which must be consistent with the RADIUS-Server's user profile settings.

Network A	uthentication	
Please enter us	er credentials	
	User-A	
		OK Cancel

- **9** Devices using User-A and User-B credentials can communicate with **USG** and **Private-Server**.
- 10 Connect User-A device to the Switch. User-A should show an "Additional information is needed to connect to this network." pop-up message.
- 11 Enter the username (Guest) and a random password.

Windows Security	
Network Au Please enter us	uthentication ser credentials
	Guest
	OK Cancel

12 Device using Guest credentials cannot communicate with USG and Private-Server.



5.4.4 What May Go Wrong?

- 1 If the Switch does not allow access to users that submitted the correct credentials, the following problems may have occurred:
 - a. Usernames and passwords are case-sensitive. Make sure that the user input the correct lower-case or upper-case characters.
 - b. The RADIUS-server is unreachable. The Switch should be able to ping the RADIUS-Server at all times. Make sure network settings were configured correctly between Switch and RADIUS-Server.
 - c. The shared secret between the Switch and RADIUS-Server is not identical.



5.5 How to configure the switch to send unauthorized users in a guest VLAN

The example shows administrators how to use Guest VLAN for users that fails or used an invalid user credential during 802.1x port authentication. In a real application, we may need to allow guests to access the USG so that they can access the Internet, but still isolated from Private-Server. On the contrary, we have to allow the users with valid credentials to only access the Private-Server.




Figure 23 Configure the switch to send unauthorized user in Guest VLAN

€ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).



5.5.1 Configure 802.1x Port Authentication on the Switch

1 Configure 802.1x on all towards users. Do not enable Port Authentication on ports to the USG, RADIUS-Server, and Private-Server. To configure Port Authentication, please refer to the topic: 5.4 How to Configure the Switch and RADIUS Server to Provide Network Access through 802.1x Port Authentication.

5.5.2 Configure VLAN for Guest VLAN

Configure the VLAN for Guest VLAN (VLAN 100) on Switch.
 VLAN 100: Set fixed port: 1, 2, 3, 30; untagged port: 1, 2, 3, 30; forbidden port: 31, 32; port 30: pvid=100. VLAN 1: Set forbidden port: 30. For isolating VLAN 1 and 100, please refer to the topic:
 2.1 How to configure the switch to separate traffic between departments.

5.5.3 Configure Guest VLAN for Failed Authentication


 Go to Menu > Advanced Application > Port Authentication > 802.1x > Guest Vlan. Activate the Guest Vlan on port 1-3 and type the guest Vlan as 100. Press "Apply".

			<u>802.1x</u>
Active	Guest Vlan	Host-mode	Multi-Secure Num
		Multi-Host 🔻	
	100	Multi-Host 🔹	1
	100	Multi-Host 🔹	1
 Image: A start of the start of	100	Multi-Host 🔻	1
	Active	□ 100	Multi-Host Image: Multi-Host Image: Multi-Host Image: Multi-Host Image: Multi-Host

5.5.4 Configure the RadiusServer

1 Edit the client profile in **/etc/freeradius/clients.conf**. Save the file and exit.





∛ Note:

The client IP address and secret must match the management IP and shared secret of the Switch.

2 Add the following user profiles in **/etc/freeradius/users**. Save the file and exit.


user	Cleartest-Password :="user1234"
	Service-Type = Administrative-User

3 Restart FreeRADIUS service.

```
root@dhcppc68:/etc/freeradius# stop freeradius
stop: Unknown instance:
root@dhcppc68:/etc/freeradius# start freeradius
freeradius start/running, process 8800
```

5.5.5 Configure the setting on User-A, User-B and Guest

 In the Services window, locate the service named Wired AutoConfig. Make sure the service status is "Started".



2 Right-click on your network adapter and select **Properties**. Click on the Authentication tab and check "**Enable IEEE**



802.1X authentication". Make sure that the network authentication method is "Microsoft: Protected EAP (PEAP)".

Uccal Area Connection Properties
Networking Authentication Sharing
Select this option to provide authenticated network access for this Ethemet adapter. Image: The select state is a select state in the
Remember my credentials for this connection each time I'm logged on
Fallback to unauthorized network access
Additional Settings
OK Cancel

3 Click on Additional Settings, select Specify authentication mode and specify User authentication.

Advanced settings
802. 1X settings
Specify authentication mode
User authentication Save gredentials
Delete credentials for all users
Enable single sign on for this network
Perform immediately before user logon
Perform immediately after user logon
Maximum delay (seconds):
✓ Allow additional dialogs to be displayed during single sign on
This network uses separate <u>v</u> irtual LANs for machine and user authentication
OK Cancel



5.5.6 Test the Result

1 Disconnect and connect the PC with Switch. PC should show an "Additional information is needed to connect to this network." pop-up message.



2 Enter the username (**User-A**) and password (**zyxeluserA**) which must be consistent with the RADIUS-Server's user profile settings.

Windows Security	
	thentication
Please enter use	er credentials
	User-A
	OK Cancel

- **3** Devices using User-A and User-B credentials can communicate with Private-Server.
- 4 Connect User-A device to the Switch. User-A should show an "Additional information is needed to connect to this network." pop-up message.
- 5 Enter the username (Guest) and a random password.
- **6** Device using Guest credentials cannot communicate with Private-Server, but it can communicate with USG.
- 7 Check the MAC table of the Switch. The device of users with wrong credentials are assigned to VLAN 100. (Menu > Management > MAC Table > Search)



Index	MAC Address	VID	Port	Туре
1	00:1e:33:27:04:93	100	3	Dynamic
2	20:6a:8a:39:fe:a9	1	12	Dynamic
3	3c:97:0e:30:0e:b8	1	12	Dynamic
4	42:73:74:20:55:56	1	CPU	Static
5	42:73:74:20:55:56	100	CPU	Static
6	60:31:97:71:6d:15	1	12	Dynamic
7	60:31:97:71:6d:21	1	12	Dynamic
8	74:d4:35:f4:6b:4e	1	12	Dynamic
9	84:ef:18:95:08:e4	1	12	Dynamic
10	a0:8c:fd:1c:c0:b1	1	12	Dynamic
11	b8:ec:a3:0f:cf:9f	1	12	Dynamic
12	c8:6c:87:9f:51:f0	_1_	12	Dynamic
13	f0:de:f1:91:74:f8	100	1	Dynamic
14	fc:3f:db:39:66:80	1	12	Dynamic

5.5.7 What Could Go Wrong

- 1 If the PC doesn't pop up the authentication message after connecting the PC to the switch:
- a. Try to use the Switch to ping Radius-Server. The Switch should be able to ping Radius-Server.
- b. Right-click on your network adapter and select Properties > Authentication > Additional settings. Uncheck the "Validate server certificate".

Protected EAP Properties
When connecting:
Validate server certificate
Connect to these servers:
Trusted <u>R</u> oot Certification Authorities:
AddTrust External CA Root
Baltimore CyberTrust Root
Class 3 Public Primary Certification Authority
Deutsche Telekom Root CA 2
DigiCert Assured ID Root CA DigiCert Global Root CA
DigiCert High Assurance EV Root CA
Do not prompt user to authorize new servers or trusted certification authorities.
cer dicadon addiondes.
Select Authentication Method:
Secured password (EAP-MSCHAP v2)
Enable East Reconnect
Enforce Network Access Protection
Disconnect if server does not present cryptobinding TLV
Enable Identity Privacy
OK Cancel

2 If the shared secret setting of Switch and PC does **NOT** match, the authentication will fail.




- 3 If the authentication is fine, but the PC cannot ping Server, please check 801.1X Port Authentication configurations. Do **NOT** activate the authentication on the uplink port (port 2, 3, and 12).
- 4 If devices sent to the Guest VLAN cannot reach the USG, make sure that the switch has created and configured the Guest VLAN in Advance Application > VLAN > VLAN Configuration > Static VLAN Setup.



5.6 How to Configure the Switch and RADIUS Server to Provide Network Access through Device MAC Address

This example will instruct the administrator on how to configure the switch to provide access to machines with specific MAC addresses. With MAC Authentication, the organization can ensure that only devices provided by the organization can access internal resources.



℃ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. The authentication server used in this example is FreeRADIUS running in Ubuntu server. All UI displayed in this article are taken from the XGS4600 series switch.



5.6.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Go to Advance Application > AAA > RADIUS Server Setup. Configure the RADIUS server's IP address and set the shared secret. Click Apply.

Mode		index-priority	/ •	
Timeout		30 s	econds	
			alsoned as such	Delete
Index	IP Address	UDP Port	Shared Secret	Delete
Index 1	IP Address 192.168.1.100	1812	zyxel1234	
Index 1 2				

The shared secret must match the secret of your RADIUS server's client profile.

3 Go to Advance Application > Port Authentication > MAC Authentication. Check the MAC Authentication Active box as well as for access ports. Do not check the active box of ports connected to either the USG, RADIUS-Server, or Private-Server.

MAC Auther	ntication			Port Authentication
Active				
Name Prefix		Acces	ssO1-	
Password		zyxel		
Timeout		0		
Port	Active		Trusted-VLA	N List
•				
1	s.			
2	√			
3	√			
4				
5	√			

www.zyxel.com



Apply Cancel						
32						
31						
30						



5.6.2 Configuration in the RADIUS-Server

1 Edit the client profile in **/etc/freeradius/clients.conf**. Save the file and exit.



∛ Note:

The client IP address and secret must match the management IP and shared secret of the Switch.

2 Add the following user profiles in /etc/freeradius/users. Username format should be <Name Prefix><MAC Address of your device>. Save the file and exit.

Access01-00-0C-29-AA-AA-AA	Cleartext-Password	:=	"zyxe1"
Access01-00-0C-29-BB-BB-BB	Cleartext-Password	:=	"zyxe1"

3 Restart FreeRADIUS service.

root@dhcppc68:/etc/freeradius# stop freeradius stop: Unknown instance: root@dhcppc68:/etc/freeradius# start freeradius freeradius start/running, process 8800 root@dhcppc68:/etc/freeradius#



5.6.3 Test the Result

- 1 Connect PC-A, PC-B, and PC-Guest to the Switch.
- **2** PC-A and PC-B should be able to reach the USG and Private-Server.
- **3** PC-Guest should not be able to reach the USG and Private-Server.



5.6.4 What Could Go Wrong?

- 1 If the Switch does not allow access to authorized devices:
 - a. The RADIUS-Server's user profile must use all uppercase characters of the device's MAC Address separated by dashes (-) instead of colons (:).
 - b. Machines, like laptops or notebooks have more than one MAC addresses (LAN, Wireless, etc). Make sure that the correct MAC address is used in the RADIUS-Server's user profile.
- 2 If the Switch still does not allow access to authorized devices after correcting the Switch or RADIUS-Server configurations, wait for a few minutes before trying again. This is determined by the MAC Authentication's timeout value, where the default time a devices is re-validated is 300 seonds.



5.7 How to configure the switch to prevent ARP spoofing

This example will instruct the administrator on how to configure the switch to protect the network from attackers using the same IP Addresses of core network components (ex. servers or gateways). ARP Spoofing is a type of attack that can cause either denial of services or an unwanted man-in-the-middle receiving sensitive information. IP Source Guard's ARP Inspection forces all clients connected to access ports to use the IP addresses provided by the administrator's dedicated DHCP server.




Figure 25 Attacker Using the Same IP Address as the USG

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. All UI displayed in this article are taken from the XGS4600 series switch.



5.7.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Configure DHCP Snooping (Refer to section 5.6.1).

Y Note: DHCP Snooping must be enabled before configuring ARP Inspection.

3 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > ARP Inspection > Configure. Check the Active box to globally enable ARP Inspection.

ARP Inspection Configure	ARP Inspection Port VLAN
Active	

4 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > ARP Inspection > Configure > Port. Set all access ports as untrusted ports. Ports to the USG or other network components should be trusted ports. Click Apply.

ARP Insp	ection Port Configure		<u>Configure</u>
Port	Trusted State	Rate (pps)	Limit Burst interval (seconds)
•	Untrusted 🔻		
1	Untrusted 🔻	15	1
2	Untrusted 🔻	15	1
3	Untrusted 🔻	15	1
4	Untrusted 🔻	15	1
5	Untrusted 🔻	15	1
30	Trusted 🔻	15	1
31	Trusted 🔻	15	1
32	Trusted 🔻	15	1
		Apply Cancel	

5 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > ARP Inspection > Configure > VLAN. Input the Start VID and End VID. Make sure that the PVID of the access ports are included in this range. Click Apply.



ARP Inspection VLAN Configure			<u>Configure</u>
VLAN	Start VID 1	End VID 5	
	Apply		

6 After inputting the VID range, a list of VID should appear below. Select **Yes** for the access ports' VLAN. Click **Apply**.

VID	Enabled	Log
•	No 🔻	None 🔻
1	Yes 🔻	Deny 🔻
2	No 🔻	Deny 🔻
3	No 🔻	Deny 🔻
4	No 🔻	Deny 🔻
5	No 🔻	Deny 🔻
	Apply Cancel	



5.7.2 Test the Result

- Connect a device using dynamic IP address in one of the Switch's access ports. This device should be able to communicate with the USG.
- 2 After the device has successfully received an IP address, access the Switch's web GUI. Go to Advance Application > IP Source Guard > IPv4 Source. An entry should appear in the IP Source Guard Table.

I	P Source Guard		IPSG Static	Binding DHCP Sr	nooping	ARP Inspection
Index	MAC Address	IP Address	Lease	Туре	VID	Port
1	20:6a:8a:39:fe:a9	192.168.1.30	2d23h59m40s	dhcp-snooping	1	1

3 Connect another device using a static IP address in one of the Switch's other access port. In this example, the device will spoof the USG's IP address "192.168.1.1". This device will not be able to communicate with any other device across the Switch.



5.7.3 What Could Go Wrong?

- 1 If the devices in the Local Network cannot reach the USG, Make sure that DHCP Snooping is configured on the Switch, first.
- 2 If the devices in the Local Network still cannot reach the USG after configuring and enabling DHCP Snooping, wait for a few minutes before attempting to reach the USG again. ARP Inspection sends the device's MAC address into a filter table. This device must wait until the entry expires, indicated by the "Expiry (sec)" column.

	RP Inspection Status ber of filters = 1			<u>IPv4 SG</u> <u>VL</u>	AN Status Log Statu	<u>s</u> <u>Configure</u>
Index	MAC Address	VID	Port	Expiry (sec)	Reason	
1	20:6a:8a:39:fe:a9	1	4	284	MAC+VLAN	
			Delete	Cancel		

- 3 If some of the devices are not able to reach the USG, the following problems may have occurred:
 - a. Make sure that the port connected to the USG or other internal devices are trusted ports.
 - b. Make sure that all the clients in the network renews their DHCP configurations incase the Switch has undergone reboot.
 - c. Make sure that the DHCP server's pool has not run out of IP addresses.



5.8 How to Configure the Switch to Protect Against Rogue DHCP Servers

This example will instruct the administrator on how to configure the switch to protect the network from attackers sending false IP configurations to clients. DHCP Snooping blocks DHCP offers coming from an untrusted port. Untrusted ports are usually ports connected to office workstations or publicly accessible jacks.




Figure 26 Fake DHCP Server Connected through Publicly Accessible Ports

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. All UI displayed in this article are taken from the XGS4600 series switch.



5.8.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Go to Go to Advance Application > VLAN > VLAN Configuration > Static VLAN Setup. For this example, all traffic entering access ports are sent to VLAN 1. VLAN 1 should be fixed and untagged for all access ports. Click Add.

Static VLAN				VLAN Configuration
ACTIVE		v		
Name		1		
VLAN Group ID		1		
VLAN Type		 Nor Priv 		
Association VLAN List				
Port		Control		Tagging
•		Fixed	v	🗹 Tx Tagging
1	Normal	Fixed	Forbidden	Tx Tagging
2	Normal	Fixed	Forbidden	🔲 Tx Tagging
3	Normal	Fixed	Forbidden	🔲 Tx Tagging
4	Normal	Fixed	Forbidden	🔲 Tx Tagging
5	Normal	Fixed	Forbidden	🔲 Tx Tagging
31	Normal	Fixed	O Forbidden	Tx Tagging
32	Normal	Fixed	O Forbidden	Tx Tagging
		Add Cana	cel Clear	

3 Go to Advance Application > VLAN > VLAN Configuration > VLAN Port Setup. Configure all access ports with PVID 1. Click Apply.

Port	Ingress Check	PVID	GVRP	Acceptable Fran	ne Type	VLAN Trunking	Isolation
•		1		All	•		
1		1		All	•		
2		1		All	•		
3		1		All	•		
4		1		All	•		
5		1		All	•		

4 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure. Check the Active box under DHCP Snooping Configure. Click Apply.



DHCP Snooping Configure	DH	ICP Snooping	<u>Port</u>	<u>VLAN</u>
Active	1			
DHCP Vlan	Disable			

5 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > Port. Set all access ports as untrusted ports. Ports to the USG or other network components should be trusted ports. Click Apply.

DHC	P Snooping Port Configure	<u>Configure</u>
Port	Server Trusted state	Rate (pps)
•	Untrusted 🔻	
1	Untrusted 🔻	0
2	Untrusted 🔻	0
3	Untrusted 🔻	0
4	Untrusted 🔻	0
5	Untrusted 🔻	0
30	Untrusted 🔻	0
31	Untrusted 🔻	0
32	Trusted 🔻	0
	Apply Cancel	

6 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > VLAN. Input the Start VID and End VID. Make sure that the PVID of the access ports are included in this range. Click Apply.

DHCP Snooping VLAN Configure			<u>Configure</u>	<u>Port</u>
Show VLAN	Start VID 1	End VID 5		
	Apply			



7 After inputting the VID range, a list of VID should appear below. Select **Yes** for the access ports' VLANs. Click **Apply**.

VID	Enabled	Option 82 Profile
•	No 🔻	•
1	Yes 🔻	•
2	No 🔻	T
3	No 🔻	T
4	No 🔻	T
5	No 🔻	v
	Apply Cancel	



5.8.2 Test the Result

1 Connect the Rogue-DHCP on one of the access ports. Create the following DHCP Pool on the LAN interface:

signing if Address	. 1/2.10.1.10
End IP Address	: 172.16.1.20

2 Connect DHCP clients on the other access ports. The clients should only be receiving IP Addresses provided by the USG.




5.8.3 What Could Go Wrong?

- 1 If the DHCP clients in the publicly accessible ports are using IP Addresses provided by the Rogue-DHCP:
 - a. Make sure that all ports connected to publicly accessible ports are an untrusted port in Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > Port.
 - b. Verify the PVID of the port to this DHCP client. Make sure that DHCP snooping is enabled for that VLAN in Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > VLAN.
- 2 If the DHCP clients in the publicly accessible ports are not able to receive IP Addresses provided by the real DHCP server:
 - a. Make sure that the port to the real DHCP is a trust port in Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > Port.
 - b. Make sure that both redundant ports are trusted ports in Advance Application > IP Source Guard > IPv4 Source Guard Setup > DHCP Snooping > Configure > Port when using a ring topology.



5.9 How to configure IPSG static binding for trusted network devices

This example will instruct the administrator on how to configure the switch to allow an administrator device to use a static IP address on the access port even while ARP Inspection in enabled. This allows the administrator device more freedom and take advantage of IP-specific policies configured on the network while non-administrative devices must still use IP addresses offered by the real DHCP server.



Connected on an Access Port

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. All UI displayed in this article are taken from the XGS4600 series switch.



5.9.1 Configuration in the Switch

- 1 Access the Switch's Web GUI.
- 2 Configure **ARP Inspection** (Refer to section **5.7.1**).

 \bigvee Note: DHCP Snooping and ARP Inspection must be enabled when applying Static Binding.

3 Go to Advance Application > IP Source Guard > IPv4 Source Guard Setup > Static Binding. Create a Static Binding entry using your device's MAC address and IP address. Input the VLAN and port that this device is allowed unrestricted access. Click Add.

Static Binding	
MAC Address	00:0c:29:aa:aa:ac
IP Address	192.168.1.10
VLAN	1
Port	Any
	Add Cancel Clear



5.9.2 Test the Result

1 Go to Advance Application > IP Source Guard. An entry with your device's MAC Address and IP Address should appear with "Static" Type and "Infinity" Lease in the IP Source Guard Table.

	IP Source Guard		IPSG Static B	inding DHCP S	inooping	ARP Inspection
Index	MAC Address	IP Address	Lease	Туре	VID	Port
1	00:0c:29:aa:aa:aa	192.168.1.10	infinity	static	1	

- 2 Configure your Admin-PC with the Static IP address. In this example, we use "192.168.1.10". Connect this to any access port. This PC should be able to reach the USG.
- 3 Configure another random PC with this Static IP address. In this example, we use "192.168.1.10". This random PC should be able to reach the USG (due to a different MAC address).



5.10 How to configure ACL to block unwanted traffic

The example shows administrators how to use ACL to block unwanted traffic. We can set different criteria to identify unwanted traffic. The example will use ACL to prevent only a single host in VLAN 10 from accessing the Server.




Figure 21 Configure ACL to block unwanted traffic

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).



5.10.1 Configure VLAN and Route Traffic

- 1 Configure the VLAN setting (VLAN 10 and VLAN 20) on Switch (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments).
- 2 Configure the VLAN IP interfaces on Switch (Please refer to the topic: 2.2 How to configure the switch to route traffic across VLANs)

5.10.2 Configure the Classifier

 Set up the Classifier: Go to Menu > Advanced Application > Classifier > Classifier Configuration. Set up Classifier: For VLAN 20.

₩ Note:

For more details about ACL, please refer to topic: **3.5 How to configure ACL to rate limit VLAN traffic**.



2 The Classifier of VLAN 20: Check the "Active" box and key in the classifier Name. Set Layer 2 > VLAN as 20 and Layer 3 > Destination as 192.168.1.150/32. Press "Add".

Classifier	r Configuration	Classifier Status Classifier Global Setting
Active		
Name	VLAN20	
Weight	32767	
	VLAN	VLAN Any 20 Inner VLAN Any
	Priority	Priority Any 0 ▼ Inner Priority Any 0 ▼ O ▼ O ▼ O ▼ O ▼ O ▼ O ▼ O ▼ O ▼
Layer 2	Ethernet Type	All (Hex)
	Source	Any MAC Address MAC /Mask
	Destination	 Any MAC Address MAC /Mask
	IP Packet Length	Any To Bytes
	DSCP	IPv4 • Any IPv6 • Any
	Precedence	Any
Layer 3	ToS	 Any
	IP Protocol	All Chers (Dec)
	IPv6 Next Header	Others (Dec)
	Source	IP Address / Address Prefix /
	Destination	IP Address / Address Prefix 192.168.1.150 / 32



5.10.3 Configure the Policy Rule

 Set up the Policy Rule: Go to Menu > Advanced Application > Policy Rule. The policy rule of VLAN 20: Check the "Active" and key in the Policy Rule Name. Select the Classifier in VLAN 20 (VLAN20). Set up the action to do if match this Classifier: Action > Forwarding > Discard the packet. Press "Add".

Policy	
Active	
Name	Policy_VLAN20
Classifier(s)	VLAN20

	Forwarding	
	No change	
L	Discard the packet	
	Do not drop the matching	g frame previously marked for dropping


www.zyxel.com



5.10.4 Test the Result

1 PC-1 can ping Server successfully.
C:\Users\User>ping 192.168.1.150
Pinging 192.168.1.150 with 32 bytes of data: Reply from 192.168.1.150: bytes=32 time=766ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128 Reply from 192.168.1.150: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.1.150: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 0ms, Maximum = 766ms, Average = 191ms

2 Due to the ACL setting, the PC-2 (VLAN 20) cannot ping Server successfully.





5.10.5 What Could Go Wrong

- 1 When setting up the Classifier, remember to consider both source and destination. In the example, if we only created a policy rule for source VLAN 20, but didn't create the policy rule for destination IP (Server IP: 192.168.1.150), the switch will block all the traffic from VLAN 20 no matter where the destination is.
- 2 Go to Menu > Advanced Application > Classifier. Check "Count". If the traffic matches the classifier, the Match Count for this classifier should be increasing every time the web page refreshes.


Cla	ssifier Con	iguration			Classifier Status Classifier Global Setting
Active	ø				
Name	VLA	N20			
Weight	327	67			
Log					
Count					
(Classifier St	latus			Classifier Configuration
Index	Active	Weight	Name	Match Count	Rule
1	Yes	32767	VLAN20	4	vlan 20; DestIP = 192.168.1.150/32; count;



5.11 How to use ACL to mirror traffic of a specific criteria

The port mirroring feature allows user to duplicate a traffic flow to the monitor port in order to examine/monitor the traffic from the monitor port without interference. It's useful for troubleshooting or scenarios involving supervisory control.

However, there are some cases that monitor port somehow receives numbers of various traffic when mirrored port is the up/down link port between devices. See the example below:





Let's say there are numerous switches and clients under switch 1 in the network.

In case that PC 1 is the monitor PC, and the goal is to monitor the communication between PC2 and the internet.

In general, port 1 will be set as the monitor port and port 9 should be the mirrored port with "both" directions.

Mirroring		
Active		
Monitor Po <mark>rt</mark>	1	
Port	Mirrored	Direction
•		Ingress 🔻
1		Ingress 🔻
2		Ingress 🔻
3		Ingress 🔻
4		Ingress 🔻
5		Ingress 🔻
6		Ingress 🔻
7		Ingress 🔻
8		Ingress 🔻
9		Both 🔻
10		Inaress 🔻

The approach is intuitive but it sometimes leads to a large amount of mirrored packets since port 9 of switch 1 is the aggregated uplink port to internet in the topology, all the downlink traffic will be converged. It's inconvenient and troublesome to sort out the particular traffic to/from PC2 among an overload of miscellaneous info in the mirrored traffic.

In the following content, it contains a detailed procedure "filtering" the mirrored packets by implementing ACL mirroring in order to monitor traffic of a specific criteria.

∛ Note:

All network addresses and subnet masks are used as examples in this article. Please replace them with your actual network configuration.



5.11.1 Configuration of ACL

- 1 Access the web GUI of the Switch-1.
- 2 Go to Advanced Application > Mirroring. Activate and set port 1 as the Monitor Port.

Mirroring		
Active		
Monitor Port	1.	

Port	Mirrored	Direction
•		Ingress 🔻
1		Ingress 🔻
2		Ingress 🔻
3		Ingress 🔻
4		Ingress 🔻
5		Ingress 🔻
6		Ingress 🔻
7		Ingress 🔻
8		Ingress 🔻
9		Ingress 🔻
10		Ingress 🔻



3 Go to Advanced Application > Classifier > Classifier Configuration > Classifier Global Setting. Set Match Order as "manual", activate "Logging", and apply.

Class	ifier Global Se	tting	Classifier Configuratio
Match Order	manual •		
1.11	Active		
Logging	Interval	3600	Second(s)
			Apply Cancel

4 Advanced Application > Classifier > Classifier Configuration. Activate with name "Source IP", and Weight 32767. Check "Log"

& "Count". Set Source IP address as PC 2' IP, Address Prefix "32", and then click "Add" to create.

Classifier	Configuration	Classifier Status Classifier Global Setting
Active		
Name	Source IP	
Weight	32767	
Log		
Count		
Time Range	None 🔻	
	Port	Any
Ingress Port	1 OII	
ingress i on	Trunk	Any
	ITOTIK	
	VLAN	VLAN Any
	VLAN	
	Priority	Priority Any O
	- 1928	
8 64	Ethernet Type	Others (Hex)
Layer 2	Source	MAC Address Any MAC Address MAC /Mask
	Destination	Any MAC Address MAC /Mask
	DSCP	IPv4 Any
		IPv6 O Any
	Precedence	Any
Layer 3	ToS	Any
	IP Protocol	All Chers (Dec)
	IPv6 Next Header	All Establish Only Others (Dec)
	Source	IP Address / 192,168,1.50 / 32
	Destination	IP Address / /
Layer 4	Source	Socket Number O To
Luyer 4	Destination	Socket Number O To



5 Advanced Application > Classifier > Classifier Configuration.

Activate with name "Destination IP", and Weight 32766. Check "Log" & "Count". Set Destination IP address as PC 2' IP, Address Prefix "32", and then click "Add" to create.

Classifie	r Configuration	Classifier Status Classifier Global Set
Active		
lame	Destination IP	
Veight	32766	
og		
Count		
me Range	None 🔻	
ngress Port	Port	Any
igress ron	Trunk	Any
	VLAN	VLAN
	Priority	Priority Any
ayer 2	Ethernet Type	All (Hex)
	Source	Any MAC Address MAC /Mask
	Destination	Any MAC Address MAC /Mask
	DSCP	IPv4 Any
	Precedence	Any
ayer 3	ToS	Any
	IP Protocol	All Establish Only Others (Dec)
	IPv6 Next Header	All T Establish Only Others (Dec)
	Source	IP Address / Address Prefix /
	Destination	IP Address / Address Prefix 192.168.1.50 / 32
ayer 4	Source	Socket Number Any
	Destination	Socket Number

6 Advanced Application > Policy Rule. Activate with name "Mirror". Select both "Source IP" and "Destination IP" for



classifiers. Check "Send the packet to the mirror port" for Outgoing Action, and click "Add" to create.

Policy					
Active					
Name	Mirror	_			
Classifier(s)	SourceIP DestinationIP	-			
Parameters	Gene VLAN ID Egress Port	1 1	Bandwidth	Rate Limit O	kbps
	Priority Forwarding	0 ¥			
	 No change Discard the packet 				
	Priority				
	No change				
	Set the packet's 802.1	p priority			
Action	Outgoing				
	Send the packet to the mirror port				
	Send the packet to the pack				
	Set the packet's VLAN ID				
	Rate Limit				
	Enable				



5.11.2 Test the Result

1 Go to Advanced Application > Classifier. The match count number of both classifiers should increase as long as PC 2 is communicating with internet.

	Classifier S	latus			Classifier Configuration
Index	Active	Weight	Name	Match Count	Rule
1	Yes	32767	Source IP	147	SrcIP = 192.168.1.50/32; count; log;
2	Yes	32766	Destination IP	104	DestIP = 192.168.1.50/32; count; log;

2 Use Wireshark to conduct packet capturing on PC1. The mirrored traffic of PC2 should be included.

Source	Destination	Protocol	Length VID	Info
192.168.1.50	192.168.1.1	ICMP	74	Echo (ping) request
192.168.1.50	192.168.1.147	ICMP	74	Echo (ping) request
192.168.1.50	192.168.1.147	ICMP	74	Echo (ping) request
192.168.1.147	192.168.1.50	ICMP	74	Echo (ping) reply
192.168.1.147	192.168.1.50	ICMP	74	Echo (ping) reply



5.11.3 What May Go Wrong

1 In Advanced Application > Policy Rule, there is the Outgoing Action "Send the packet to the mirror port". The mirror port

here stands for the **[Monitor Port]** but **NOT** the **[Mirrored**]

Port_j in **Advanced Application > Mirroring**.


Mirroring		
nitor Port O		
Port	Mirrored X	Direction
•		Ingress 🔻
1		Ingress 🔻
2		Ingress 🔻
3		Ingress 🔻
4		Ingress 🔻
5		Ingress 🔻
6		Ingress 🔻
7		Ingress 🔻
8		Ingress 🔻
9		Ingress 🔻
10		Ingress 🔻




5.12 How to Separate Traffic through L2 Port Isolation

It's a common application that we desire to separate or isolate the mutual traffic between various clients/devices on switches in a network environment.


The most intuitive implementation is to create different VLANs to logically segment a LAN into different broadcast domains to achieve the goal.



However, there are certain circumstances that we may want the traffic between clients to be isolated, but yet clients still share the same subnet and VLAN. Let's say in a commercial hotel network, clients in different rooms may belong the same subnet and VLAN to reach the internet, but there is no way that clients are able to communicate with each other.



On the Zyxel enterprise switch, we can use the feature "Port Isolation" in Advanced Application -> VLAN -> VLAN Configuration -> VLAN Port Setup to separate traffic between specific ports despite belonging to the same VLAN.



Name	Device	VLAN	IP Address	Subnet Mask
Gateway	USG310	1	192.168.1.254	255.255.255.0
Switch A	GS2210-8	1	192.168.1.1	255.255.255.0
Switch B	GS2210-8	1	192.168.1.2	255.255.255.0
Switch C	G\$2210-8	1	192.168.1.3	255.255.255.0
Client A	PC	1	192.168.1.101	255.255.255.0
Client B	PC	1	192.168.1.102	255.255.255.0
Client C	PC	1	192.168.1.103	255.255.255.0
Client D	PC	1	192.168.1.104	255.255.255.0

This is a scenario from customer's issue. All client PCs are in the same subnet and VLAN

By using L2 port isolation on the switches, the goals are:

- 1. Every PC can surf the internet.
- 2. Every PC cannot communicate with each other.



In the following content, a step-by-step procedure will be introduced of how to implement L2 port isolation using 3 x GS2210-8 to achieve the goal.

V Note:

All network addresses and subnet masks are used as examples in this article. Please

replace them with your actual network configuration.

5.12.1 Configuration in the Switch

- 1 Access Switch C's web GUI.
- 2 Go to Advance Application > VLAN > VLAN Configuration > VLAN Port Setup

Check Port Isolation for port 1 & 2.

							GVRP
g Isolatior	VLAN Trunking	Frame Type	Acceptable	GVRP	PVID	Ingress Check	Port
		•	All				•
		Ŧ	All				1
		T	All		1		2
		•	All				З
		Υ.	All				4
		*	All				5
		•	All		1		6
		•	All				7
		•	All		1		8
		¥	All				9
			All		1		10

Apply Cancel

∛ Note:

If there are multiple clients under switch B, follow the same configuration pattern as Switch C. In this case, it's unnecessary since there's only one client under switch B.

3 Access Switch A's web GUI.

4 Go to Advance Application > VLAN > VLAN Configuration > VLAN Port Setup

Check Port Isolation for port 1, 7 & 8.

www.zyxel.com

VLAN Port Setting		VLAN Configuration
GVRP		

*		All	•	
1	1	All	•	
2	1	All	•	
3	1	All	•	
4	1	All	•	
5	1	All	•	
6	1	All		
7	1	All	•	
8	1	All	•	
9	1	All	•	
10	1	All	v	

Apply Cancel

5.12.2 Test the Result

1 Client D can ping Gateway and surf the internet.

C:\Users\ZT02721>ping <u>192.168.1.254</u> Gateway Pinging 192.168.1.254 with 32 bytes of data: Reply from 192.168.1.254: bytes=32 time=1ms TTL=254 Reply from 192.168.1.254: bytes=32 time=1ms TTL=254 Reply from 192.168.1.254: bytes=32 time=1ms TTL=254 Reply from 192.168.1.254: bytes=32 time=1ms TTL=254
Ping statistics for 192.168.1.254: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 1ms, Maximum = 1ms, Average = 1ms
C:\Users\ZT02721>ping 8.8.8.8 Internet Pinging 8.8.8.8 with 32 bytes of data: Reply from 8.8.8.8: bytes=32 time=3ms TTL=55 Reply from 8.8.8.8: bytes=32 time=3ms TTL=55 Reply from 8.8.8.8: bytes=32 time=3ms TTL=55 Reply from 8.8.8.8: bytes=32 time=3ms TTL=55
Ping statistics for 8.8.8.8: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 3ms, Maximum = 3ms, Average = 3ms

2 Client D cannot communicate with Client A, B, or C.

C:\Users\ZT02721>ping 192.168.1.101

Pinging 192.168.1.101 with 32 bytes of data: Reply from 192.168.1.104: Destination host unreachable. Request timed out. Request timed out. Ping statistics for 192.168.1.101: Packets: Sent = 4, Received = 1, Lost = 3 (75% loss), C:\Users\ZT02721>ping 192.168.1.102 Pinging 192.168.1.102 with 32 bytes of data: Reply from 192.168.1.104: Destination host unreachable. Request timed out. Request timed out. Request timed out. Request timed out. Ping statistics for 192.168.1.102: Packets: Sent = 4, Received = 1, Lost = 3 (75% loss), C:\Users\ZT02721>ping 192.168.1.103 Pinging 192.168.1.103 with 32 bytes of data: Reply from 192.168.1.104: Destination host unreachable. Request timed out. Ping statistics for 192.168.1.103 Pinging 192.168.1.103 with 32 bytes of data: Reply from 192.168.1.104: Destination host unreachable. Request timed out. Request timed out. Ping ing 192.168.1.103 with 32 bytes of data: Reply from 192.168.1.104: Destination host unreachable. Request timed out. Request timed out. Ping statistics for 192.168.1.103: Packets: Sent = 4, Received = 1, Lost = 3 (75% loss),

5.12.3 What May Go Wrong

1 L2 port isolation is port-based but not VLAN-based, that is, as long as particular ports are configured as isolation ports, they cannot communicate with each other no matter in the same VLAN or not.

Implementing VOIP

6.1 How to configure an IP Phone's VLAN using LLDP-MED

The example shows administrators how to use LLDP-MED to configure an IP Phone's VLAN ID. Any IP Phone connected to the switch will be assigned to the certain VLAN based on the switch's port. In the following topic, we will also introduce other ways to send VOIP traffic into a specific (Voice) VLAN. Implementing VOIP allows administrators the option to prioritize Voice traffic during network congestions, thus, preventing poor voice quality or miscommunications between IP Phones.




Figure 23 Configure LLDP-MED to assign an IP Phone's VLAN

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XG\$4600-32 (Firmware Version: V4.50).



6.1.1 Configure VLAN for IP Phone

 Configure VLAN 100 on Switch (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments). VLAN 100 is created for the IP Phone.

6.1.2 Configure Switch

 Enter the web GUI and go to Menu > Advanced Application > LLDP > LLDP Configuration. Make sure that the LLDP configuration is active.

LLDP Configuration		LLDP Basic TLV Setting Org-specific TLV Setting
Active		
Transmit Interval	30	seconds
Transmit Hold	4	times
Transmit Delay	2	seconds
Reinitialize Delay	2	seconds
	Apply Co	incel

- 2 Enter web GUI and go to Menu > Advanced Application > LLDP
 - > LLDP-MED Configuration. Check the "Network Policy" on port1 (the port that connects to the IP Phone).

LLDP-MED Configuration							
Port	Notification		LV Setting				
	Topology Change	Location	Network Policy				
•							
1							
2							
3							

3 Enter the web GUI and go to Menu > Advanced Application > LLDP > LLDP-MED Network Policy. Key in the port number as 1 and the VLAN we want to assign the IP Phone to (VLAN 100) and leave DSCP as "0". We can also set the Priority. Click "Add".

www.zyxel.com



LLDP-MED Netw	rork Policy	<u>LLDP</u>
Port	1	
Application Type	voice •	
Tag	tagged 🔻	
VLAN	100	
DSCP	0	
Priority	7 🔻	
	Add Cancel	

6.1.3 Test the Result

1 Go to Menu > Management > MAC Table > Search. Check the MAC table. The IP Phone's MAC address should be in VLAN 100.

ndex	MAC Address	VID	Port	Туре
1	00:15:65:93:81:54	1	1	Dynamic
2	00:15:65:93:81:54	100	1	Dynamic
3	00:1e:33:27:04:93	1	16	Dynamic
4	42:73:74:20:55:56	1	CPU	Static
5	42:73:74:20:55:56	10	CPU	Static

2 Enter the web GUI and go to Menu > Management > Diagnostic > Ping test. Use Switch to ping the IP Phone. The switch can ping the IP Phone successfully.

	● IPv4	- •	
	O IPv6	- •	
Ping Test	IP Address/Host Name	192.168.100.100	Ping
	Source IP Address		
	Count	3	

	Diagnostic	2				
Resolv	ving 192.1	68.100.1	100	192.168.1	00.100	
sent i	rcvd rate	rtt	avg	mdev	max min reply from	
1	1 100	0 0	0	0	0 192.168.100.100	
2	2 100	0 0	0	0	0 192.168.100.100	
3	3 100	0 0	0	0	0 192.168.100.100	
						/
						_

6.1.4 What Could Go Wrong

- If the MAC address of the IP Phone is not assigned to the VLAN 100 successfully, please check if the IP Phone supports LLDP-MED. LLDP-MED must be enabled on the switch.
- 2 Since the IP Phone is assigned a VLAN ID via the function of the Network Policy in LLDP-MED, the voice traffic from the switch must be tagged backed to the IP Phone. Port 1 in VLAN 100 on the Switch should be tagged out (Check TX tagging) so that the Switch can ping the IP Phone successfully.
- 3 Since the IP Phone is assigned a VLAN ID via the function of the Network Policy in LLDP-MED, please make sure the IP Phone either supports LLDP-MED, or has LLDP-MED enabled.

6.2 How to configure the switch to separate VOIP traffic from data traffic

The example shows administrators how to use Voice VLAN to separate untagged VOIP traffic from untagged data traffic. Unlike traditional VOIP applications, the Voice VLAN feature separates VOIP and data traffic as traffic **reaches the switch**. This means that the VLAN architecture begins on the switch and not on the IP Phones themselves.




Figure 24 Configure Voice VLAN to separate VOIP traffic from data traffic

∛ Note:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XGS4600-32 (Firmware Version: V4.50).

6.2.1 Configure VLAN 100 for IP Phone

 Configure VLAN 100 on Switch (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments). VLAN 100 is created as the Voice VLAN for the IP Phone.

6.2.2 Configure Voice VLAN

1 Enter the web GUI and go to: Menu > Advanced Application > VLAN > VLAN Configuration > Voice VLAN Setup. Input the Voice VLAN. In this example, it is VLAN 100. Click "Apply".

Voice VLAN Setup Voice VLAN Global Setup		VLAN Configuration
Voice VLAN	Disable	
Priority	5 🔻	
	Apply Cancel Clear	

2 Configure the OUI Setup: Enter the web GUI and go to: Menu > Advanced Application > VLAN > VLAN Configuration > Voice VLAN Setup. Set the OUI address. (You can key in the MAC address.) In this example, it is cc:5d:4e:64:de:77. Set up the OUI mask as ff:ff:ff:00:00:00. Click "Add".

Voice VLAN OUI Setup	
OUI address	cc:5d:4e:64:de:77
OUI mask	ff:ff:ff:00:00:00
Description	ZYXEL IP Phone
	Add Cancel
∛ Vote:	

This will instruct the switch to process any traffic from devices with MAC address between cc:5d:4e:00:00:00 and cc:5d:4e:ff:ff:ff into the Voice VLAN.

6.2.3 Test the Result

 Go to Menu > Management > MAC Table > Search. Check the MAC address table. The IP Phone is assigned to VLAN 100.

Index	MAC Address	VID	Port	Туре
1	00:1e:33:27:04:93	1	9	Dynamic
2	42:73:74:20:55:56	1	CPU	Static
3	42:73:74:20:55:56	100	CPU	Static
4	cc:5d:4e:64:de:77	100	1	Dynamic

2 Enter web GUI and go to Menu > Management > Diagnostic > Ping test. Use Switch to ping IP Phone. Switch can ping IP Phone successfully.

	● IPv4	- •	
	O IPv6	- •	
Ping Test	IP Address/Host Name	192.168.100.100	Ping
	Source IP Address		
	Count	3	

		D	iagnosti	C					
Re	esol	vin	g 192.1	68.10	00.10	00 1	92.168.	100.100	
S	ent	rc	vd rate	rtt	t o	vg	mdev	max min reply from	
	1							0 192.168.100.100	
	2	2	100	0	0	0	0	0 192.168.100.100	
	3	3	100	0	0	0	0	0 192.168.100.100	
									1

6.2.4 What Could Go Wrong

- 1 If the IP phone is not assigned to the voice VLAN, please verify the MAC address of the IP phone. The MAC address can usually be found on the label or sticker underneath the IP phones. This MAC address must be within the range of the Voice VLAN OUI settings.
- 2 Here are the expected behaviors of IP phones based on the different settings. If you find the behaviors of the IP Phone is not the same as your expectation, please refer below:
- a. If the IP Phone is VLAN enabled and this VLAN is the same as Voice VLAN: The Switch will keep the Voice VLAN and assign the priority setting to the IP phone. The IP phone will only recognize the tagged traffic. In this case, port 1 in VLAN 100 on Switch should be set as tagged out (check the TX tagging box).
- b. If the IP Phone is VLAN enabled and this VLAN is different from the switch's Voice VLAN: The Switch will not apply any changes on the VOIP traffic of the IP Phone.
- c. If the IP Phone is VLAN **disabled**: The Switch will assign the Voice VLAN and priority setting to the IP phone's VOIP traffic. This setting causes the IP Phone to only send and receive **untagged** traffic. In this case, port 1 in VLAN 100 on Switch should be set as **untagged out** (uncheck the TX tagging box).

6.3 How to configure the switch to improve Voice traffic quality

The example shows administrators how to use Voice VLAN to improve Voice traffic. Like the introduction in topic 6.2, Voice VLAN not only groups voice traffic into an assigned VLAN, but also assign the voice traffic a certain priority. Administrators can use this priority to improve Voice traffic quality. The Voice VLAN priority can be applied to both tagged and untagged voice traffic.




Figure 25 Configure Voice VLAN to separate VOIP traffic from data traffic

€ Vote:

All network IP addresses and subnet masks are used as examples in this article. Please replace them with your actual network IP addresses and subnet masks. This example was tested using XG\$4600-32 (Firmware Version: V4.50) and G\$2210-48HP (Firmware Version: V4.30).

6.3.1 Configure VLAN for voice traffic

1 Configure VLAN 100 on Switch-1 and Switch-2. (Please refer to the topic: 2.1 How to configure the switch to separate traffic between departments). VLAN 100 is created for the Voice VLAN. Make sure that devices in VLAN 100 can communicate across Switch-1 and Switch-2.



6.3.2 Configure Voice VLAN

Enter the web GUI and go to: Menu > Advanced Application > VLAN > VLAN Configuration > Voice VLAN Setup. Key in the Voice VLAN. In this example, it is VLAN 100. Assign a priority to the traffic, for example, priority=6. Click "Add".

Voice VLAN Selup Voice VLAN Global Selup		VLAN Configuration
Voice VLAN Priority	 Disable 100 6 T 	
	Apply Cancel Clear	

2 Configure the OUI Setup: Enter the web GUI and go to: Menu > Advanced Application > VLAN > VLAN Configuration > Voice VLAN Setup. Set the OUI address. (You can key in the MAC address.) In this example, it is cc:5d:4e:64:de:77. Set up the OUI mask as ff:ff:ff:00:00:00. Click "Add".

Voice VLAN OUI Setup	
OUI address	cc:5d:4e:64:de:77
OUI mask	ff:ff:ff:00:00:00
Description	ZYXEL IP Phone
	Add Cancel
℃ Note:	

This will instruct the switch to process any traffic from devices with MAC address between cc:5d:4e:**00:00:00** and cc:5d:4e:**ff:ff:ff** into the Voice VLAN.

6.3.3 Configure Mirroring (For "Test the Result")

1 To verify that results are acceptable, we have to use the mirroring function to check if the priority of the packet is what we assigned. Enter the web GUI and go to Menu > Advanced Application > Mirroring. Check the "Active" box. Key in the Monitor port, which is used to monitor the traffic. Check the port we want to mirror. In this example, it is port 2. Select the direction as "Both". Click "Apply".

Mirroring		<u>RMirror</u>
Active		
Monitor Port	10	
Port	Mirrored	Direction
*		Ingress 🔻
1		Ingress 🔻
2		Both 🔻
3		Ingress 🔻

6.3.4 Test the Result

- Connect the PC and Switch-1. Open Wireshark to monitor the packet. Filter "arp || igmp".
- 2 Use Switch-2 to ping IP Phone: Enter web GUI and go to Menu
 > Management > Diagnostic > Ping test. Switch-2 can ping IP Phone successfully.
- **3** Check the packet from IP Phone (**192.168.100.100**) on Wireshark. The VLAN header should indicate the assigned Voice VLAN priority "6".


	🔳 🖉 💿 🌗 🔚 🗙	🖸 । ९ 🗢 🗢 😤 🤇	ि 🕹 🚍 🔲 🍳 ९ ९ 🎹			
	arp II icmp					
No.	Time	Source	Destination	Protocol	Length Info	
	17 1.704977	192.168.100.2	192.168.100.100	ICMP	78 Echo (ping) request	id=0x2014
	18 1.704980	192.168.100.2	192.168.100.100	ICMP	78 Echo (ping) request	id=0x2014
	19 1.704982	192.168.100.100	192.168.100.2	ICMP	78 Echo (ping) reply	id=0x2014
	20 1.704985	192.168.100.2	192.168.100.100	ICMP	78 Echo (ping) request	id=0x2014
⊳	Frame 19: 78 bytes	on wire (624 bit	s), 78 bytes captured (62	24 bits) on	interface 0	
⊳	Ethernet II, Src:	ZyxelCom 64:de:77	/ (cc:5d:4e:64:de:77), Dst	t: ZyxelCom	14:97:5c (04:bf:6d:14:97:5c	:)
⊿	802.10 Virtual LAN	I, PRI: 6, CFI: 0,	ID: 100			
۱ '	110	<pre> = Priority:</pre>	Voice, < 10ms latency and	jitter (6))	
	0	= CFI: Canon	ical (0)			
	0000 0110 (0100 = ID: 100				
	Type: IPv4 (0x0	800)				

6.3.5 What Could Go Wrong

- 1 If the priority is not the same as the setting in voice VLAN, please verify the MAC address of the IP phone. The MAC address can usually be found on the label or sticker underneath the IP phones. This MAC address must be within the range of the Voice VLAN OUI settings
- 2 Here are the expected behaviors of IP phones based on the different settings. If you find the behaviors of the IP Phone is not the same as your expectation, please refer below:
- a. If the IP Phone is VLAN enabled and this VLAN is the same as Voice VLAN: The Switch will keep the Voice VLAN and assign the priority setting to the IP phone. The IP phone will only recognize the tagged traffic. In this case, port 1 in VLAN 100 on Switch should be set as tagged out (check the TX tagging box).
- b. If the IP Phone is VLAN enabled and this VLAN is different from the switch's Voice VLAN: The Switch will not apply any changes on the VOIP traffic of the IP Phone.
- c. If the IP Phone is VLAN **disabled**: The Switch will assign the Voice VLAN and priority setting to the IP phone's VOIP traffic. This setting causes the IP Phone to only send and receive **untagged** traffic. In this case, port 1 in VLAN 100 on Switch should be set as **untagged out** (uncheck the TX tagging box).
- 3 Some computer network cards may not support the 802.1Q (VLAN) information. If you don't see the 802.1Q information in Wireshark, you may need to use a different NIC. We recommend using USB network adapters.

6.4 How to Configure Voice VLAN on Zyxel Switch

Use voice VLAN to separate voice packets from other service packets. Prioritize the voice packet to enhance the voice quality and user



Nowadays IP phones are commonly used in office environments, to give voice traffic a higher priority is an important consideration when designing a network.

Common scenario of the installation, the IP phone is connected to a switch on one end while linking the PC or laptop on the other end bridging both devices. In this case, Voice VLAN is an important feature used to easily mark and prioritize voice packets from IP phone, separating data packets from the PC.

In the following configuration guide, the goal to achieve is to separate traffic between the IP phone and PC without having to set individual VLAN tags for them. The Switch will add VLAN tags for voice & data packets separately upon receiving them and then forwarded to the uplink.

6.4.1 Configuration

The following steps for standalone switch configuration is applicable to the GS1920 smart managed switch series and above.

Create VLAN interfaces

Create a VLAN for voice packets transmission, select ports which are connected to IP phone, unselect Tx tagging as to save efforts of configuring VLAN on each phones.

ZYXEL GS2210						C Refresh	L Save	1 Status		P He
Menu										
Basic Setting	Static VLAN				VLAN Configuration					
Advanced Application	ACTIVE									
P Application	Name		Voice	VIAN						
Management	VLAN Group ID		10	VENIX						
includige internet	to the Group io		10							
VLAN										
Static MAC Forwarding	Port		Control							
Static Multicast Forwarding	Porr		Fixed	•	Tagging					
Fillering		0			Tx Tagging					
Spanning Tree Protocol Bandwidth Control	-	Normal	Fixed	Forbidden	Tx Tagging					
Broadcast Storm Control	2	Normal	Fixed	Forbidden	Tx Tagging					
Mirroring	3	Normal	Fixed	Forbidden	Tx Tagging					
Link Aggregation	4	Normal	Fixed	Forbidden	Tx Tagging					
Port Authentication	5	Normal	Fixed	Forbidden	🔲 Tx Tagging					
Port Security	6	Normal	Fixed	Forbidden	Tx Tagging					
Time Range Classifier	7	Normal	Fixed	Forbidden	Tx Tagging					
Classifier Policy Rule	8	Normal	Fixed	Forbidden	Tx Tagging					
Queuing Method	9	Normal	Fixed	Forbidden	Tx Tagging					
Multicast	10	Normal	Fixed	Forbidden	Tx Tagging					
AAA	11	Normal	Fixed	Forbidden	Tx Tagging					
IP Source Guard	12	Normal	Fixed	Forbidden	Tx Tagging					
Loop Guard	13	Normal	Fixed	Forbidden	Tx Tagging					
VLAN Mapping Laver 2 Protocol Tunnelina	14	Normal	Fixed	Forbidden	Tx Tagging					
PPPoE	15	Normal	 Fixed 	Forbidden	Tx Tagging					
Endisable										
Private VIAN	. 16	Normal	Fixed	Forbidden	Tx Tagging				v Zvxel Commu	

Create another VLAN for data packets, select member ports, unselect Tx tagging.



Menu							
Basic Setting	Stalic VLAN				VLAN Configurati	ion	
Advanced Application	ACTIVE						
P Application	Name		Interne	5†			
Management	VLAN Group ID		5				
VLAN							
Static MAC Forwarding Static Multicast Forwardina	Port		Control		Tagging		
Static Muticast Forwarding Fillering			Normal	*	Tx Tagging		
Spanning Tree Protocol	1	Normal	Fixed	Forbidden	Tx Tagging		
Bandwidth Control	2	Normal	 Fixed 	Forbidden	Tx Tagging		
Broadcast Slorm Control	3	Normal	 Fixed 	Forbidden	Tx Tagging		
Mirroring	4	Normal	 Fixed Fixed 	Forbidden			
Link Aggregation					Tx Tagging		
Port Authentication	5	Normal	Fixed	Forbidden	Tx Tagging		
Port Security	6	Normal	Fixed	Forbidden	🔲 Tx Tagging		
Time Range Classifier	7	Normal	Fixed	Forbidden	Tx Tagging		
Policy Rule	8	Normal	Fixed	Forbidden	Tx Tagging		
Queuing Method	9	Normal	Fixed	Forbidden	Tx Tagging		
Mullicast	10	Normal	Fixed	Forbidden	Tx Tagging		
AAA	11	Normal	Fixed	Forbidden	Tx Tagging		
P Source Guard	12	Normal	 Fixed 	Forbidden	Tx Tagging		
Loop Guard							
VLAN Mapping	13	Normal	Fixed	Forbidden	Tx Tagging		
Layer 2 Protocol Tunneling	14	Normal	Fixed	Forbidden	Tx Tagging		

On the uplink port enable Tx Tagging to transmit packets with VLAN tags.

11	Normal	Fixed	Forbidden	Tx Tagging	
12	Normal	Fixed	Forbidden	Tx Tagging	
13	Normal	Fixed	Forbidden	🗹 Tx Tagging	
14	Normal	Fixed	Forbidden	Tx Tagging	

Configure PVID to separate data packets from voice packets. PVID number should be same as the VLAN number created for data packets.

Menu											
Basic Setting		VLAN Port Setti	ng				VLAN	Configuration			
Advanced Application	GVRP										
IP Application	GVRP										
Management	_			_							
VLAN	Port	Ingress Chec		GVRP				Isolation			
Static MAC Forwarding			5		All	•					
Static Multicast Forwarding	1	8	6		All		8				
Fillering	1		5			122					
Spanning Tree Protocol	2		5		All	•					
Bandwidth Control	3		5		All	Ψ.					
Broadcast Storm Control	4		5		All						
Mirroring Link Aggregation	5		5		All						
Link Aggregation Port Authentication	6		5		All						
Port Security	7	200	0								
Time Range			5		All	•					
Classifier	8		5		All	Ŧ					
Policy Rule	9		5		All	•					
Queuing Method	10		5		All						
Mullicast	11		5	1	All	T					
AAA	12		6		All						
IP Source Guard		100,000	5								
Loop Guard	13		5		All	•					
VLAN Mapping	14		5		All	*					
Layer 2 Protocol Tunneling	15		5		All						



After setting PVID for data packets, next step is to configure "Voice VLAN" feature for the switch to identify the voice packets.

Configure Voice VLAN

Configure Voice VLAN number and priority to prioritize the voice packets. Voice VLAN number should be same as the VLAN number created earlier for voice service packets.

Specify the OUI addresses. OUI are the first 3 bytes of a MAC address that represents the vendor. Through specifying the IP phone MAC address, the switch can identify voice traffic accordingly. Zyxel switch supports up to 6 vendor OUIs.

	oice VLAN Setup N Global Setup		VLAN	Configuration
Voice VL/	AN	Disable10		
Priority		5 🔻		
		Apply Cancel Clear		
Voice VLA	N OUI Setup			
OUI addr	ess	00:15:65:00:00:00		
OUI mask	:	ff:ff:ff:00:00:00		
Descriptio	on			
		Add Cancel		
Index	OUI address	OUI mask	Description	
1	00:15:65:00:00:00	ff:ff:ff:00:00:00		
		Delete Cancel		

∛ Note:

This guide demonstrates the ease of configuring Voice VLAN on standalone switches. In general, separating VLANs and determine rules for data and voice achieved the goal of prioritizing voice traffic without additional configuration on the IP phones. The applicable model for standalone switches are of GS1920 series and above.

6.4.2 Test the result

Go to the VLAN Configuration to check the VLAN status, you will see the status of VLAN 10 is Voice VLAN.

VLAN Status			VLAN Configuration
AN Search by V	/ID	Search	
lumber of VLAI Index	N: 3. VID	Elapsed Time	Status
	1000000	Elapsed Time 48:16:52	Status Static
	1997 B 1997		

Check mac address table and you will see the mac address of IP phone is VLAN 10 and the mac address of PC is VLAN 5

GS2210#	show mac	аа		
Port	VLAN	ID	MAC Address	Type
13	10		00:15:65:93:81:54	Dynamic
13	5		00:1e:33:28:0a:84	Dynamic

Index	MAC Address	VID	Port	Туре
1	00:15:65:93:81:54	10	13	Dynamic
2	00:1e:33:28:0a:84	5	13	Dynamic
3	38:d5:47:8d:0b:91	1	24	Dynamic

6.4.3 What Could Go Wrong

Here are the expected behaviors of IP phones based on the different settings. If you find the behaviors of the IP Phone is not the same as your expectation, please refer below:

- a. If the IP Phone is VLAN **enabled** and this VLAN is the same as **Voice VLAN**: The Switch will keep the Voice VLAN and assign the priority setting to the IP phone. The IP phone will only recognize the tagged traffic. In this case, port 1 in VLAN 100 on Switch should be set as **tagged out** (check the TX tagging box).
- b. If the IP Phone is VLAN enabled and this VLAN is different from the switch's Voice VLAN: The Switch will not apply any changes on the VOIP traffic of the IP Phone.
- c. If the IP Phone is VLAN **disabled**: The Switch will assign the Voice VLAN and priority setting to the IP phone's VOIP traffic. This setting causes the IP Phone to only send and receive **untagged** traffic. In this case, port 1 in VLAN 100 on Switch should be set as **untagged out** (uncheck the TX tagging box).